


AD-A152 148


DEVELOPMENT OF GRAPHICAL POLE-ZERO ROOT-LOCUS BODE
NYQUIST AND NICHOLS RESPONSES USING THE OPTSYSX PROGRAM
(U) NAVAL POSTGRADUATE SCHOOL MONTEREY CA M H LAPTAS
SEP 84 F/G 9/2

1/3

UNCLASSIFIED

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS 1963-A

(2)

NAVAL POSTGRADUATE SCHOOL

Monterey, California



DTIC
ELECTE
APR 5 1985
S B D

AD-A152 148

DTIC FILE COPY

THESIS

DEVELOPMENT OF GRAPHICAL POLE-ZERO,
ROOT-LOCUS, BODE, NYQUIST, AND NICHOLS
RESPONSES USING THE OPTSYSX PROGRAM

by

Michael Henry Laptas

September 1984

Thesis Advisor:

Daniel J. Collins

Approved for public release; distribution unlimited

85 03 18 015

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) Development of Graphical Pole-Zero, Root-Locus, Bode, Nyquist, and Nichols Responses Using the OPTSYSX Program		5. TYPE OF REPORT & PERIOD COVERED Master's Thesis September 1984
7. AUTHOR(s) Michael Henry Laptas		6. PERFORMING ORG. REPORT NUMBER
9. PERFORMING ORGANIZATION NAME AND ADDRESS Naval Postgraduate School Monterey, California 93943		8. CONTRACT OR GRANT NUMBER(s)
11. CONTROLLING OFFICE NAME AND ADDRESS Naval Postgraduate School Monterey, California 93943		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office)		12. REPORT DATE September 1984
		13. NUMBER OF PAGES 219
		15. SECURITY CLASS. (of this report)
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE
16. DISTRIBUTION STATEMENT (of this Report) Approved for public release; distribution unlimited		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) OPTSYSX Nyquist Noise. Pole-Zero Nichols Compensator, Root-Locus Transfer function <i>etc.</i> Bode Open Loop		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This thesis discusses the modification of and additions to an existing Optimal Systems Control FORTRAN Program (OPTSYS) originally obtained from Professor Arthur E. Bryson of Stanford University. This program has been subsequently redesigned to run interactively on the IBM 3033 VM/CMS by Lieutenant Commander John G. Hoden, and additions by Commander Harry A. Diel provide the user with a highly accurate graphic time response to a system designed using the OPTSYSX program.		

The addition of the FORTRAN program OPTGRAPH gives the user the capability to obtain classical analysis (Pole-Zero Map, Root Locus, Bode, Nyquist, and Nichols) of transfer functions, calculated for a system designed with the OPTSYSX program. The OPTGRAPH program uses high resolution precision plotting software to provide the user with highly accurate frequency response plots.

This series of programs permits users to rapidly carry out simulation, analysis, and design of Optimal Systems Control problems in a totally interactive mode.

Computer supplied by user - included - > p 1

Accession For	
NTIS GRA&I	<input checked="" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	

Distribution/	
by the DTIC	
to the user	
by the DTIC	
to the user	



A-1

Approved for public release; distribution unlimited.

Development of Graphical Pole-Zero, Root-Locus, Bode,
Nyquist, and Nichols Responses using the
OPTSYSX Program

by

Michael H. Laptas
Lieutenant, United States Navy
B.S., Purdue University, Lafayette, 1977

Submitted in partial fulfillment of the
requirements for the degree of

MASTER OF SCIENCE IN AERONAUTICAL ENGINEERING

from the

NAVAL POSTGRADUATE SCHOOL
September 1984

Author: _____

Michael H. Laptas
Michael H. Laptas

Approved by: _____

D.J. Collins
D.J. Collins, Thesis Advisor

D.M. Layton
D.M. Layton, Second Reader

M.F. Platz

M.F. Platz, Chairman,
Department of Aeronautics

J.N. Dyer

J.N. Dyer,
Dean of Science and Engineering

ABSTRACT

This thesis discusses the modification of and additions to an existing Optimal Systems Control FORTRAN Program (OPTSYS) originally obtained from Professor Arthur E. Bryson of Stanford University. This program has been subsequently redesigned to run interactively on the IBM 3033 VM/CMS by Lieutenant Commander John G. Hoden, and additions by Commander Harry A. Diel provide the user with a highly accurate graphic time response to a system designed using the OPTSYSX program.

The addition of the FORTRAN program OPTGRAPH gives the user the capability to obtain classical analysis (Pole-Zero Map, Root Locus, Bode, Nyquist, and Nichols) of transfer functions, calculated for a system designed with the OPTSYSX program. The OPTGRAPH program uses high resolution precision plotting software to provide the user with highly accurate frequency response plots.

This series of programs permits users to rapidly carry out simulation, analysis, and design of Optimal Systems Control problems in a totally interactive mode.

TABLE OF CONTENTS

I.	INTRODUCTION	9
II.	THE OPTSYSX COMPUTER PROGRAM	11
	A. BACKGROUND	11
	B. OVERVIEW	11
	C. OPTSYSX MODIFICATIONS	12
	D. OPTSYS EXEC MODIFICATIONS	13
III.	THE OPGRAPH PROGRAM	15
	A. PROGRAM OVERVIEW	15
	1. Program Language	15
	2. Graphics Package	15
	3. Library Subroutines	15
	4. Program Composition	16
	B. GENERAL PROGRAM OPERATION	16
	1. User Protection Features	16
	2. Large Order System	17
	C. SYSTEM/MODEL DESCRIPTION	18
	D. PROGRAM ORGANIZATION	19
	1. Main Program	19
	2. Program Sequencing	20
	3. Graphic and/or Tabular System Response	21
	E. INTERACTIVE EXAMPLES	23
	F. CHARACTERISTIC EQUATION ANALYSIS	24
	1. Pole-Zero Map	24
	2. Pole-Zero Map (Interactive Example)	25
	3. Root-Locus	33
	4. Root-Locus (Interactive Example)	34

G.	FREQUENCY RESPONSE ANALYSIS	43
1.	Bode Response	44
2.	Bode Response (Interactive Example) . . .	45
3.	Nyquist Response	51
4.	Nyquist Response (Interactive Example) . .	52
5.	Nichols Response	52
6.	Nichols Response (Interactive Example) . .	52
IV.	CONCLUSIONS AND RECOMMENDATIONS	59
A.	CONCLUSIONS	59
B.	RECOMMENDATIONS	60
1.	Root Finding Routines	60
2.	Program Memory Requirements	61
3.	Further Modifications	61
	APPENDIX A: OPTSYS EXEC LISTING	62
	APPENDIX B: OPTSYSX PROGRAM LISTING	71
	APPENDIX C: OPTGRAPH PROGRAM LISTING	160
	APPENDIX D: OPGRAPH LISTING	215
	LIST OF REFERENCES	217
	BIBLIOGRAPHY	218
	INITIAL DISTRIBUTION LIST	219

LIST OF FIGURES

3.1	Pole-Zero Map Example	53
3.2	Root Locus Response Example	54
3.3	Bode Response Example (Magnitude)	55
3.4	Bode Response Example (Phase)	56
3.5	Nyquist Response Example	57
3.6	Nichols Response Example	58

SYMBOLS

A = State (N_s, N_s) or Output (N_o, N_o) Weighting Matrix
 B = Control (N_c, N_c) Weighting Matrix
 C = Control Gain Matrix (N_c, N_s)
 D = Control (N_o, N_c) or Noise (N_o, N_g) Feedforward Matrix
 F = Open-Loop Dynamics Matrix (N_s, N_s)
 G = Control Distribution Matrix (N_s, N_c)
 GAM = State Disturbance Distribution Matrix (N_s, N_g)
 H = Measurement Scaling Matrix (N_o, N_s)
 K = Estimator Gain Matrix (N_s, N_o)
 N_c = Number of Controls
 N_g = Number of Process Noise Sources
 N_s = Number of States
 N_o = Number of Observations or Measurements
 Q = White Process Noise Covariance Matrix (N_g, N_g)
 R = White Meas. Noise Covariance Matrix (N_o, N_o)
 S = Steady-State Covariance Matrix of Control (N_c, N_c)
 u = Control Vector ($N_c, 1$)
 v = White Measurement Noise Vector ($N_o, 1$), with Zero Mean and Covariance Matrix R
 w = White Process Noise Vector ($N_g, 1$), with Zero Mean and Covariance Matrix Q
 w_0 = Constant Disturbance Vector ($N_g, 1$)
 x = State Vector ($N_s, 1$)
 \dot{x} = Derivative of State Vector ($N_s, 1$)
 \hat{x} = Estimate of State Vector ($N_s, 1$)
 $\dot{\hat{x}}$ = Derivative of Estimate of State Vector ($N_s, 1$)
 y = Output Vector ($N_o, 1$)
 z = Measurement Vector ($N_o, 1$)

I. INTRODUCTION

The purpose of this thesis is to describe the modification and additions to the existing FORTRAN program (OPTSYS) which is used in the study and application of Optimal Systems Control theory.

The Optimal Systems control program was originally developed by Hall [Ref. 1] to support his research in rotary-wing aircraft control systems. Later program modifications were made by Walker [Ref. 2] and Liu [Ref. 3] of Stanford University, and are designated OPTSYS 4 and OPTSYS 5 respectively. OPTSYS modifications made by Hoden [Ref. 4] were primarily devoted to creating a user-friendly interactive version (OPTSYSX) of the OPTSYS 4 program. The latest modifications by Diel [Ref. 5] allowed the user to save matrices for subsequent runs of the OPTSYSX program, and formed data file sets for the time response program OPTCALC.

The intent of this thesis work was to develop an interactive program to plot the Pole-Zero map, Root-Locus, Bode, Nyquist, and Nichols responses to the open loop, closed loop noise, and compensator transfer functions of a State Variable Control System which has been developed using OPTSYS Program. Minor modifications to the OPTSYSX Program were necessary to construct a data file sets for plotting the Pole-Zero Map, and in calculations for the Root-Locus, Bode, Nyquist, and Nichols plots.

It is assumed that the user is familiar with the basic concepts of Control Theory and Optimal Systems Design. The symbol/naming conventions of Bryson [Ref. 6]. are used in the discussion of program operations and descriptions of problems using the OPTSYS System.

An overview of the OPTSYSX Program capabilities and of modifications to the existing programs is presented first. This is followed by a description of the program (OPTGRAPH), which was developed to plot the Pole-Zero Map and to perform calculations for the Root-Locus, Bode, Nyquist, and Nichols plots.

This work concludes with examples of various types of problems demonstrated in the interactive mode, including a copy of each terminal session with the final results. Complete program listings for the OPTSYS EXEC program, OPTSYSX program, and OPTGRAPH program are included in appendices A,B, and C respectively.

II. THE OPTSYSX COMPUTER PROGRAM

A. BACKGROUND

OPTSYSX is a double-precision, interactive FORTRAN program employing modern control theory analysis techniques. Its capabilities include the calculation of the open-loop eigensystem, and the stationary closed loop system; the synthesis of regulators and filters; along with power spectral density, and modal distribution computations. The modifications introduced to the OPTSYSX program by this thesis work do not affect the program's original capabilities.

B. OVERVIEW

OPTSYSX is an extremely large and complex program with over 3000 lines of code. To use the program in its small version (dimensioned for a 32 X 32 "F", "G", and "H" matrices), the user must extend his Virtual Machine (VM) memory capacity beyond the default VM memory capacity of 720 kilobytes to 1024 kilobytes.

Any significant increase in the OPTSYSX program size, with the the resulting requirement for additional memory capacity, would cause user difficulties. For this reason the task of obtaining the Pole-Zero maps, Root-Locus, and Bode, Nyquist, Nichols plots for the open loop, noise and compensator transfer functions was relegated to a separate program (OPTGRAPH). Three data files (OPTGROL DATA, OPTGRNO DATA, and OPTGRCM DATA), containing the open loop, noise, and compensator transfer functions, are formed by the OPTSYS program to be transferred to the OPTGRAPH program. The OPTSYS EXEC program provides an interface between the

OPTSYSX program, the time response programs (OPTCALC and OPTPLCT), and the OPTGRAPH program.

C. OPTSYSX MODIFICATIONS

OPTSYSX program modifications consist of the addition of write statements, three flags, and a short routine to interpret user inputs.

Write statements, to input data to the OPTGROL, OPTGRNO, and OPTGRCM DATA files were added to the main program, subroutine INNER, subroutine ZEROS, and subroutine POLES. System information consisting of number of states (Ns), number of controls (Nc), number of measurements (No), number of process noise sources (Ng), type transfer function (ITFX), Markov Parameter (IE), and two flags to be used by the OPTSYS EXEC and the OPTGRAPH programs is inputted from the main program. The write statements added to the subroutine INNER, and subroutine POLES input the poles for the open loop and noise transfer functions, and compensator transfer function respectively. The zeros, the numerator order, the gain, and the input and output numbers for all three transfer functions are obtained from the subroutine ZEROS.

The first of the two flags, input with the system information from the main program to the three data files, serves as a marker for the OPTSYS EXEC to locate the correct data line for reading system inputs. The second flag, which is set by the routine to interpret user inputs, serves as a signal for the OPTSYS EXEC to either load the OPTGRAPH program if any one of the three transfer functions was calculated by the OPTSYSX program, and abort loading the OPTGRAPH program if none of the three transfer functions were calculated. The third flag (ITFX) is an existing OPTSYSX program flag. The flag (ITFX) is passed from the

subroutine TF to the subroutine ZEROS to identify the calculation of either an open loop, noise, or compensator transfer function zeros.

The short routine added to the main program of OPTSYSX reads the flags ITF1, ITF2, ITF3, and IRET. The flag sent to the CPTGROL, OPTGRNO, or OPTGRCM DATA files is set to allow loading of transfer function data file to the OPTGRAPH program if the user selects either of the transfer function options number two (calculate poles, residues, and zeros - ITF1 = 1, ITF2 = 1, or ITF3 = 1) number three (calculate poles, and zeros - ITF1 = 2, ITF2 = 2, or, ITF3 = 2) when calculating the open loop, noise, or compensator transfer functions. The selection of any other transfer function option will not calculate the transfer function zeros. The flag IRET is read to determine if the user desires to rerun a problem without exiting the OPTSYSX program. Should the user elect to rerun a problem without exiting OPTSYSX (IRET = 1), the three data files are set back to the beginning (REWIND) to accept the new problem system data.

D. OPTSYS EXEC MODIFICATIONS

The OPTSYS EXEC was written by Diel [Ref. 5] to interface between the OPTSYSX program and the time response programs OPTCALC and CPTPLOT. The modifications to the exec program were to add the option to select running the OPTGRAPH program to the exec menus and a short section to interface the OPTGRAPH program with the OPTSYSX program.

The added section to interface between the OPTSYSX and OPTGRAPH programs defined loader size (LDRTBLE), file definitions (FILEDEF), and text libraries (TXTLIB) for the CPTGRAPH program. The first line of the three data files is read to ensure that there has been at least one of the three transfer functions calculated by the OPTSYSX program prior to loading OPTGRAPH program.

The OPTSYS EXEC routine is also used to send plots to the VERSATEC plotter from the OPTPLOT program and the OPTGRAPH program.

III. THE OPGRAPH PROGRAM

A. PROGRAM OVERVIEW

CPTGRAPH is an interactive FORTRAN program which uses the transfer function poles and zeros calculated by OPTISYSX to calculate, tabulate, and plot the Pole-Zero Map, Pode, Nyquist, Nichols, and Root-Locus responses for either the open loop, closed loop noise, or compensator transfer functions.

1. Program Language

CPTGRAPH is programmed in FORTRAN following the conventions of the IBM System /360/370/ FORTRAN IV language. CPTGRAPH has been compiled and run under both FORTRAN IV (G1) and FORTRAN H (extended) compilers on the IBM 3033.

2. Graphics Package

This program uses the Display Integrated Software System and Plotting System Software (DISSPLA) developed and distributed by the Integrated Software Systems Corporation (ISSCC) of San Diego, California. The DISSPLA package is a library of FORTRAN subroutines using FORTRAN IV conventions.

3. Library Subroutines

CPTGRAPH uses the International Mathematical and Statistical Library (IMSL) subroutine ZRPOLY to calculate the roots of a polynomial equation. ZRPOLY is a double precision FORTRAN subroutine to which is input a polynomial with real coefficients (double precision) in terms of decreasing powers of the polynomial. The subroutine finds the roots of the polynomial and returns a double precision

complex array containing the roots. ZRPOLY is capable of accepting polynomials greater than 0 order and less than 101 order.

4. Program Composition

CPTGRAPH has one main program and 24 subroutines. The main program and its subroutines may be divided into four basic categories:

- 1) File Data Input
- 2) Interactive Data Input
- 3) Plot Setup and Sequencing
- 4) Calculation

A brief and general description of the program and its subroutines will follow in subsequent sections.

B. GENERAL PROGRAM OPERATION

OFTGRAPH was written to satisfy two specific objectives. The first is to create a program to be used as a instructional tool for students taking controls related courses, and the second is as method to assist in the analysis of actual large order control system problems.

To accomplish these objectives the emphasis while writing this program was to make the program as user oriented as possible by attempting to eliminate ambiguities and providing features which would protect the user from inadvertent wrong entries. An effort was also made to minimize the Virtual Machine (VM) memory required to execute the program to facilitate the analysis of a large order system.

1. User Protection Features

Three basic methods were used to protect the user from an abnormal program termination in the case of an inadvertent wrong entry. The first was to construct the

subroutines to display a summary of the user inputs and allowing changes prior to leaving the subroutine. For the case where the user input is expected to fall within a given range, the input is examined and the user is either allowed to continue for an input within the range or issued an error or warning and reasked the question for an input outside the range. The final method is used by the three subroutines which read the user input from the screen. The subroutines RDINT, RDREAL, and RICHAR expect an integer input, real number input, and a logical "yes" or "no" respectively. In the event that a "null" line is inadvertently entered, the user is issued a warning and allowed another opportunity to enter the correct input before abnormally terminating the program. The entry of two "null" lines also offers the user the option to exit the OPTGRAPH program at other than normal program exit points. The subroutine RDCHAR also examines the input and issues a warning if the input is not either "yes" or "no".

2. Large Order System

The large order control problem being considered for analysis by the OPTSYSX and the OPTGRAPH programs is the X-29A aircraft longitudinal axis backup mode system. This system has a (98 X 98) "F" matrix, a (2 X 98) "H" matrix, and a (98 X 1) "G" matrix.

To accommodate this large order system the OPTGRAPH program was dimensioned to accept a system with a maximum of 99 states (Ns), 12 controls (Nc), 12 process noise sources (Ng), and 12 measurements (No). The Virtual Machine (VM) memory requirements for the program were minimized by the reuse of memory locations allocated for storage of calculated data after that data has been either tabulated or plotted. This method of memory reuse has allowed the OPTGRAPH program to be dimensioned to accommodate a large

order system and still operate with less than the 1024 KILOBYTES VM memory required to run OPTSYSX in its small version.

C. SYSTEM/MODEL DESCRIPTION

The system equations used by the OPTSYSX program for the calculation of the transfer functions are of the state variable form. The system equations are:

system model

$$\dot{x} = [F]*x + [G]*u + [GAM]*w \quad (3.1)$$

measurement equation

$$z = [H]*x + [D]*u + v \quad (3.2)$$

estimator equation

$$\dot{x}_e = [F]*x_e + [G]*u + [K]*(z - [H]*x_e) \quad (3.3)$$

open loop transfer function

$$[H]*[s[I] - [F]]^{-1}*[G] \quad (3.4)$$

closed loop noise transfer function

$$[H]*[s[I] - [F]]^{-1}*[GAM] \quad (3.5)$$

compensator transfer function from measurement to input

$$[C]*([s[I] - [F]] + [G]*[C] + [K]*[H])^{-1}*[K] \quad (3.6)$$

where

u = Control vector (Ns X 1)

w = White process noise vector ($N_g \times 1$)
 x = State vector ($N_s \times 1$)
 \dot{x} = Derivative of the state vector ($N_s \times 1$)
 y = Output vector ($N_o \times 1$)
 z = measurement vector ($N_o \times 1$)
 $[C]$ = control gain matrix (N_c, N_s)
 $[D]$ = control feed-forward distribution matrix (N_c, N_c)
of the control vector (u)
 $[F]$ = open-loop dynamics matrix (N_s, N_s)
(System matrix or Plant matrix)
 $[G]$ = control distribution matrix (N_s, N_c)
 $[GAM]$ = state disturbance distribution matrix (N_s, N_g)
 $[H]$ = measurement distribution matrix (N_o, N_s)
 $[I]$ = identity matrix (N_s, N_s)

D. PROGRAM ORGANIZATION

1. Main Program

The main program presents a menu allowing the user to select for analysis either the open loop transfer function, the closed loop noise transfer function, the compensator transfer function, or exit the OPTGRAPH program. The data file for the selected transfer function is examined by the main program to ensure that the file contains the required transfer function data. Should the data file be incomplete the program gives the user a warning message indicating the nature of the missing data and allows the user to select another option.

The main program menu:

OPTGRAPH

DO YOU DESIRE TO ANALYZE:

1. OPEN LOOP TRANSFER FUNCTION
2. NOISE TRANSFER FUNCTION
3. COMPENSATOR TRANSFER FUNCTION
4. EXIT OPTGRAPH

ENTER OPTION NUMBER.

Data is read from the selected file by the main program and formed into three arrays and seven integer variables. The exchange of data between the main program and the subroutines, and between the subroutines is by the extensive use of labeled common statements. The data transferred through the subroutine call statements is limited primarily to flags, and constants. The program moves to its primary sequencing subroutine (GRAPH) upon the completion of file data entry.

2. Program Sequencing

The subroutine GRAPH first presents the user with a summary of the the transfer system received from the data file. The user is then asked which transfer function he desires to to analyze using the conventions of the OPTSYSX program describing the transfer functions by input number and output number. A menu is presented which allows the user to select graphical and/or tabular system response (Pole-Zero map, Root-locus, Bode, Nyquist, or Nichols), select another transfer function, or exit the OPTGRAPH program. Upon completion of a graphical and/or tabular response option, or change of transfer function option, the program returns to the GRAPH menu to allow the user to choose another option or exit to the main program.

Subroutine GRAPH data summary and menu:

OPTGRAPH

THE OPEN LOOP TRANSFER SYSTEM OBTAINED FROM OPTSYS CONTAINS:

- | | |
|-----------------------|---|
| 1. NUMBER OF STATES = | 4 |
|-----------------------|---|

2. NUMBER OF CCNTROLS (INPUTS) = 1
3. NUMBER OF MEASUREMENTS (OUTPUTS) = 1
4. MARKOV PARAMETER = 10.0**- 6

CLEAR SCREEN TO CONTINUE

OPTGRAPH

AN OPEN LOOP POLE-ZERO, ROOT LOCUS, BODE, NYQUIST, AND/
OR NICHOLS PLOT IS DESIRED FOR:

INPUT # ?

OUTPUT # ?

OPTGRAPH

OPEN LOOP TRANSFER FUNCTION

INPUT # = 1

OUTPUT # = 1

DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR DATA FOR:

1. POLE-ZERO MAP
2. ROOT-LOCUS
3. BODE
4. NYQUIST (POLAR PLOT)
5. NICHOLS
6. ANOTHER INPUT/OUTPUT COMBINATION (SAME TRANSFER
FUNCTION)
7. ANOTHER TYPE TRANSFER FUNCTION /EXIT OPTGRAPH

ENTER OPTICN NUMBER.

3. Graphic and/or Tabular System Response

The selection of a graphical and/or tabular system response option for an Pole-Zero map, Root-Locus, Bode, open loop Nyquist, or open loop Nichols calls the subroutines

PZERO, RTLO, BODE, NYQST, or NICHOL respectively. While the response of these subroutines is different, their organization is similar.

The subroutines PZERO, RTLO, BODE, NYQST, and NICHOL primarily act as sequencing and plot setup subroutines. The interactive questioning of the user for graphic/tabular response information and the system response calculation has been relegated to other subroutines. The subroutines PZERO, RTLO, BODE, NYQST, and NICHOL are divided into two major sections with the first being devoted to producing a graphical output and the second to producing a tabular output.

The user is presented a subroutine menu offering the option for graphic response, tabular response, or exiting the subroutine. The program moves to either the first section (graphic response), second section (tabular response) or back to the subroutine GRAPH menu depending on the option selection. The program returns to the subroutine menu upon completion of either the graphic response, or tabular response section, allowing the user to select another response option, or exit the subroutine.

Features that are common to the five subroutines will be described here and features that are unique to one of the subroutines will be described in the following section under the appropriate response heading.

For a graphic response, the user is given the choice of two printer options (TEK 618, or VERSATEC). With the selection of the TEK 618, the plot page size is defaulted to 11 inches by 8.5 inches, and the plot will be presented on the TEK 618 screen. The VERSATEC option gives the user the option to create up to a 21 inch by 21 inch plot (maximum for the VERSATEC printer) and causes a DISPLA METAFILE to be created. A scaling subroutine (PSCALE) scales the plot heading, legend, etc. in proportion to the page width selected. The VERSATEC option offers the the advantage of a

high quality print from the VERSATEC printer using the VERSATEC printer option in the OPTSYS EXEC. The creation of a DISPLA METAFILE also gives the user (after he exits optsys) the opportunity to use printers other than the TEK 618 or VERSATEC. A major disadvantage with the VERSATEC option is that the user must exit the OPTGRAPH program before he can print a graphic system response. For this reason, it is recommended that the system response first be plotted on the TEK 618 prior to selecting the VERSATEC option.

For a tabular response, the user is presented a menu which gives him the choice of three devices (screen, printer, or disk) to send the tabular output. The user is asked if he desires to make any changes, after the tabular data has been calculated. If the answer is affirmative, he is presented a menu and allowed to make changes and rerun the tabular data routine.

Examples of these features are included in the following sections with the interactive examples for the system responses.

E. INTERACTIVE EXAMPLES

The open-loop, closed loop noise, and compensator transfer functions are handled identically by the OPTGRAPH program, with the only difference being the program and graph headings identifying the transfer function type. The frequency response programs for the Bode, Nyquist, and Nichols responses use identical setup and tabular data routines.

A good overall representation of the OPTGRAPH program capabilities will be demonstrated by single interactive terminal session examples for the pole-zero, root locus, and bode responses using selected transfer functions. Tabular

data examples will be provided for the Pole-Zero, Root Locus, and Bode responses, and graphic response examples will be provided the Pole-Zero, Root Locus, Bode, Nyquist, and Nichols responses.

F. CHARACTERISTIC EQUATION ANALYSIS

The subroutines PZERO and RTLO are similar in their basic formats. The pole and zero locations for the selected transfer function input and output numbers are read into two single dimension arrays. The extraneous zeros, calculated by the OPTSYSX program, are eliminated by comparing the zeros to the Markov parameter sent with the system information from the OPTSYSX program. For a graphical response, the user is asked to define the plot limits in terms of X-coordinates (real axis) and Y-coordinates (imaginary axis). Points for the plot which fall outside these limits will be ignored. System information (transfer function input number, output number, and (DC) gain) is listed in the graph legend.

1. Pole-Zero Map

The subroutine PZERO converts the double precision numbers for pole and zero locations to single precision for compatibility with the Graphics Package and plots the poles and zeros within the plot limits defined by the user for the graphical response routine. For tabular data response the user is given system information (numerator order, denominator order, and transfer function (DC) gain) for the selected transfer function input number and output number, and the pole and zero locations.

2. Pole-Zero Map (Interactive Example)

The following example of a simplified open loop transfer function for an airplane with an autopilot in the longitudinal mode was obtained from [Ref. 7,p.315].

The aircraft system is represented by:

$$[D] = [0]$$

$$[F] = \begin{bmatrix} 0. & 1. & 0. & 0. \\ 0. & 0. & 1. & 0. \\ 0. & 0. & 0. & 1. \\ 0. & 16. & -12. & -3. \end{bmatrix}$$

$$[G] = \begin{bmatrix} 0. \\ 0. \\ 1. \\ -2. \end{bmatrix}$$

$$[GAM] = [0]$$

$$[H] = [1. \quad 0. \quad 0. \quad 0.]$$

a. Example of Graphic Response (Terminal Session)

BEGIN RECORDING OF TERMINAL SESSION

R; T=0.01/0.02 19:40:17

EXECUTION BEGINS...

OPTGRAPH

DO YOU DESIRE TO ANALYZE:

1. OPEN LOOP TRANSFER FUNCTION
2. NOISE TRANSFER FUNCTION
3. COMPENSATOR TRANSFER FUNCTION
4. EXIT OPTGRAPH

ENTER OPTION NUMBER.

1

OPTGRAPH

THE OPEN LOOP TRANSFER SYSTEM OBTAINED FROM OPTSYS
CONTAINS:

1. NUMBER OF STATES = 4
2. NUMBER OF CONTROLS (INPUTS) = 1
3. NUMBER OF MEASUREMENTS (OUTPUTS) = 1
4. MARKOV PARAMETER = 10.0×10^{-6}

CLEAR SCREEN TO CONTINUE

OPTGRAPH

AN OPEN LOOP POLE-ZERO, ROOT LOCUS, BODE, NYQUIST,
AND? OR NICHOLS PLOT IS DESIRED FOR:

INPUT # ?

1

OUTPUT # ?

1

OPTGRAPH

OPEN LOOP TRANSFER FUNCTION

INPUT # = 1

OUTPUT # = 1

DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR
DATA FOR:

1. POLE-ZERO MAP

2. ROOT-LOCUS
3. EODE
4. NYQUIST (POLAR PLOT)
5. NICHOLS
6. ANOTHER INPUT/OUTPUT COMBINATION (SAME
TRANSFER FUNCTION)
7. ANOTHER TYPE TRANSFER FUNCTION /EXIT
CPTGRAPH

ENTER OPTICN NUMBER.

1

POLE-ZERO MAP

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTICN NUMBER.

1

POLE-ZERO MAP

OPEN LOOP TRANSFER FUNCTION

PLOTTER SELECTION AND PAGE SIZE

(NOTE: PAGE IS 11.0 INCHES BY 8.5 INCHES WITH
SELECTION OF TEK618)

WHICH PLOTTER DO YOU DESIRE:

1. TEK618
2. VERSATEC

CHOCSE OPTION 1 OR 2

2

PAGE SIZE (MAXIMUM = 21.0 INCHES BY 21.0
INCHES)

HEIGHT =

6

WIDTH =

8

PLOTTING LIMITS FOR GRAPH

X AXIS (REAL AXIS)

X MINIMUM = ?

-15

X MAXIMUM = ?

5

Y AXIS (IMAGINARY AXIS)

Y MINIMUM = ?

-5

Y MAXIMUM = ?

5

PLOTTING LIMITS FOR GRAPH

X AXIS (REAL AXIS)

X MINIMUM = -15.00

X MAXIMUM = 5.00

Y AXIS (IMAGINARY AXIS)

Y MINIMUM = -5.00

Y MAXIMUM = 5.00

DO YOU DESIRE TO MAKE ANY CHANGES ?

TYPE "YES" OR "NO".

n

PLOT HEADING

HOW MANY LINES OF HEADING DO YOU DESIRE ?

(3MAX)

ENTER NUMBER OF LINES.

(ENTER "0" FOR NO HEADING)

3

A MAXIMUM OF 32 CHARACTERS PER LINE IS
ALLCWED

LINE 1 IS:

aircraft with an autopilot in

LINE 2 IS:
the longitudinal mode

LINE 3 IS:
ref. 7; page 315

PLOT HEADING

LINE 1 : AIRCRAFT WITH AN AUTOPILOT IN
LINE 2 : THE LONGITUDINAL MODE
LINE 3 : REF. 7; PAGE 315

DO YOU DESIRE TO MAKE ANY CHANGES ?

TYPE "YES" OR "NO".

n

>USING A PRE-ALLOCATED DATASET FOR UNIT FT17F001.

>USING A PRE-ALLOCATED DATASET FOR UNIT FT18F001.

A DISSPLA METAFILE HAS BEEN CREATED
CLEAR SCREEN TO CONTINUE

POLE-ZERO MAP

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE TO MAKE ANY CHANGES TO:

1. PLOTTER / PAGE SIZE
2. GRAPH LIMITS
3. HEADING
4. NO ADDITIONAL CHANGES - PLOT POLE-ZERO
MAP
5. NO CHANGES - EXIT POLE-ZERO PLOTTING
ROUTINE

ENTER OPTION NUMBER.

5

POLE-ZERO MAP

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTICN NUMBER.

3

OPTGRAPH

OPEN LOOP TRANSFER FUNCTION

INPUT # = 1

OUTPUT # = 1

DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR
DATA FOR:

1. POLE-ZERO MAP
2. ROOT-LOCUS
3. BODE
4. NYQUIST (POLAR PLOT)
5. NICHOLS
6. ANOTHER INPUT/OUTPUT COMBINATION (SAME
TRANSFER FUNCTION)
7. ANOTHER TYPE TRANSFER FUNCTION /EXIT

CPTGRAPH

ENTER OPTICN NUMBER.

7

OPTGRAPH

DO YOU DESIRE TO ANALYZE:

1. CPEN LOOP TRANSFER FUNCTION
2. NOISE TRANSFER FUNCTION
3. COMPENSATOR TRANSFER FUNCTION
4. EXIT OPTGRAPH

ENTER OPTICN NUMBER.

4

```
R; T=2.80/4.67 19:45:15
record off
END RECORDING OF TERMINAL SESSION
```

The preceding example follows at the end of the chapter as figure 3.1 .

b. Example of Tabular Data (Terminal Session)

The entering and exiting option menus for the tabular data terminal session are identical to the graphic response terminal session option menus, and have been eliminated from the following terminal session.

```
BEGIN RECORDING OF TERMINAL SESSION
```

```
R; T=0.01/0.02 19:51:03
```

```
EXECUTION BEGINS...
```

```
POLE-ZERO MAP
```

```
OPEN LOCF TRANSFER FUNCTION
```

```
DO YOU DESIRE:
```

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

```
ENTER OPTICN NUMBER.
```

```
2
```

```
POLE-ZERO MAP
```

```
OPEN LOCF TRANSFER FUNCTION
```

```
DO YOU DESIRE TABULAR OUTPUT TO GO TO:
```

1. SCREEN
2. PRINTER
3. DISK (OPGRAPH LISTING)

```
ENTER OPTICN NUMBER.
```

```
1
```

POLE-ZERO MAP
 OPEN LOOP TRANSFER FUNCTION
 INPUT NUMBER = 1
 OUTPUT NUMBER = 1
 TRANSFER FUNCTION (DC) GAIN = 0.1000D+01
 DENOMINATOR ORDER = 4

POLE LOCATIONS

REAL PART	IMAGINARY PART
0.0000D+00	0.0000D+00
0.1000D+01	0.0000D+00
-0.2000D+01	0.3464D+01
-0.2000D+01	-0.3464D+01

NUMERATOR ORDER = 1

ZERO LOCATIONS

REAL PART	IMAGINARY PART
-0.1000D+01	0.0000D+00

DO YOU DESIRE TO CHANGE OUTPUT DEVICE?

TYPE "YES" OR "NC".

n

POLE-ZERO MAP
 OPEN LOOP TRANSFER FUNCTION
 DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTION NUMBER.

3

R; T=1.60/3.23 19:53:00

record off

END RECORDING OF TERMINAL SESSION

3. Root-Locus

The subroutine RTLO creates a closed loop system (with negative unity feed-back) from the selected transfer function input numbers and output numbers. Transfer function poles and zeros are formed into two separate polynomials by the subroutine MAKPOL. The numerator polynomial (zeros) is multiplied by the gains, and the two polynomials are added to form a single polynomial. Complex roots of the of the polynomial are calculated by the IMSL library subroutine ZRPCLY. The complex roots are separated into real and imaginary components for either plotting or tabulating.

The plotting routine first plots the transfer function pole and zero locations then plots the root locations as they are received from the subroutine ZRPOLY. For the plotting routine the gain interval specified by the user is divided into 2000 evenly spaced points for the subroutine ZRPOLY to calculate roots. The poles, zeros, and roots are plotted within the plot limits specified by the user.

For the tabular data routine the user is given the option to choose between 1 and 500 points for the subroutine ZRPOLY to calculate roots. The tabular data output provided for the user is system information (numerator order, denominator order, and transfer function (DC) gain) for the selected transfer function input number and output number, the pole and zero locations, and the root locus gains and roots

A positive unity feedback system may be analyzed by specifying a negative gain range vice a positive gain range.

4. Root-Locus (Interactive Example)

The following interactive example is of the open loop transfer function for an aircraft with an autopilot in the longitudinal mode described in Pole-Zero interactive section.

a. Example of Graphic Response (Terminal Session)

BEGIN RECORDING OF TERMINAL SESSION

R; T=0.01/0.02 20:28:37

EXECUTION BEGINS...

OPTGRAPH

DO YOU DESIRE TO ANALYZE:

1. OPEN LOOP TRANSFER FUNCTION
2. NOISE TRANSFER FUNCTION
3. COMPENSATOR TRANSFER FUNCTION
4. EXIT OPTGRAPH

ENTER OPTION NUMBER.

1

OPTGRAPH

THE OPEN LOOP TRANSFER SYSTEM OBTAINED FROM OPTSYS
CONTAINS:

- | | |
|---------------------------------------|---|
| 1. NUMBER OF STATES = | 4 |
| 2. NUMBER OF CONTROLS (INPUTS) = | 1 |
| 3. NUMBER OF MEASUREMENTS (OUTPUTS) = | 1 |
| 4. MARKOV PARAMETER = 10.0**- 6 | |

CLEAR SCREEN TO CONTINUE

OPTGRAPH

AN OPEN LOOP POLE-ZERO, ROOT LOCUS, BODE, NYQUIST,

AND/OR NICHOLS PLOT IS DESIRED FOR:

INPUT # ?

1

OUTPUT # ?

1

OPTGRAPH

OPEN LOCF TRANSFER FUNCTION

INPUT # = 1

CUTPUT # = 1

DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR
DATA FOR:

1. POLE-ZERO MAP
2. ROOT-LOCUS
3. BODE
4. NYQUIST (POLAR PLOT)
5. NICHOLS
6. ANOTHER INPUT/OUTPUT COMBINATION (SAME
TRANSFER FUNCTION)
7. ANOTHER TYPE TRANSFER FUNCTION /EXIT

OPTGRAPH

ENTER OPTION NUMBER.

2

ROOT-LOCUS

OPEN LOCF TRANSFER FUNCTION

DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTION NUMBER.

1

ROOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

PLOTTER SELECTION AND PAGE SIZE

(NOTE: PAGE IS 11.0 INCHES BY 8.5 INCHES WITH
SELECTION OF TEK618)

WHICH PLOTTER DO YOU DESIRE:

1. TEK618

2. VERSATEC

CHOCSE OPTION 1 CR 2

2

PAGE SIZE (MAXIMUM = 21.0 INCHES BY 21.0
INCHES)

HEIGHT =

6

WIDTH =

8

PLOTTING LIMITS FOR GRAPH

X AXIS (REAL AXIS)

X MINIMUM = ?

-15

X MAXIMUM = ?

5

Y AXIS (IMAGINARY AXIS)

Y MINIMUM = ?

-5

Y MAXIMUM = ?

5

PLOTTING LIMITS FOR GRAPH

X AXIS (REAL AXIS)

X MINIMUM = -15.00

X MAXIMUM = 5.00

Y AXIS (IMAGINARY AXIS)

Y MINIMUM = -5.00

Y MAXIMUM = 5.00

DO YOU DESIRE TO MAKE ANY CHANGES ?

TYPE "YES" OR "NC".

n

GAIN RANGE FOR ROOT-LOCUS PLOT

MINIMUM GAIN = ?

0

MAXIMUM GAIN = ?

500

GAIN RANGE FOR ROOT-LOCUS PLOT

MINIMUM GAIN = 0.000D+00

MAXIMUM GAIN = 0.500D+03

DO YOU DESIRE TO MAKE ANY CHANGES ?

TYPE "YES" OR "NC".

n

PLOT HEADING

HOW MANY LINES OF HEADING DO YOU DESIRE ?

(3 MAX)

ENTER NUMBER OF LINES.

(ENTER "0" FOR NO HEADING)

3

A MAXIMUM OF 32 CHARACTERS PER LINE IS
ALLOWED

LINE 1 IS:

aircraft with an autopilot in

LINE 2 IS:

the longitudinal mode

LINE 3 IS:

ref. 7; page 315

PLOT HEADING

LINE 1 : AIRCRAFT WITH AN AUTOPILOT IN
LINE 2 : THE LONGITUDINAL MODE
LINE 3 : REF. 7; PAGE 315

DO YOU DESIRE TO MAKE ANY CHANGES ?

TYPE "YES" OR "NO".

n

>USING A PRE-ALLOCATED DATASET FOR UNIT FT17F001.

>USING A PRE-ALLOCATED DATASET FOR UNIT FT18F001.

A DISPLA METAFILE HAS BEEN CREATED
CLEAR SCREEN TO CONTINUE

ROOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE TO MAKE ANY CHANGES TO:

1. PLOTTER / PAGE SIZE
2. GRAPH LIMITS
3. HEADING
4. GAIN RANGE
5. NO ADDITIONAL CHANGES - PLOT ROOT-LOCUS
6. NO CHANGES - EXIT ROOT-LOCUS PLOTTING

ROUTINE

ENTER OPTION NUMBER.

6

RCOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTION NUMBER.

3

OPTGRAPH

OPEN LOOP TRANSFER FUNCTION

INPUT # = 1

OUTPUT # = 1

DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR
DATA FOR:

1. POLE-ZERO MAP
2. ROOT-LOCUS
3. BODE
4. NYQUIST (POLAR PLOT)
5. NICHOLS
6. ANOTHER INPUT/OUTPUT COMBINATION (SAME
TRANSFER FUNCTION)
7. ANOTHER TYPE TRANSFER FUNCTION /EXIT

OPTGRAPH

ENTER OPTION NUMBER.

7

OPTGRAPH

DO YOU DESIRE TO ANALYZE:

1. OPEN LOOP TRANSFER FUNCTION
2. NOISE TRANSFER FUNCTION
3. COMPENSATOR TRANSFER FUNCTION
4. EXIT OPTGRAPH

ENTER OPTION NUMBER.

4

R; T=12.36/15.14 20:32:54

record off

END RECORDING OF TERMINAL SESSION

The preceding example follows at the end of the chapter as figure 3.2 .

b. Example of tabular data (Terminal Session)

The entering and exiting option menus for the tabular data terminal session are identical to the graphic response terminal session option menus, and have been eliminated from the following terminal session.

BEGIN RECORDING OF TERMINAL SESSION

R; T=0.01/0.02 20:42:59

EXECUTION BEGINS...

ROOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTION NUMBER.

2

ROOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE TABULAR OUTPUT TO GO TO:

1. SCREEN
2. PRINTER
3. DISK (OPGRAPH LISTING)

ENTER OPTION NUMBER.

1

GAIN RANGE FOR ROOT-LOCUS PLOT

MINIMUM GAIN = ?

1

MAXIMUM GAIN = ?

5

GAIN RANGE FOR ROOT-LOCUS PLOT

MINIMUM GAIN = 0.100D+01

MAXIMUM GAIN = 0.500D+01

DO YOU DESIRE TO MAKE ANY CHANGES ?

TYPE "YES" OR "NC".

n

HOW MANY POINTS DO YOU WANT TO TABULATE?

(500 IS THE MAXIMUM)

ENTER NUMBER OF POINTS.

5

ROOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

INPUT NUMBER = 1

OUTPUT NUMBER = 1

TRANSFER FUNCTION (DC) GAIN = 0.1000D+01

OPEN LOOP TF POLES AND ZEROS

DENOMINATOR ORDER = 4

POLE LOCATIONS

REAL PART	IMAGINARY PART
0.0000D+00	0.0000D+00
0.1000D+01	0.0000D+00
-0.2000D+01	0.3464D+01
-0.2000D+01	-0.3464D+01

NUMERATOR ORDER = 1

ZERO LOCATIONS

REAL PART	IMAGINARY PART
-0.1000D+01	0.0000D+00

GAIN = 0.1000D+01

REAL PART	IMAGINARY PART
0.7074D-01	0.0000D+00
0.8962D+00	0.0000D+00
-0.1983D+01	0.3441D+01

-0.1983D+01 -0.3441D+01

GAIN = 0.1800D+01

REAL PART	IMAGINARY PART
0.1453D+00	0.0000D+00
0.7948D+00	0.0000D+00
-0.1970D+01	0.3422D+01
-0.1970D+01	-0.3422D+01

GAIN = 0.2600D+01

REAL PART	IMAGINARY PART
0.2576D+00	0.0000D+00
0.6552D+00	0.0000D+00
-0.1956D+01	0.3402D+01
-0.1956D+01	-0.3402D+01

GAIN = 0.3400D+01

REAL PART	IMAGINARY PART
0.4426D+00	0.1661D+00
0.4426D+00	-0.1661D+00
-0.1943D+01	0.3383D+01
-0.1943D+01	-0.3383D+01

GAIN = 0.4200D+01

REAL PART	IMAGINARY PART
0.4285D+00	0.3096D+00
0.4285D+00	-0.3096D+00
-0.1929D+01	0.3363D+01
-0.1929D+01	-0.3363D+01

DO YOU DESIRE TO MAKE ANY CHANGES ?

TYPE "YES" OR "NO".

Y

ROOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE TO MAKE ANY CHANGES TO:

1. OUTPUT DEVICE

2. GAIN RANGE
3. NUMBER OF POINTS CALCULATED
4. NO ADDITIONAL CHANGES - TABULATE DATA
5. EXIT ROOT-LCCUS TABULAR DATA ROUTINE

ENTER OPTICN NUMBER.

5

ROOT-LOCUS

OPEN LOOP TRANSFER FUNCTION

DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTICN NUMBER.

3

R; T=1.63/3.40 20:44:54

record off

END RECORDING OF TERMINAL SESSION

G. FREQUENCY RESPONSE ANALYSIS

The calculations for the frequency response of the Bode, Nyquist, and Nichols responses are identical. The only difference is in the graphical presentation of the calculated data. The subroutines BODE, NYQST, and NICHOLS call the subroutine FREQ to calculate the transfer function magnitude and phase for the frequency range specified by the user.

The subroutine FREQ eliminates the extraneous zeros by comparing the zeros to the Markov parameter as described in the Characteristic Equation Analysis section. The frequency response magnitude and phase are calculated using double precision complex library functions following the

conventions of the IBM System /360/370/ FORTRAN IV language. The frequency response is calculated by determining the product of successive numerator zeros which have been combined with the frequency and divided by the product of successive denominator poles which also have been combined with the frequency. The magnitude for the complex result of the zeros, poles, and frequency calculations is determined using the FORTRAN double precision library functions for finding the magnitude of a complex argument. The phase of the of the complex result is determined by separating the real and imaginary parts of the complex results, and finding the phase angle using the double precision FORTRAN library function arctangent. The angle is converted from radians to degrees and is corrected for proper quadrant by checking the signs of the real and imaginary parts. The normal range for calculating phase angles by the subroutine is from +540 degrees to -540 degrees. This range is considered adequate for most application, but should these limits be exceeded the plot will jump with a vertical line to either +360 degrees or -360 degrees respectively before continuing with the plot.

For a graphic response the user specified frequency range is divided into 500 equally spaced points (on a logarithmic scale) for which to calculate the magnitude and phase. The user is given the option to select between 1 and 500 points for tabular data.

1. Bode Response

The graphic response section of the subroutine BODE creates two plots. The first plot is the response magnitude in decibels versus the frequency in radians per second. The magnitude from the subroutine FREQ is converted to decibels and plotted with its corresponding frequency. The second plot is of the phase in degrees versus frequency in radians

per second. The phase from the subroutine FREQ is plotted with its corresponding frequency. The frequency for both plots is plotted on a logarithmic scale. The scale range for both is set automatically to include the entire range of data to be plotted by the subroutine MINMAX which scans the data for the maximum and minimum values. System information (transfer function input number, output number, and (DC) gain) is listed in the graph legend.

The magnitude in decibels and the phase in degrees is searched for "0" decibel and 180 degree crossover points to calculate the phase and gain margins.

The tabular response section gives the user the option to select the the number of frequency points to be calculated between 1 and 500 for the frequency range he has specified. For tabular data response the user is given system information (numerator order, denominator order, and transfer function (DC) gain) for the selected transfer function input number and output number, and the frequency (radians per second), magnitude (decibels), phase (degrees), and the real and imaginary frequency response parts.

2. Code Response (Interactive Example)

The following example of compensator transfer function with a filter and regulator was obtained from [Ref. 8, pp. 382 - 384].

The compensated system is represented by:

$$[C] = \begin{bmatrix} -254.1 & -19.57 \end{bmatrix}$$

$$[D] = \begin{bmatrix} 0 \end{bmatrix}$$

$$[F] = \begin{bmatrix} 0. & 1.0 \\ 0. & -4.6 \end{bmatrix}$$

[G] = $\begin{bmatrix} 0. & \\ & 0.787 \end{bmatrix}$

[GAM] = $\begin{bmatrix} 0. & \\ & 0.1 \end{bmatrix}$

[H] = $\begin{bmatrix} 1. & 0. \end{bmatrix}$

[K] = $\begin{bmatrix} 95.4 & \\ & 4561. \end{bmatrix}$

[Q] = $\begin{bmatrix} 10. \end{bmatrix}$

a. Example of Graphic Response (Terminal Session)

BEGIN RECCRDING OF TERMINAL SESSION

R; T=0.01/0.02 18:30:23

graphics

EXECUTION BEGINS...

OPTGRAPH

DO YOU DESIRE TO ANALYZE:

1. OPEN LOOP TRANSFER FUNCTION
2. NOISE TRANSFER FUNCTION
3. COMPENSATOR TRANSFER FUNCTION
4. EXIT OPTGRAPH

ENTER OPTION NUMBER.

3

OPTGRAPH

THE COMPENSATOR TRANSFER SYSTEM OBTAINED FROM
OPTSYS CCNTAINS:

1. NUMBER OF STATES = 2
2. NUMBER OF CONTROLS (INPUTS) = 1
3. NUMBER OF MEASUREMENTS (OUTPUTS) = 1
4. MARKOV PARAMETER = 10.0×10^{-6}

CLEAR SCREEN TO CONTINUE

OPTGRAPH

AN OPEN LOOP POLE-ZERO, ROOT LOCUS, BODE, NYQUIST,
AND/OR NICHOLS PLOT IS DESIRED FOR:

INPUT # ?

1

OUTPUT # ?

1

OPTGRAPH

COMPENSATOR TRANSFER FUNCTION

INPUT # = 1

OUTPUT # = 1

DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR
DATA FOR:

1. POLE-ZERO MAP
2. ROOT-LOCUS
3. BODE
4. NYQUIST (POLAR PLOT)
5. NICHOLS
6. ANOTHER INPUT/OUTPUT COMBINATION (SAME
TRANSFER FUNCTION)
7. ANOTHER TYPE TRANSFER FUNCTION /EXIT

CPTGRAPH

ENTER OPTION NUMBER.

3

BODE PLOT
COMPENSATOR TRANSFER FUNCTION
DO YOU DESIRE:

1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE

ENTER OPTION NUMBER.

1

BODE PLOT
COMPENSATOR TRANSFER FUNCTION
PLOTTER SELECTION AND PAGE SIZE
(NOTE: PAGE IS 11.0 INCHES BY 8.5 INCHES WITH
SELECTION OF TEK618)

WHICH PLOTTER DO YOU DESIRE:

1. TEK618
2. VERSATEC

CHOOSE OPTION 1 OR 2

2

PAGE SIZE (MAXIMUM = 21.0 INCHES BY 21.0
INCHES)

HEIGHT =

5.65

WIDTH =

8.5

PLOTTING LIMITS FOR GRAPH

FREQUENCY RANGE - RADIANS PER SECOND

MINIMUM FREQUENCY = ?

0.1

MAXIMUM FREQUENCY = ?

1000000

PLOTTING LIMITS FOR GRAPH

FREQUENCY RANGE - RADIANS PER SECOND

MINIMUM FREQUENCY = 0.100E+00
MAXIMUM FREQUENCY = 0.100E+07
DO YOU DESIRE TO MAKE ANY CHANGES ?
TYPE "YES" OR "NO".

n

PLOT HEADING
HOW MANY LINES OF HEADING DO YOU DESIRE ?
(3 MAX)
ENTER NUMBER OF LINES.
(ENTER "0" FOR NO HEADING)

2

A MAXIMUM OF 32 CHARACTERS PER LINE IS
ALLOWED
LINE 1 IS:
filter simulation
LINE 2 IS:
ref. 8; pages 332 - 334

PLOT HEADING
LINE 1 : FILTER SIMULATION
LINE 2 : REF. 8; PAGES 332 - 334
DO YOU DESIRE TO MAKE ANY CHANGES ?
TYPE "YES" OR "NO".

n

A DISSPLA METAFILE HAS BEEN CREATED
CLEAR SCREEN TO CONTINUE

GAIN MARGIN AND PHASE MARGIN
PHASE CROSSOVER FREQUENCY IS 75.1184 RAD/SEC;
GAIN MARGIN IS -59.8906 DB
GAIN CROSSOVER FREQUENCY IS ***** RAD/SEC;
PHASE MARGIN IS -89.9480 DEG
CLEAR SCREEN TO CONTINUE

BODE PLOT
COMPENSATOR TRANSFER FUNCTION
DO YOU DESIRE TO MAKE ANY CHANGES TO:
1. PLOTTER / PAGE SIZE
2. GRAPH LIMITS (FREQUENCY RANGE)
3. HEADING
4. NO ADDITIONAL CHANGES - PLOT BODE PLOTS
5. NO CHANGES - EXIT BODE SUBROUTINE
ENTER OPTION NUMBER.
5

BODE PLOT
COMPENSATOR TRANSFER FUNCTION
DO YOU DESIRE:
1. GRAPHICAL OUTPUT
2. TABULAR DATA
3. QUIT SUBROUTINE
ENTER OPTION NUMBER.
3

OPTGRAPH
COMPENSATOR TRANSFER FUNCTION
INPUT # = 1
OUTPUT # = 1
DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR
DATA FOR:
1. POLE-ZERO MAP
2. ROOT-LOCUS
3. BODE
4. NYQUIST (POLAR PLOT)
5. NICHOLS
6. ANOTHER INPUT/OUTPUT COMBINATION (SAME

```
TRANSFER FUNCTION)
7.  ANOTHER TYPE TRANSFER FUNCTION /EXIT
    CPTGRAPH
ENTER OPTION NUMBER.
7
```

```
OPTGRAPH

DO YOU DESIRE TO ANALYZE:
1.  OPEN LOOP TRANSFER FUNCTION
2.  NOISE TRANSFER FUNCTION
3.  COMPENSATOR TRANSFER FUNCTION
4.  EXIT OPTGRAPH
ENTER OPTION NUMBER.
4
R; T=7.01/8.84 18:39:11
record off
END RECORDING OF TERMINAL SESSION
```

The preceding example follows at the end of the chapter as figure 3.3 and figure 3.4 .

b. Example of Tabular Data Listing File

The terminal session for the Bode tabular data response is similar to the Bode graphic response terminal session. Appendix D contains an example of tabular output sent to a disk (OPGRAPH LISTING) for five points between 10 and 100 radians/second.

3. Nyquist Response

The graphic response section of the subroutine NYQST creates a polar plot from the magnitude and phase data received from the subroutine FREQ. The plot is automatically scaled from a minimum radius of one by using the

subroutine MINMAX to determine the maximum phase and magnitude values. The gain / phase margin calculations and the tabular data output are identical to the subroutine BODE.

4. Nyquist Response (Interactive Example)

The following example is of the open loop transfer function for the filter simulation example described in the Bode interactive section.

This example follows at the end of the chapter as figure 3.5 .

5. Nichols Response

The graphic response section of the subroutine NICHCI creates a single rectangular plot of magnitude in decibels versus phase in degrees. The magnitude from the subroutine FREQ is converted to decibels and plotted with the corresponding magnitude. The plot is automatically scaled using the subroutine MINMAX to determine the maximum phase and magnitude values. The gain / phase margin calculations and the tabular data output are identical to the subroutine BODE.

6. Nichols Response (Interactive Example)

The following example is of the open loop transfer function for the filter simulation example described in the Bode interactive section.

This example follows at the end of the chapter as figure 3.6 .

AIRCRAFT WITH AN AUTOPILOT IN
THE LONGITUDINAL MODE

REF. 7; PAGE 315

OPEN LOOP TRANSFER POLE-ZERO MAP

INPUT # = 1
OUTPUT # = 1
DC GAIN = 1.000×10^0




Figure 3.1 Pole-Zero Map Example.

AIRCRAFT WITH AN AUTO PILOT IN
THE LONGITUDINAL MODE
REF. 7; PAGE 315
ROOT-LOCUS PLOT (OPEN LOOP TF)

INPUT # = 1
OUTPUT # = 1
DC GAIN = 1.000×10^0




Figure 3.2 Root Locus Response Example.

FILTER SIMULATION
 REF. 8; PAGES 332 - 334
 COMPENSATOR TF BODE MAGNITUDE

INPUT # = 1
 OUTPUT # = 1
 DC GAIN = -1.135×10^0




Figure 3.3 Bode Response Example (Magnitude).




Figure 3.4 Bode Response Example (Phase).

FILTER SIMULATION
REF. 8; PAGES 332 - 334
OPEN LOOP TRANSFER NYQUIST

INPUT # = 1
OUTPUT # = 1
DC GAIN = 7.870×10^{-1}




Figure 3.5 Nyquist Response Example.

FILTER SIMULATION
 REF. 8; PAGES 332 - 334
 OPEN LOOP TRANSFER NICHOLS

INPUT # = 1
 OUTPUT # = 1
 DC GAIN = $7.870 \cdot 10^{-1}$




Figure 3.6 Nichols Response Example.

IV. CONCLUSIONS AND RECOMMENDATIONS

A. CONCLUSIONS

An evaluation of the computational ability of OPTSYSX and OPTGRAPH, the program was tested using an 82 X 82 matrix, provided by NASA-Edwards, of longitudinal equations for the X-29A experimental forward-swept wing fighter aircraft prototype. The OPTSYSX program array had to be redimensioned and a 2-megabyte virtual machine size was required for a system of this size.

The open loop eigenvalues calculated by the OPTSYSX program compared favorably with the Eigensystem data supplied by NASA-Edwards, but the OPTSYSX program failed in calculating the open loop transfer function zeros. Extraneous zeros (calculated by OPTSYSX) were of the same approximate magnitude as the open loop system zeros. This prevented the identification and elimination of the extraneous zeros by comparison with the Markov parameter. The open loop zero identification was further complicated by not having available open loop transfer function zero information from NASA-Edwards to compare the OPTSYSX results to.

When requested for additional information NASA-Edwards provided a computer tape with a revised 98 X 98 matrix of longitudinal motion equations for the X-29A fighter aircraft. For this revised system, the OPTSYSX program requires a virtual machine size in excess of 2-megabyte. Time constraints have prevented running the OPTSYSX program with the revised system.

The OPTGRAPH program was tested using the OPTSYSX program's open loop Eigenvalue and transfer function output data for the X-29A 82 X 82 system of longitudinal motion

equations. OPTGRAPH provided excellent quality Bode plots for all of the open loop transfer function inputs and outputs and did not exhibit any computational difficulties as indicated by the lack of error messages at the end of the test. While the test results are encouraging as to the ability of the OPTGRAPH program to assist in the analysis of large order systems, the actual computational accuracy of the OPTGRAPH program can not be fully verified until accurate transfer function information can be obtained from the OPTSYSX program.

B. RECCMMENDATIONS

Based on the results of this Thesis the following areas emerged as possible areas for further research and study.

1. Root Finding Routines

The OPTSYSX program has two similar root finding subroutines (HQR and HQR2), to find the transfer function Eigensystem (poles) and zeros. The order of the transfer function numerator is calculated separately in the subroutine ZEROS.

The inclusion of the open loop transfer function eigensystem (pole locations), zero locations, transfer function numerator orders, and transfer function gains, for the revised (98 X 98) longitudinal mode system by NASA-Edwards should simplify the locating the problem in calculating the transfer function zeros.

The open loop system data from NASA-Edwards also included Bode magnitude and phase plots, and gain and phase margin information, which can be used to evaluate more conclusively the OPTGRAPH program's ability to help evaluate a large order system.

2. Program Memory Requirements

The OPTSYSX program requires in excess of 2-megabyte of virtual machine memory when configured for large matrix operations (98 X 98). Virtual machines with this memory capacity are not normally available to a user. The memory usage for matrix storage and manipulation is a possible area for the reduction in program memory requirement size. The OPTSYSX program retains most of its computational arrays in memory. This method simplifies programming but is extremely inefficient in its use of virtual machine memory.

3. Further Modifications

The area of modern digital controls should be further investigated. The computational abilities of the OPTGRAPH program make it readily adaptable, with minor modifications, for assisting in the analysis of transfer functions in the digital domains.

APPENDIX A
OPTSYS EXEC LISTING

```
      &TRACE OFF
*****
*
*           THE OPTSYS EXEC
*
*           CONTROLS THE OPTSYSX, OPTCALC AND OPTPLOT
*
*           TO DETERMINE THE TIME RESPONSE OF A SYSTEM.
*
*           BY H. A. DIEL
*
*           VERSION 1.0   16 JULY 1984
*
*           MODIFIED BY M. H. LAPTAS
*****
CLRSCRN
&BEGTYPE -ENDFOUR

*****

      CUIPUT FROM OPTSYSX WILL COME TO THE SCREEN IF YOU
      WISH DISK FILE
      ENTER  D   ANY OTHER INPUT YIELD SCREEN

*****

-ENDFOUR
&READ VARS &ANS
&IF .&ANS NE .D &GOTO -ONE
FILEDEF 06 DISK OUTPUTX LISTING A1
CLRSCRN
&BEGTYPE -ENDSIX
```

OUTPUT WILL GO TO DISK FILE 'OUTPUTX LISTING A1'

-ENDSIX

CP SLEEP 3 SEC

-ONE

CLRSCRN

CP LINK 0039P 191 251 RR

ACC 251 F

*

* ALLOW THE USE OF AN OLD "OPTMAT DATA A1"

*

RENAME OPTMAT DATA A1 OPTSYS DATA A1

EIF &RC NE 0 &GOTO -FIRST

RENAME OPTSYS DATA A1 OPTMAT DATA A1

FINDSTAK OPTMAT DATA A1 C01 0 LIM002 ALL GROUP1

EREAD VARS &A1 &A2

EIF .&A2 NE .1 &GOTO -START

CLRSCRN

EBEGTYPE -ENDTWO

YOU HAVE A DATA FILE NAMED 'OPTMAT DATA' ON YOUR A
DISK THAT WAS PREVIOUSLY GENERATED BY THE OPTSYS
PROGRAM AND CONTAINS THE F, G, H, GAMMA, A AND B
MATRICES FROM THAT RUN.

IF YOU WOULD LIKE TO USE THESE SAME MATRICES FOR
THIS RUN, THE CPTSYS PROGRAM WILL READ IN THE
DESIRED DATA AT THE APPROPRIATE TIME,

IF YOU TYPE (Y) ES.

ANY OTHER INPUT WILL RESULT IN THAT FILE BEING ERASED!

-ENDTWO

&READ VARS &ANS

&IF .&ANS EQ .Y &GOTO -START

-FIRST

* *

* ERASE THE OLD "CPTMAT DATA A1" DATA FILE *

* PLACE "000 0" IN THE NEW "OPTMAT DATA FILE" *

* TO ACT AS A FLAG FOR OPTSYSX AND OPTCALC *

* *

ERASE OPTMAT DATA A1

&STACK 000 0

FILESTCK OPTMAT DATA A1 F 80 1

-START

CLRSCFN

&BEGTYPE -ENDONE

THE OPTSYS EXEC CONTROLS FOUR PROGRAMS:

- 1 OPTSYSX FCRTRAN (SYSTEM ANALYSIS)
GENERATES OPTMAT AND OPTGRAPH DATA SETS
- RERUN USES OPTMAT
- 2 OPTCALC FCRTRAN (CALCULATE TIME RESPONSE)
GENERATES OPTPLOT DATA SET USES OPTMAT FROM
OPTSYSX
- 3 OPTGRAPH FORTRAN (POLE-ZERO, ROOT-LOCUS, ECDE,

NYQUIST, ETC)

USES OPTGROL -OPTGRNO -OPTGRCM FROM OPTSYSX

4 EXIT

OPTPLOT FORTRAN IS THE FOURTH PROGRAM

USES OPTPLOT DATA SET FROM OPTCALC

THE SIZE OF THE DATA SETS VARY WITH THE SYSTEM
ORDER, AND CAN USE ABOUT 20% OF THE USERS DISK SPACE.
THEREFORE ENSURE THAT SUFFICIENT DISK SPACE IS
AVAILABLE.

IF DATA SET IS ALREADY AVAILABLE YOU MAY RUN ANY
PROGRAM

- ENTER 1 , 2 , 3 , 4 ANY OTHER INPUT
RETURNS TO MENU

-ENDONE

&READ VAES &ANS

&IF .&ANS EQ .1 &GOTO -OPTSYS

&IF .&ANS EQ .2 &GOTO -OPTCALC1

&IF .&ANS EQ .3 &GOTO -OPGRAPH1

&IF .&ANS EQ .4 &EXIT &RC

&GOTO -START

-OPTSYS

FILEDEF 8 DISK OPTPLCT DATA A1 (PERM

FILEDEF 9 DISK OPTMAT DATA A1 (PERM

FILEDEF 10 DISK OPTGRCL DATA A1 (PERM

FILEDEF 01 DISK OPTGRNO DATA A1 (PERM

FILEDEF 04 DISK OPTGRCM DATA A1 (PERM

GLOBAL TXTLIB VFORTLIE IMSLDP NONIMSL

&TYPE LCADING OPTSYS.... GENERAL STATE VARIABLE ANALYSIS

PROGRAM

&TYPE.... OPTMAT DATA A1 INPUT DATA SET ON RERUNS

OPTSYSX

CLRSCN

&TYPE... DATA SETS .. OPTMAT AND .. OPGRAPH CREATED

CP SLEEP 5 SEC


```

&GOTO -START
-OPTCALC1
*****
*
*          CHECK FOR DATA IN THE FILE "OPTMAT DATA "
*          BEFORE LOADING OPTCALC
*
*****
FINDSTAK OPTMAT DATA A1 C01 0 LIM002 ALL GROUP1
&READ VARS &A1 &A2
&IF .&A2 EQ .1 &GOTO -OPTCALC
&TYPE PROPER DATA FILE IS NOT AVAILABLE FOR OPTCALC
CP SLEEP 5 SEC
&GOTO -START
-OPTCALC
&TYPE.....OPTCALC.... TIME RESPONSE PROGRAM
FILEDEF 8 DISK OPTPLCI DATA A1 (PERM
FILEDEF 9 DISK OPTMAT DATA A1 (PERM
GLOBAL TXTLIB VFORTLIE IMSLDP NONIMSL
OPTCALC
&TYPE    .. OPTPLOT DATA A1    CREATED
CP SLEEP 5 SEC
CLRSCRN
&BEGTYPE -ENDNINE

```

```

*****

```

IF YOU ARE DISSATISFIED WITH THE RESULTS
THUS FAR AND WOULD LIKE TO EXIT TO CMS,

-TYPE 'Y' TO EXIT-

(ANY OTHER INPUT TO CONTINUE)

```

*****
-ENDNINE
&READ VARS &ANS
&IF .&ANS EQ .Y &GOTO -START
&TYPE PLOTS NEXT
CP SLEEP 4 SEC
GLOBAL TXTLIB DISLIBVS 92DISLIB 92INTLIB VPORTLIB GRFLIB
      NCNIMSL CMSLIB
FILEDEF 8 DISK OPTPLOT DATA A1 (PERM
FILEDEF 11 DISK LBLANK TMP A3 (RECFM F LRECL 2400 BLKSIZE
      2400 BLKSIZE 2400 XTENT 600
FILEDEF 12 DISK ISSCCMAP MAPDTA * (RECFM F LRECL 400
      BLKSIZE 400
FILEDEF 13 DISK TABLET TMP A3 (RECFM VS LRECL 208 BLKSIZE
      208 XTENT 1000
FILEDEF 14 DISK LBLANK MAPDTA &LBMODE (RECFM VS LRECL 608
      BLKSIZE 608
FILEDEF 17 DISK DISSPIA SYSUT1 A3 (RECFM FB LRECL 2000
      BLCK 2000 XTENT 500
FILEDEF 18 DISK DISSPIA METAFILE A4 (RECFM VBS LRECL 19065
      BLCK 19069
OPTPLOT
&GOTO -META
-OPGRAPH1
*****
*
*          CHECK FOR DATA IN THE OPTGRAPH DATA SETS "
*          BEFORE LOADING OPGRAPH
*
*****
*****
RENAME OPTGROL DATA A1 OPTSYS DATA A1
&IF &RC NE 0 &GOTO -CFTNOISE
RENAME OPTSYS DATA A1 OPTGROL DATA A1

```

```

FINDSTAK OPTGRNO DATA A1 C01 0 LIM002 ALL GROUP1
&READ VARS &A1 &A2 &A3 &A4 &A5
&IF .&A2 NE .0 &GOTO -SIXTEEN
-OPTNCISE
RENAME OPTGRNO DATA A1 OPTSYS DATA A1
&IF &RC NE 0 &GOTO -CPTCOMP
RENAME OPTSYS DATA A1 OPTGRNO DATA A1
FINDSTAK OPTGRNO DATA A1 C01 0 LIM002 ALL GROUP1
&READ VARS &A1 &A2 &A3 &A4 &A5
&IF .&A2 NE .0 &GOTO -SIXTEEN
-OPTCCMP
RENAME OPTGRCM DATA A1 OPTSYS DATA A1
&IF &RC NE 0 &GOTO -NCDATA
RENAME OPTSYS DATA A1 OPTGRCM DATA A1
FINDSTAK OPTGRCM DATA A1 C01 0 LIM002 ALL GROUP1
&READ VARS &A1 &A2 &A3 &A4 &A5
&IF .&A2 NE .0 &GOTO -SIXTEEN
-NODATA
&PRINT PROPER DATA FILE IS NOT AVAILABLE FOR OPGRAPH
CP SLEEP 5 SEC
&GOTO -START
-SIXTEEN
&TYPE ...OPTGRAPH.... CLASSICAL ANALYSIS OF OPTSYS OUTPUT
SET IDRTLS 10
GLOBAL TXTLIB DISLIBVS 92DISLIB 92INTLIB VFORTLIB GRFLIB
      NONIMSL CMSLIB
SET IDRTBLS 10
FILEDEF 01 DISK OPTGRNO DATA A1 (PERM
FILEDEF 02 DISK OPGRAPH LISTING A1
FILEDEF 03 PRINTER (RECFM FA BLKSIZE 133 PERM
FILEDEF 04 DISK OPTGRCM DATA A1 (PERM
FILEDEF 06 TERM (RECFM FA BLKSIZE 133
FILEDEF 05 TERM (RECFM FA BLKSIZE 80
FILEDEF 10 DISK OPTGRCL DATA A1 (PERM
FILEDEF 11 DISK LBLANK TMP A3 (RECFM F LRECL 2400 BLKSIZE

```

```

2400 XTENT 600
FILEDEF 12 DISK ISSCCMAP MAPDTA * (RECFM F LRECL 400
    BLKSIZE 400
FILEDEF 13 DISK TABLET TMP A3 (RECFM VS LRECL 208 BLKSIZE
    208 XTENT 1000
FILEDEF 14 DISK LBLANK MAPDTA &LBMODE (RECFM VS LRECL 608
    BLKSIZE 608
FILEDEF 17 DISK DISSPLA SYSUT1 A3 (RECFM FB LRECL 2000
    BLCK 2000 XTENT 500
FILEDEF 18 DISK DISSPLA METAFILE A4 (RECFM VBS LRECL 19065
    BLCK 19069

```

CPTGRAPH

-META

```

*
*          CHECK FOR FILE "DISSPLA METAFILE A4" ON
*          THE USER'S DISK BEFORE GOING TO DISSPOP
*

```

```

RENAME DISSPLA METAFILE A4 OPTSYS METAFILE A4
&IF &RETCODE NE 0 &GCTO -START
RENAME OPTSYS METAFILE A4 DISSPLA METAFILE A4
-EIGHT
CLRSCRN
&BEGTYPE -ENDTEN

```

DC YOU WANT A VRSTEC PLOTTER SMOOTH COPY OF THE
THE DISSPLA METAFILE THAT YOU JUST CREATED?

(Y OR N)

-ENDTEN
%READ VARS %ANS
%IF .%ANS EQ .Y %GOTO -NINTH
%IF .%ANS EQ .N %GOTO -START
%GOTO -EIGHT
-NINTH
EXEC DISSPOP VRSTEC
CLRSCRN
%BEGTYPE -ENDTWELVE

YOUR GRAPH(S) CAN BE PICKED UP AT THE COMPUTER CENTER.

THE GRAPH(S) WILL BE ADDRESSED TO "POP (USER ID)".

-ENDTWELVE
CP SLEEP 5 SEC
%GOTO -START

APPENDIX B
OPISYSX PROGRAM LISTING

This portion of the thesis contains the OPTSYSX FORTRAN program (88 pages).

72

```

C-----DATA IY/Y',IZ/N'/-----OPT00490
C-----SUPPRESS INDIVIDUAL UNDERFLOW, OVERFLOW, DIVICE CHECK, AND DECIMAL-----OPT00500
C-----CONVERT ERROR MESSAGES; PROVIDE SUMMARY OF ERRORS ONLY.-----OPT00510
C-----OPT00520
C-----OPT00530
C-----OPT00540
C-----CALL ERRSET (207,256,-1,1,1,209)-----OPT00550
C-----CALL ERRSET (215,256,-1,1,1)-----OPT00560
C-----OPT00570
C-----INITIALIZE SAVE FLAGS.-----OPT00580
C-----OPT00590
C-----ISAF=0-----OPT00600
C-----ISAG=0-----OPT00610
C-----ISAH=0-----OPT00620
C-----IGAM=0-----OPT00630
C-----ISAA=0-----OPT00640
C-----ISAB=0-----OPT00650
C-----ISET=0-----OPT00660
C-----CALL FRICMS ('CLRSCRN ')-----SCRNA-----OPT00670
C-----WRITE (5,8E)-----OPT00680
C-----CALL RDINT (IANS)-----OPT00690
C-----IF (IANS.EC.1) GO TO 20-----OPT00700
C-----IF (IANS.EQ.2) GO TO 10-----OPT00710
C-----GO TO 5-----OPT00720
C-----OPT00730
C-----CALL FRICMS ('CLRSCRN ')-----SCRNI-----OPT00740
C-----WRITE (5,8EC)-----OPT00750
C-----CALL RDCHAR (IANS)-----OPT00760
C-----IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 30-----OPT00770
C-----GO TO 40-----OPT00780
C-----WRITE (5,8EC)-----OPT00790
C-----GO TO 20-----OPT00800
C-----CCNTINUE-----OPT00810
C-----IF (IANS.EC.IZ) GO TO 560-----OPT00820
C-----OPT00830
C-----CALL FRICMS ('CLRSCRN ')-----SCRN2-----OPT00840
C-----WRITE (5,9C)-----OPT00850
C-----CALL RDCHAR (IANS)-----OPT00860
C-----IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 60-----OPT00870
C-----GO TO 70-----OPT00880
C-----WRITE (5,8EC)-----OPT00890
C-----GO TO 50-----OPT00900
C-----CCNTINUE-----OPT00910
C-----IF (IANS.EC.IZ) GO TO 560-----OPT00920
C-----OPT00930
C-----CALL FRICMS ('CLRSCRN ')-----ISET-----OPT00940
C-----WRITE (5,91C)-----OPT00950
C-----OPT00960

```


5C	CALL RCCHAR (IANS)	OPT00970
	IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 90	OPT00980
	GO TO 100	OPT00990
	WRITE (5,88C)	OPT01000
	GO TO 80	OPT01010
100	CONTINUE	OPT01020
C	IF (IANS.EC.IY) ISET=1	OPT01030
C	INITIALIZE SYSTEM FLAGS.	OPT01040
C		OPT01050
1C	CONTINUE	OPT01060
	ISET=0	OPT01070
	IQL=0	OPT01080
	IQ=0	OPT01090
	IR=0	OPT01100
	ISS=0	OPT01110
	IM=0	OPT01120
	ITF1=0	OPT01130
	ITF2=0	OPT01140
	ITF3=0	OPT01150
	IFDFW=0	OPT01160
	IF=0	OPT01170
	IDSTAB=0	OPT01180
	IDBUG=0	OPT01190
	IPSD=0	OPT01200
	IYU=0	OPT01210
	INCRM=0	OPT01220
	IREG=0	OPT01230
	NS=0	OPT01240
	NC=0	OPT01250
	NOR=0	OPT01260
	NC=0	OPT01270
	IRDMAT=0	OPT01280
C		OPT01290
	CALL FRTCMS ('CLRSCRN')	OPT01300
	WRITE (5,57C)	OPT01310
	CALL RDINT (IANS)	OPT01320
	ICL=IANS-1	OPT01330
	IF (IOL.EQ.2) GO TO 350	OPT01340
	IF (IOL.EQ.3) GO TO 200	OPT01350
C		OPT01360
	CALL FRTCMS ('CLRSCRN')	OPT01370
110	WRITE (5,58C)	OPT01380
	CALL RCCHAR (IANS)	OPT01390
	IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 120	OPT01400
	GO TO 130	OPT01410
120	WRITE (5,88C)	OPT01420
	GO TO 110	OPT01430
		OPT01440

250	GO TO 260	OPT01930
	WRITE (5,88C)	OPT01940
260	GO TO 240	OPT01950
	CONTINUE	OPT01960
	IF ((IANS.EC.IY) IDSTAB=1	OPT01970
	IF ((IANS.EC.IZ) IDSTAB=0	OPT01980
C	-----	OPT01990
270	WRITE (5,66C)	OPT02000
	CALL RCHAR (IANS)	OPT02010
	IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 280	OPT02020
	GO TO 290	OPT02030
280	WRITE (5,88C)	OPT02040
	GO TO 270	OPT02050
290	CONTINUE	OPT02060
	IF ((IANS.EC.IY) IDEBUG=1	OPT02070
	IF ((IANS.EC.IZ) IDEBUG=0	OPT02080
300	CONTINUE	OPT02090
C	-----	OPT02100
	CALL FRCMS ('CLRSCRN ')	OPT02110
320	WRITE (5,71C)	OPT02120
	CALL RCHAR (IANS)	OPT02130
	IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 320	OPT02140
	GO TO 340	OPT02150
330	WRITE (5,88C)	OPT02160
	GO TO 320	OPT02170
340	CONTINUE	OPT02180
	IF ((IANS.EC.IY) IREG=1	OPT02190
	IF ((IANS.EC.IZ) IREG=0	OPT02200
350	CALL RDMATF(NS,NC,NCB,NG,ISAF,ISAG,ISAH,IGAM,ISAB,IRDMAT)	OPT02210
	IF ((ISAF.EC.1).AND.(IRDMAT.EQ.1)) GO TO 352	OPT02220
C	-----	OPT02230
	CALL FRCMS ('CLRSCRN ')	OPT02240
	WRITE (5,72C)	OPT02250
	CALL RCREAL (ANSR)	OPT02260
	NS=IDINT (ANSR)	OPT02270
352	IF ((IOL.EQ.2) GO TO 360	OPT02280
	IF ((ISAG.EC.1).AND.(IPDMAT.EQ.1)) GO TO 354	OPT02290
C	-----	OPT02300
	WRITE (5,73C)	OPT02310
	CALL RCREAL (ANSR)	OPT02320
	NC=IDINT (ANSR)	OPT02330
354	IF ((ISAH.EC.1).AND.(IRDMAT.EQ.1)) GO TO 356	OPT02340
C	-----	OPT02350
	WRITE (5,740)	OPT02360
	CALL RCREAL (ANSR)	OPT02370
	NOB=IDINT (ANSR)	OPT02380
356	IF ((IGAM.EC.1).AND.(IRDMAT.EQ.1)) GO TO 360	OPT02390
C	-----	OPT02400

```

WRITE (5,75C)
CALL RDRREAL (ANSR)
NG=IDINT (ANSR)
CCNT INUE
IF (IOL.EQ.2) GO TO 364
IF (IOL.EQ.3) GO TC 310
C-----IPSD-----
IF (IREG.NE.C.OR.NC.EQ.0) GO TO 310
CALL FRTCMS ('CLRSCRN ')
WRITE (5,65C)
CALL RDINT (IANS)
IPSD=IANS
IF (IPSD.EQ.3) IPSD=0
IF (IPSD.EQ.0) GO TC 310
C-----IYU-----
CALL FRTCMS ('CLRSCRN ')
WRITE (5,77C)
CALL RDINT (IANS)
IYU=IANS-1
C-----INCRM-----
CALL FRTCMS ('CLRSCRN ')
WRITE (5,82C)
CALL RDRREAL (ANSR)
INORM=IDINT (ANSR)
CONTINUE
310 C-----ITF1-----
CALL FRTCMS ('CLRSCRN ')
WRITE (5,62C)
CALL RDINT (IANS)
ITF1=IANS-1
IF (IOL.EQ.3) GO TC 362
C-----ITF2-----
IF (IREG.NE.1) GO TC 315
CALL FRTCMS ('CLRSCRN ')
WRITE (5,63C)
CALL RDINT (IANS)
ITF2=IANS-1
C-----ITF3-----
IF (IREG.NE.0.OR.(NC.EQ.0.CR.NG.EQ.0)) GO TC 362
CALL FRTCMS ('CLRSCRN ')
WRITE (5,64C)
CALL RDINT (IANS)
ITF3=IANS-1
C-----IF-----
362 CCNT INUE
IF ((ITF1+ITF2+ITF3).EQ.0) GO TO 364
CALL FRTCMS ('CLRSCRN ')
WRITE (5,66C)

```

OPT02410
 OPT02420
 OPT02430
 OPT02440
 OPT02450
 OPT02460
 OPT02470
 OPT02480
 OPT02490
 OPT02500
 OPT02510
 OPT02520
 OPT02530
 OPT02540
 OPT02550
 OPT02560
 OPT02570
 OPT02580
 OPT02590
 OPT02600
 OPT02610
 OPT02620
 OPT02630
 OPT02640
 OPT02650
 OPT02660
 OPT02670
 OPT02680
 OPT02690
 OPT02700
 OPT02710
 OPT02720
 OPT02730
 OPT02740
 OPT02750
 OPT02760
 OPT02770
 OPT02780
 OPT02790
 OPT02800
 OPT02810
 OPT02820
 OPT02830
 OPT02840
 OPT02850
 OPT02860
 OPT02870
 OPT02880

```

CALL RDREAL (ANSR)
IE=IDINT(ANSR)
C-----FLAG SETTINGS-----
364 CONTINUE
CALL FRTCMS ('CLRSCRN ')
WRITE (6,76C)
WRITE (6,77C)
WRITE (6,78C) IOL,IQ,IR,ISS,IM,ITF1,ITF2,ITF3,IFDFW,IE,IDEBUG,ISET
1, IDSTAB
WRITE (6,79C)
WRITE (6,80C) IPSD,IYU,INORM,IREG,NS,NC,NOB,NG
WRITE (6,81C) NS,NC,NOB,NG
C-----CPTGRAPH DATA FILES -----
ZERO = 0
CNE = 1
REWIND 10
ITFX = 1
WRITE (10,1000) ZERO,CNE,NS,NC,NOB,IE,ITFX
REWIND 1
ITFX = 2
WRITE (1,1000) ZERO,CNE,NS,NC,NOB,IE,ITFX
REWIND 4
ITFX = 3
WRITE (4,1000) ZERO,CNE,NS,NC,NOB,IE,ITFX
C-----BEGIN CALCULATIONS-----
N2=2*NS
CALL INNER (NS,NC,NOB,NG,N2,ACL,B,BA,CI,CR,CC,CWI,CWR,D,FBGC,FBGE,
1G,GAM,GM,GN,HC,DI,D2,PRO,RM,RC,Q,SC,WR,WI,W21,X,WNORM,WNORMI,D
2ESTAB,AA,BM,CM,JCF,RES,AY,8B,CC,CP,GW,GV,HY,HU,DSICRE,ISAF,ISAH,IS
3AG,IGAM,IRET,PRIT,NRCW,NCOL,IRDMAT,ISAA,ISAB)
C-----CPTGROL DATA-----
IF((ITF1.EQ.1).OR.(ITF1.EQ.2)) GO TO 396
END FILE 10
REWIND 10
ITFX = 1
WRITE (10,1000) ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO
C-----CPTGRNO DATA-----
396 IF((ITF2.EQ.1).OR.(ITF2.EQ.2)) GO TO 397
END FILE 1
REWIND 1
ITFX = 2
WRITE (1,1000) ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO
C-----CPTGRCM DATA-----
397 IF((ITF3.EQ.3).OR.(ITF3.EQ.2)) GO TO 398
END FILE 4
REWIND 4
ITFX = 3
WRITE (4,1000) ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO,ZERO
OPT02890
OPT02900
OPT02910
OPT02920
OPT02930
OPT02940
OPT02950
OPT02960
OPT02970
OPT02980
OPT02990
OPT03000
OPT03010
OPT03020
OPT03030
OPT03040
OPT03050
OPT03060
OPT03070
OPT03080
OPT03090
OPT03100
OPT03110
OPT03120
OPT03130
OPT03140
OPT03150
OPT03160
OPT03170
OPT03180
OPT03190
OPT03200
OPT03210
OPT03220
OPT03230
OPT03240
OPT03250
OPT03260
OPT03270
OPT03280
OPT03290
OPT03300
OPT03310
OPT03320
OPT03330
OPT03340
OPT03350
OPT03360

```

```

C-----OPT03370
358 IF(IRET.EQ.1) GO TO 370
CALL WRTMAT(BA,G,HO,CAM,FBGC,FBGE,AY,B,NS,NC,NOB,NG)
C-----OPT03380
OPT03390
OPT03400
OPT03410
OPT03420
OPT03430
OPT03440
OPT03450
OPT03460
OPT03470
C-----RESET OPGRAPH DATA FILE
IF(IANS.EQ.1Z) GO TO 395
END FILE 10
REWIND 10
END FILE 1
REWIND 1
END FILE 4
REWIND 4
C-----OPT03480
OPT03490
OPT03500
OPT03510
OPT03520
OPT03530
OPT03540
OPT03550
OPT03560
OPT03570
OPT03580
OPT03590
C-----ISAF
CCNTINUE
IF(IRET.EQ.1) GO TO 400
IF(ISET.EQ.1) GO TO 400
CALL FRTCMS('CLRSCRN')
WRITE(5,840)
CALL RCCHAR(IANS)
IF(IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 420
GO TO 430
WRITE(5,88C)
GO TO 410
CCNTINUE
IF(IANS.EQ.IY) ISAF=1
IF(IANS.EQ.IZ) ISAF=0
C-----ISAH
IF(NOB.EQ.C) GO TO 470
CALL FRTCMS('CLRSCRN')
WRITE(5,88C)
CALL RCCHAR(IANS)
IF(IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 450
GO TO 460
WRITE(5,88C)
GO TO 440
CCNTINUE
IF(IANS.EQ.IY) ISAH=1
IF(IANS.EQ.IZ) ISAH=0
OPT03600
OPT03610
OPT03620
OPT03630
OPT03640
OPT03650
OPT03660
OPT03670
OPT03680
OPT03690
OPT03700
OPT03710
OPT03720
OPT03730
OPT03740
OPT03750
OPT03760
OPT03770
OPT03780
OPT03790
OPT03800
OPT03810
OPT03820
OPT03830
OPT03840

```

470	CCNT INUE	ISAG	OPT03850
	IF (NG.EQ.C) GO TO 510		OPT03860
480	CALL FRTCMS ('CLRSCRN ')		OPT03870
	WRITE (5,88C)		OPT03880
	CALL RDCHAR (IANS)		OPT03890
490	IF ((IANS.NE.IV).AND.(IANS.NE.IZ)) GO TO 490		OPT03900
	GO TO 500		OPT03910
	WRITE (5,88C)		OPT03920
500	GO TO 480		OPT03930
	CCNT INUE		OPT03940
	IF (IANS.EC.IV) ISAG=1		OPT03950
	IF (IANS.EC.IZ) ISAG=0		OPT03960
510	CONT INUE	IGAM	OPT03970
	IF (NG.EQ.C) GO TO 550		OPT03980
	CALL FRTCMS ('CLRSCRN ')		OPT03990
520	WRITE (5,87C)		OPT04000
	CALL RDCHAR (IANS)		OPT04010
	IF ((IANS.NE.IV).AND.(IANS.NE.IZ)) GO TO 530		OPT04020
530	GO TO 540		OPT04030
	WRITE (5,88C)		OPT04040
540	GO TO 520		OPT04050
	CONT INUE		OPT04060
	IF (IANS.EC.IV) IGAM=1		OPT04070
	IF (IANS.EC.IZ) IGAM=0		OPT04080
550	CONT INUE	ISAA	OPT04090
	CALL FRTCMS ('CLRSCRN ')		OPT04100
551	WRITE (5,872)		OPT04110
	CALL RDCHAR (IANS)		OPT04120
	IF ((IANS.EC.IV).OR.(IANS.EQ.IZ)) GO TO 553		OPT04130
553	WRITE (5,88C)		OPT04140
	GO TO 551		OPT04150
	CONT INUE		OPT04160
	IF (IANS.EC.IV) ISAA=1		OPT04170
	IF (IANS.EC.IZ) ISAA=0		OPT04180
	CONT INUE	ISAB	OPT04190
555	CALL FRTCMS ('CLRSCRN ')		OPT04200
	WRITE (5,874)		OPT04210
	CALL RDCHAR (IANS)		OPT04220
	IF ((IANS.EC.IV).OR.(IANS.EQ.IZ)) GO TO 557		OPT04230
557	WRITE (5,88C)		OPT04240
	GO TO 555		OPT04250
	CONT INUE		OPT04260
	IF (IANS.EC.IV) ISAB=1		OPT04270
	IF (IANS.EC.IZ) ISAB=0		OPT04280
	GO TO 10		OPT04290
			OPT04300
			OPT04310
			OPT04320

```

C-----WRITE (5,92C)-----TERMINATE-----OPT04320
560STOPOPT04340
C-----FORMAT (5X,22HIN CASE OF PROBLEMS CALL EXT 2826,/,/,10X,42H1 DEFIOPT04370
8851NES MATRIX EQUATIONS USED IN OPTSYS,/,15X,32HAND ALTERNATE DATA INOPT04380
2PUT METHOD,/,/,10X,26H2 START INTERACTIVE INPUT,/,/,15X,13HENTER OPT04390
31OR 2,/,/,5X,59HNormally two successive null enters terminates OPT04400
4HE PROGRAM.)OPT04410
FORMAT (5X,22HSHOPTSYSX IS A COMPLETELY INTERACTIVE OPTIMAL SYSTEMS OPT04420
1CCONTROL,/,8X,55HPROGRAM. IT WILL SOLVE NUMEROUS CONTROL PROBLEMS OPT04430
2N THE,/,8X,55HCLCING TYPES OF SYSTEMS CONTROL EQUATIONS: OPT04440
3,35HXDOF = F&X + G&X + GAM&*(W+W0),/,20X,22HMEASUREMENT PERFORMANCE OPT04450
4TION--/,/,15X,21H2 = H&X + D&X*U + V,/,20X,22HREGULATOR OPT04460
5ANCE INDEX--/,/,15X,42H2 = 1/2*INTEGRAL (Y9*AE*Y + U9*BE*U)DT,OPT04470
6/,20X,32HSTATE FEEDBACK GAIN DEF? TYPE "YES" CR "NO",/,25X,1CHU = - C&X,/,OPT04480
7,15X,45HDO YOU WISH TO ENTRY? TYPE "YES" CR "NO",/,OPT04490
FORMAT (25X,14H--DATA ENTRY--/,5X,49HALTHOUGH OPTSYSX IS SPECIFICIOPT04500
1CALLY DESIGNED TO READ,/,5X,48HALL MATRIX DATA INTERACTIVELY, SEVEOPT04510
2THAL ALTERNATE,/,5X,31HMETHODS ARE AVAILABLE TO USERS: OPT04520
3METHOD 1--THE "F", "G", AND "GAMMA" MATRICES,/,13X,37HMA BE REAC FROMOPT04530
4M SEPARATE DATA FILES,/,10X,50HMETHOD 2--THE "F", "G", AND "GAMMA" OPT04540
5" MATRICES MAY BE,/,13X,45HEXPLICITLY DEFINED WITHIN SUBROUTINE "SOPT04550
6TUP",/,17X,34HCF THE NOTE: IN EITHER CASE, THE USER SHOULD OBTAIN A COPT04560
8LES CONTAINED IN S/R "SETUP".6,/,10X,45HDC YOU WISH TO CONTINUE? OPT04570
9TYPE "YES" OR "NO",/,OPT04580
FORMAT (/,5X,46HDO YOU WISH TO INPUT THE "F", "G", AND "GAMMA",/,OPT04590
110X,40HMATRICES FROM SUBROUTINE "SETUP" IAW THE,/,1CX,40HMETHODCOPT04600
2SCRIBED ON THE PREVIOUS SCREEN?,/,15X,19HTYPE "YES" OR "NO",/,OPT04610
3FORMAT (25X,24HWITHOUT 2 -- SYSTEM ANALYSIS WITH CPEN--LOCP OPT04620
1EM ANALYSIS WITHIN 2 -- SYSTEM ANALYSIS WITH CPEN--LOCP OPT04630
2/,10X,42HOPTIONS,/,10X,39HOPTIONS,/,22X,25HEIGENOPT04640
3SYSTEM CALCULATIONS,/,10X,39HOPTIONS,/,22X,25HEIGENOPT04650
4SOUND,/,22X,23HANDY,/,10X,48HOPTIONS,/,22X,25HEIGENOPT04660
5CULOWS IMMEDIATELY,/,22X,37HWITHOUT FILTER OR REGULATOR OPT04670
6ICES COMPUTED,/,22X,37HWITHOUT FILTER OR REGULATOR OPT04680
7,25HOR STEADY-STATE ANALYSIS,/,15X,30HSELECT AN OPTION: 1,2,3, OPT04690
8FORMAT (/,5X,46HDO YOU DESIRE RMS VALUES OF STATE AND CONTRLOPT04700
1,10X,19HTYPE "YES" OR "NO",/,OPT04710
1,10X,19HTYPE "YES" OR "NO",/,OPT04720
1FORMAT (/,20X,30HCPISYSX LQR/CLASSICAL OPTICNS: OPT04730
1-- OPTIMAL R "K",/,22X,13HMATRIX INPUT,/,10X,43HOPTION 2 -- OPT04740
2ERNAL FILTER AND/OR REGULATOR,/,22X,27HSYNTHESIS WITH EXTERNA OPT04750
3MAL FILTER AND/OR REGULATOR,/,22X,27HSYNTHESIS WITH EXTERNA OPT04760
422X,13HMATRIX INPUT,/,10X,43HOPTION 3 -- OPTIMAL FILTER AND/OR OPT04770
5REGULATOR,/,22X,27HSYNTHESIS WITH EXTERNA OPT04780
6UT,/,10X,43HOPTION 4 -- SYSTEM ANALYSIS,/,22X,13HMATRIX INP OPT04800

```



```

CALL FRTCMS ('FILEDEF', '03', 'DISK', 'X29A82', '
1 DATA 'A
-----
THIS IS AN EXAMPLE OF A 83 X 84 DATA FILE X29A82 DATA A1 READ FROM
A USER'S DISK AND CONVERTED (FROM A "DUMMY" ARRAY NAMED 'DUM') TO A
SYMMETRIC ARRAY. THE FCRMAT STATEMENT MUST MATCH YOUR DISK DATA
FCRMAT OR THE PROGRAM WILL FAIL. NOTE: ALL PROGRAM DIMENSIONS
MUST BE ENLARGED ACCORDINGLY FOR A SYSTEM OF THIS SIZE.
-----
READ (3,100)
READ (3,100)
DO 20 I=1,NS
READ (3,50) (BA(I,J),J=1,NS)
CONTINUE
20
-----
THESE ARE EXAMPLES OF SEVERAL POSSIBLE METHODS OF ARRAY GENERATION
WITHIN SUBROUTINE SETUP. THE "GAM" ARRAY WAS SET TO ZERO SINCE NO
"NOISE" WAS PRESENT, AND THE NON-ZERO ELEMENTS OF THE "G" ARRAY WERE
EXPLICITLY DEFINED. THEY COULD ALSO BE READ FROM FILES AS ABOVE.
-----
DO 40 I=1,NS
DO 30 J=1,NC
GAM(I,J)=0.0D+00
G(I,J)=0.0D+00
CONTINUE
G(82,1)= 0.1000D+00
G(52,1)= 0.362D+07
G(77,1)= 0.1591D+02
G(78,1)= 0.2448D+00
G(79,1)= 0.2448D+00
G(81,1)= 0.1000D+00
-----
READ (3,100)
DO 70 I=1,NS
READ (3,50) (G(I,J),J=1,NC)
CONTINUE
70
-----
THIS IS AN EXAMPLE OF ONE POSSIBLE METHOD OF ARRAY GENERATION
WITHIN THE PROGRAM ITSELF. FOR VERY LARGE DATA ARRAYS, THIS METHOD
MAY BE PREFERABLE TO SOME USERS OVER INTERACTIVE ENTRY OF EACH
INDIVIDUAL ELEMENT.
-----
DO 2 I=1,11
DO 1 J=1,82
HO(I,J) = 0.0D+00
HO(1,1) = 0.11520D+00
HO(2,75) = 0.5730D+02

```

```

C-----HO(3,74) = C.1000D+01OPT06730
C-----HO(4,63) = C.5730D+02OPT06740
C-----HO(5,62) = C.1000D+01OPT06750
C-----HO(6,76) = C.5730D+02OPT06760
C-----HO(7,44) = C.5730D+02OPT06770
C-----HO(8,45) = C.5730D+02OPT06780
C-----HO(9,46) = C.5730D+02OPT06790
C-----HO(10,47) = C.5730D+02OPT06800
C-----HO(11,48) = C.5730D+02OPT06810
C1-----CONTINUEOPT06820
C2-----CONTINUEGC TO 90OPT06830
C3-----CONTINUEOPT06840
C-----READ(3,100)OPT06850
C-----DC 90 I=1,NCOPT06860
C-----READ(3,50) (HO(I,J),J=1,NS)OPT06870
C-----CONTINUEOPT06880
C-----RETURNOPT06890
C-----OPT06900
C-----FORMAT(5E12,4)OPT06910
C-----FORMAT(3(E12,15,3X))OPT06920
C-----ENDOPT06930
C-----SUBROUTINE CHECK(EPS,NC,NG,NO,IRET)OPT06940
C-----CHECKS THE CONSISTENCY OF REQUESTED OPTIONS.OPT06950
C=====OPT06960
C-----DOUBLE PRECISION EPSOPT06970
C-----COMMON /PREC/ IOL,IQ,IR,ISS,IM,ITF1,ITF2,ITF3,IFDFW,IE,IDSTAE,IDEROPT06980
C-----IUG,ISSET,IREQ,IPSD,IYU,INORMOPT06990
C-----SET MODAL ANALYSIS WHEN OL EIGENSYS OR CL TF REQUESTEDOPT07000
C-----IF (IM.EQ.1 .AND. IOL.EQ.0) IOL=1OPT07010
C-----IF (IOL.EQ.3 .OR. ITF1.NE.0) IM=1OPT07020
C-----CHECK TO SEE IF H MATRIX INPUTOPT07030
C-----IF (NO.NE.0 .OR. ICL.GE.2) GO TO 10OPT07040
C-----WRITE(5,9C)OPT07050
C-----IRET=1OPT07060
C-----RETURNOPT07070
C-----CONTINUEOPT07080
C-----TRANSFER FUNCTION CHECKS-----OPT07090
C-----IF (IE.EQ.0) IE=6OPT07100
C-----EPS=10.*(-IE)OPT07110
C-----OPT07120
C-----OPT07130
C-----OPT07140
C-----OPT07150
C-----OPT07160
C-----OPT07170
C-----OPT07180
C-----OPT07190
C-----OPT07200

```

```

C-----COMPENSATOR TF-----OPT07210
2C  IF (ITF3.EC. 0) GO TO 30 OPT07220
    IF (IREG.EC. 0.AND. (NC.NE. 0.AND. NG.NE. 0)) GO TC 30 OPT07230
    WRITE(5,11C) OPT07240
    RETURN OPT07250
    CONTINUE OPT07260
3C  NCISE TF-----OPT07270
    IF (ITF2.EC. 0) GO TO 40 OPT07280
    IF (NG.NE. 0.AND. NC.NE. 0) GO TO 40 OPT07290
    WRITE(5,12C) OPT07300
    RETURN OPT07310
    CONTINUE OPT07320
C-----DESTABILIZATION RESTRICTIONS-----OPT07330
4C  IF (IDSTAB.EC. 0) GO TO 50 OPT07340
    IF (NC.EC. 0) GO TC 50 OPT07350
    IF (NG.NE. 0) IREG=1 OPT07360
    WRITE(5,13C) OPT07370
    IF (IREG.EC. 1) GO TO 50 OPT07380
    RETURN OPT07390
    CONTINUE OPT07400
5C  PSD INPUT-----OPT07410
    IF (IPSD.EC. 0) GO TO 80 OPT07420
    IF (IPSD.LT. 0.OR. IPSD.GT. 3) GO TO 60 OPT07430
    IF (IYU.LT. 0.OR. IYU.GT. 3) GO TO 60 OPT07440
    IF (INORM.LT. 0.OR. INORM.GT. NG+MD) GO TC 60 OPT07450
    GO TO 70 OPT07460
    WRITE(5,14C) OPT07470
    IRET=1 OPT07480
    RETURN OPT07490
7C  IF (IREG.EC. 0.AND. NC.NE. 0) GO TO 80 OPT07500
    WRITE(5,15C) OPT07510
    RETURN OPT07520
    CONTINUE OPT07530
    RETURN OPT07540
8C  OPT07550
    CONTINUE OPT07560
    RETURN OPT07570
C-----MATRIX MUST BE INPUT, I.E. "NC" MUST BE > 0.-----OPT07580
9C  FORMAT (//,EX,49H H - MATRIX MUST BE INPUT, I.E. "NC" MUST BE > 0. OPT07590
    1,/) OPT07600
10C  FORMAT (//,EX,46H(G) MATRIX MUST BE INPUT, I.E. NC MUST BE > 0.,/, OPT07610
    110X,26HTD CCMPUTE OPEN LOOP TO F.,/) OPT07620
110  FORMAT (//,EX,48HREGULATOR AND FILTER SYNTHESIS MUST BE REQUESTED, OPT07630
    1/,5X,44HIN THE SAME RUN TO COMPUTE COMPENSATOR T. F.,/,5X,47H I.E. OPT07640
    2IPEG MUST = 0.;"NC" AND "NG" MUST BE > 0.,/) OPT07650
120  FOPMAT (//,EX,51HNCISE T. F. CALCULATED ONLY WHEN REGULATOR DESIGN OPT07660
    1ED,/,5X,47H I.E. IREG MUST = 1.;"NC" AND "NG" MUST BE > 0.,/) OPT07670
130  FOPMAT (//,EX,47HDESTABILIZATION OPTION DESIGNED FOR A REGULATOR, OPT07680
    1,/)

```



```

1C      CALL RCREAL (ANSR)
2C      CSTAB=ANSR
3C      DO 10 I=1,NS
4C      DESTAB(I)=CSTAB
5C      CCNTINUE
6C      GO TO 30
7C      CALL SETUP (BA,G,GAM,HO,NS,NC,NG,NO)
8C      CCNTINUE
9C      WRITE (6,1350)
10C      DO 40 I=1,NS
11C      WRITE (6,1350) (BA(I,J),J=1,NS)
12C      IF (IDSTAB.EQ.0) GO TO 50
13C      WRITE (6,1450)
14C      WRITE (6,1350) (DESTAB(I),I=1,NS)
15C      CCNTINUE
16C      -----EIGENSYSTEM OF THE OPEN LOOP DYNAMICS-----
17C      IF (IOL.EQ.0) GO TO 90
18C      IF (IOL.EQ.0) GO TO 90
19C      DO 60 I=1,NS
20C      DO 60 J=1,NS
21C      GN(I,J)=BAL(I,J)
22C      CALL BALANC (NS,NS,GN,LOW,HIGH,D1)
23C      CALL ORTHES (NS,NS,LCW,HIGH,GN,D2)
24C      CALL ORTRAN (NS,NS,LCW,HIGH,GN,D2,SC)
25C      CALL HQP2 (NS,NS,LOW,HIGH,GN,CWR,SC,IERR)
26C      IF (IERR.NE.0) CALL EEXIT (NS,GN,SC,IERR)
27C      CALL BALBAK (NS,NS,LCW,HIGH,D1,NS,SC)
28C      -----NORMALIZE AND PRINT OPEN LOOP EIGENSYSTEM-----
29C      IWRITE=1
30C      CALL CNORM (CWR,CWI,SC,NS,IWRITE,NSQ,DD,D1,D2,WNORM,WNCRMI,FC,CM,
31C      1NO,NS)
32C      -----CPTGRCL/CPTGRNO DATA-----
33C      DO 64 I = 1,NS
34C      WRITE (1,2000) CWR(I), CWI(I)
35C      WRITE (1,2000) CWR(I), CWI(I)
36C      CCNTINUE
37C      -----
38C      IF (IOL.EQ.2) RETURN
39C      IF (IOL.EQ.0) OR (NC.NE.0) OR (IDSTAB.GT.0) GO TO 50
40C      DO 70 I=1,NS
41C      IF (CWR(I).LT.0.) GO TO 70
42C      WRITE (5,1450)
43C      RETURN
44C      CCNTINUE
45C      GO TO 130
46C      DO 50 I=1,NS
47C      DO 80 J=1,NS
48C      W1(I,J)=SC(I,J)

```

```

OPT08170
OPT08180
OPT08190
OPT08200
OPT08210
OPT08220
OPT08230
OPT08240
OPT08250
OPT08260
OPT08270
OPT08280
OPT08290
OPT08300
OPT08310
OPT08320
OPT08330
OPT08340
OPT08350
OPT08360
OPT08370
OPT08380
OPT08390
OPT08400
OPT08410
OPT08420
OPT08430
OPT08440
OPT08450
OPT08460
OPT08470
OPT08480
OPT08490
OPT08500
OPT08510
OPT08520
OPT08530
OPT08540
OPT08550
OPT08560
OPT08570
OPT08580
OPT08590
OPT08600
OPT08610
OPT08620
OPT08630
OPT08640

```



```

          CALL MINV (NSQ,W11,NS,DDD,D1,D2)
          CCNT INUE
          IF (IDSTAB.EQ.0) GO TO 130
          FORM U * DIAG(DESTAB) * U-INV-----
100      DO 100 J=1,NS
          DO 100 I=1,NS
          AA(I,J)=WNCFM(I,J)*DESTAB(J)
          CC 120 I=1,NS
          DO 120 J=1,NS
          CDD=0.0
          DO 110 K=1,NS
          CDD=DDC+AA(I,K)*WNORMI(K,J)
          DSTORE(I,J)=DDD
          BA(I,J)=BA(I,J)+DDD
120      CCNT INUE
          IF (NO.EQ.0) GO TO 145
          IF (ISET.EC.1) GO TO 135
          CALL READH (NO,NS,ISAH,HD)
          CCNT INUE
          WRITE (6,1440)
          DO 140 I=1,NC
          WRITE (6,1450) (HD(I,J),J=1,NS)
          IF (IM.NE.1) GO TO 150
          CALL IMODE (WNORM,HO,CM,NS,NO,NS,2)
150      CCNT INUE
          IF (IFCFW.EC.0) GO TO 170
          CALL READD (NO,NC,D)
          WRITE (6,1470)
          DO 160 I=1,NC
          WRITE (6,1480) (D(I,J),J=1,NC)
          CCNT INUE
          NOB=0
          IF (INC.EQ.0) GO TO 550
          IF (IOL.EC.2) GO TO 270
          IF (IR.NE.1.AND.0IR.NE.3) GO TO 210
          IF (ISET.EC.1) GO TO 180
          CALL READG (NS,NC,ISAG,G)
          CCNT INUE
          CALL READFB (NC,NS,FBGC)
          WRITE (6,1400)
          DO 190 I=1,NS
          WRITE (6,1490) (G(I,J),J=1,NC)
          IF (IM.NE.1) GO TO 200
          CALL IMODE (WNORMI,G,BM,NS,NS,NC,0)
          CCNT INUE
          GO TO 330
          DO 220 I=1,NS
          DO 220 J=1,NS

```

```

OPT08650
OPT08660
OPT08670
OPT08680
OPT08690
OPT08700
OPT08710
OPT08720
OPT08730
OPT08740
OPT08750
OPT08760
OPT08770
OPT08780
OPT08790
OPT08800
OPT08810
OPT08820
OPT08830
OPT08840
OPT08850
OPT08860
OPT08870
OPT08880
OPT08890
OPT08900
OPT08910
OPT08920
OPT08930
OPT08940
OPT08950
OPT08960
OPT08970
OPT08980
OPT08990
OPT09000
OPT09010
OPT09020
OPT09030
OPT09040
OPT09050
OPT09060
OPT09070
OPT09080
OPT09090
OPT09100
OPT09110
OPT09120

```



```

WRITE (6,1570)
CALL RAPRT (NS,NS,NS,9,SC,4,'(9(1X,1PD13.6))')
CCNT INUE
450 C-----RESET FLAG AND F MATRIX FOR ITERATIVE DESTABILIZATION CASE-----
      IF (IDSTAB.EQ.0) GC TO 470
      CC 460 I=1,NS
      BA(I,1)=BA(I,1)-DESTAB(I)
      IP=1
460 C-----CALCULATION OF FEEDBACK GAIN-----
      CCNT INUE
      U = -(BINVERSE)*GT*GNE
      FEEDBACK GAINS-----
      CALCULATE GT-----
      DO 490 I=1,NC
      CC 490 J=1,NS
      PRO(I,J)=0.CO
      DO 480 K=1,MH
      PRO(I,J)=PRO(I,J)+C(K,I)*GN(K,J)
480 C-----NORMALIZE AND PRINT OPT. REG. CLOSED LOOP EIGENSYSTEM-----
490 C-----
      IF (IDSTAB.EQ.1) GC TO 500
      IWRITE=2
      CALL CNORM (CWR,CWI,SC,NS,IWRITE,NSQ,DDD,D1,D2,WNORM,WNCRMI,FBGC,
      1AA,NC,NS)
      THE OPTIMUM FEEDBACK CONTROL GAINS-----
500 C-----
      WRITE (6,1580)
      DO 510 I=1,NC
510 C-----
      WRITE (6,1590) (FBGC(I,J),J=1,NS)
      COMPUTE MICAL C MATRIX OPEN LOOP U-INVERSE SAVED IN WNORMIS-----
      IF (IM.NE.1) GO TO 530
      IN COMPUTING MICAL C RECCMPUTE U OPEN LOOP SINCE WNORM USED TO STCRE
      U & U-INV FOR CLOSED LOOP SYSTEMS; WNCRMI USED TO SAVE U-INV OPEN LOOP
      DO 520 I=1,NS
      CC 520 J=1,NS
      WNCRMI(I,J)=WNORM(I,J)
520 C-----
      CALL MINV (NSQ,WNORM,NS,DDD,D1,D2)
      CALL MCDE (WNORM,FBGC,AA,NS,NC,NS,3)
      CCNT INUE
      THE CLOSED LOOP DYNAMICS MATRIX-----
530 C-----
      DO 550 I=1,NS
      CC 550 J=1,NS
      SUM=0.DO
      DO 540 K=1,NC
      SUM=SUM+G(I,K)*FBGC(K,J)
540 C-----
      ACL(I,J)=BA(I,J)+SUM
      WRITE (6,1600)
      CALL RAPRT (MH,MH,MH,5,ACL,4,'(5(1X,1PD13.6))')

```

```

560 IF (IR.NE.1.AND.IR.NE.3) GO TO 590
DO 560 I=1,NS
DO 560 J=1,NS
GN(I,J)=ACL(I,J)
CALL BALANC (NS,NS,GN,LOW,IHIGH,D1)
CALL ORTRAN (NS,NS,LCW,IHIGH,GN,D2,SC)
CALL HQR2 (NS,NS,LOW,IHIGH,GN,CWR,CW,SC,IERR)
IF (IERR.NE.0) CALL IEREXIT (NS,GN,IERR)
CALL BALBAK (NS,NS,LOW,IHIGH,D1,NS,SC)
C-----NORMALIZE AND PRINT CLOSED LOOP SUBOPT. REG. EIGENSYSTEM-----
IWRITE=3
IWRITE (CWR,CW,SC,NS,IWRITE,NSQ,DDD,D1,D2,WNORM,WNCRMI,FEGC,
1AA,NC,NS)
DO 570 I=1,NS
IF (CWR(I).LT.0.0) GC TO 570
WRITE (5,1410)
RETURN
570 CCNT INUE
IF (IO.NE.1) GO TO 590
DO 580 I=1,NS
DO 580 J=1,NS
W1(I,J)=S(I,J)
CALL MINV (NSQ,W1,NS,DDD,D1,D2)
NCB=NO
IF (NG.EC.0) RETURN
IF (ISET.EC.1) GO TO 610
CALL READG2 (NS,NG,IGAM,GAM)
580 CCNT INUE
IF (IOL.EC.3) GO TO 620
CALL PEADQ (NG,Q)
WRITE (6,1420)
DO 630 I=1,NS
WRITE (6,1430) (GAM(I,J),J=1,NG)
IF (IMCDE.1) GO TO 640
CALL MCDE (WNORMI,GAM,AA,NS,NS,NG,1)
590 CCNT INUE
IF (IOL.EC.3) RETURN
WRITE (6,1420)
DO 650 I=1,NG
WRITE (6,1430) (Q(I,J),J=1,NG)
IF (IQ.EC.1.AND.(NG.EC.0)) GO TO 1260
DO 660 I=1,NS
DO 660 J=0,LO
PRO(I,J)=PRC(I,J)+Q(I,K)*GAM(J,K)
660 DO 670 I=1,NS
DO 670 J=1,NS
OPT10570
OPT10580
OPT10590
OPT10600
OPT10610
OPT10620
OPT10630
OPT10640
OPT10650
OPT10660
OPT10670
OPT10680
OPT10690
OPT10700
OPT10710
OPT10720
OPT10730
OPT10740
OPT10750
OPT10760
OPT10770
OPT10780
OPT10790
OPT10800
OPT10810
OPT10820
OPT10830
OPT10840
OPT10850
OPT10860
OPT10870
OPT10880
OPT10890
OPT10900
OPT10910
OPT10920
OPT10930
OPT10940
OPT10950
OPT10960
OPT10970
OPT10980
OPT10990
OPT11000
OPT11010
OPT11020
OPT11030
OPT11040

```


AD-A152 148

DEVELOPMENT OF GRAPHICAL POLE-ZERO ROOT-LOCUS BODE
NYQUIST AND NICHOLS RESPONSES USING THE OPTSYSX PROGRAM
(U) NAVAL POSTGRADUATE SCHOOL MONTEREY CA M H LAPTAS


2/3


UNCLASSIFIED

SEP 84

F/G 9/2

NL





MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963-A


```

74C RM(I+MH,J+MF)=-BA(J,I)
    RM(I,J+NS)=CC(I,J)
    GC TO 400
C-60 BACK TO 450 TO SET UP THE FILTER HAMILTONIAN: CALC. THE FILTER GAINS
750 CALL RGAIN (M,NS,NC,NCB,WRWI,X,GN,GM, RM,W21,D1,CR,CI,PRO,M+S,D2)
C-----CHECK EIGENVECTORS-----
    IF (IDEBUG.EQ. 0) GC TO 760
    WRITE (6,I=70)
    CALL RAPRNT (NS,NS,NS,9,PRO,4,'(9(1X,1PD13.6))')
760 CCNTINUE
    IF (IDSTAB.EQ. 1) GC TO 770
C-----NORMALIZE AND PRINT OPT. ESTIMATOR EIGENSYSTEM-----
    IWRITE=4
    CALL CNORM (CR,CI,PRC,NS,IWRITE,NSQ,DDD,D1,D2,WNCRM,WNCRMI,HC,AA,
77C 1NC,NS)
    CO 780 I=1,MH
    CO 780 J=1,NC
78C PRO(I,J)=+PC(J,I)/RC(J,J)
    DO 790 I=1,MH
    DO 790 J=1,NC
    FBGE(I,J)=C.DO
    DO 790 K=1,MH
    FEGE(I,J)=FEGE(I,J)+GN(I,K)*PRO(K,J)
790 IF (IDSTAB.EQ. 1) GC TO 810
    WRITE (6,I=70)
    CALL RAPRNT (MH,MH,MF,5,GN,4,'(5(1X,1PD13.6))')
    IWRITE=4
    CO 800 I=1,MH
    X(I,I)=DSCRT(GN(I,I))
80C WRITE (6,I=70) (X(I,I),I=1,MH)
    CO 820 I=1,MH
    FBGE(I,J)=FBGE(I,J),J=1,NC
82C WRITE (6,I=70) (FBGE(I,J),J=1,NC)
C-----MODAL K MATRIX OPEN LOOP U-INV SAVED IN WNCRMIG-----
    IF (IM.NE. 1) GO TO 830
    CALL MODE (WNCRMI,FEGE,AA,MH,MH,NO,4)
83C CCNTINUE
    IF (IDSTAB.EQ. 0) GC TO 850
    DO 840 I=1,NS
    DO 840 J=1,NS
84C PA(I,J)=BA(I,J)-DSTORE(I,J)
    IWRITE=2
850 CCNTINUE
    DO 870 I=1,NS
    DO 870 J=1,NS
    SUM=0.0
    DO 860 K=1,NC

```

```

840      SLM=SUM+FBGE(I,K)*HC(K,J)
850      PRO(I,J)=BA(I,J)-SUM
      WRITE(6,1450)
      CALL RAPRNT(NS,NS,NS,5,PRO,4,'(5(1X,1PD13.6))')
      IF(IR.LT.2) GO TO 890
      CALL BALANC(NS,NS,PRO,LOW,IGH,D1)
      CALL ORTHES(NS,NS,LCW,IGH,PRO,D2)
      CALL ORTRAN(NS,NS,LCW,IGH,PRO,D2,GM)
      CALL HQR2(NS,NS,LOW,IGH,PRO,CR,CI,GM,IEFR)
      IF(IEFR.NE.0) CALL EEXIT(NS,PRO,IEFR)
      CALL BALBAK(NS,NS,LCW,IGH,D1,NS,GM)
      WRITE(6,1460)
      C-----NORMALIZE AND PRINT SUBOPT. ESTIMATOR EIGENSYSTEM-----
      IWRITE=5
      CALL CNORM(CR,CI,GM,NS,IWRITE,NSQ,DD,D1,C2,WNCRM,WNCRMI,HC,AA,
      1NO,NS)
      DO 880 I=1,NS
      IF(CR(I).LT.0.0) GO TO 880
      WRITE(5,1460)
      RETURN
      CCNT INUE
      GC TO 900
      IF(IQ.EQ.C) GO TO 1260
      DO 910 I=1,NH
      DO 910 J=1,NH
      PRO(I,J)=0.0
      DO 910 K=1,NC
      PRO(I,J)=PRC(I,J)+RC(I,K)*FBGE(J,K)
      DO 920 I=1,NH
      DO 920 J=1,NH
      CQ(I,J)=0.0
      DO 920 K=1,NC
      CQ(I,J)=CQ(I,J)-FBGE(I,K)*PRO(K,J)
      CCNT INUE
      C-----THE RMS STATE AND CONTROL RESPONSES-----
      IR=IR+1
      GC TO (1090,1090,940,940), IR
      DO 950 I=1,NS
      DO 950 J=1,NG
      X(I,J)=0.0
      DO 950 K=1,NG
      X(I,J)=X(I,J)+GAM(I,K)*Q(K,J)
      DO 970 I=1,NS
      DO 970 J=1,NS
      SUM=0.0
      DO 960 K=1,NG
      SLM=SUM-X(I,K)*GAM(J,K)
      PRO(I,J)=SUM+CQ(I,J)

```

```

OPTI2010
OPTI2020
OPTI2030
OPTI2040
OPTI2050
OPTI2060
OPTI2070
OPTI2080
OPTI2090
OPTI2100
OPTI2110
OPTI2120
OPTI2130
OPTI2140
OPTI2150
OPTI2160
OPTI2170
OPTI2180
OPTI2190
OPTI2200
OPTI2210
OPTI2220
OPTI2230
OPTI2240
OPTI2250
OPTI2260
OPTI2270
OPTI2280
OPTI2290
OPTI2300
OPTI2310
OPTI2320
OPTI2330
OPTI2340
OPTI2350
OPTI2360
OPTI2370
OPTI2380
OPTI2390
OPTI2400
OPTI2410
OPTI2420
OPTI2430
OPTI2440
OPTI2450
OPTI2460
OPTI2470
OPTI2480

```



```

1080 GM(I,J)=CQ(I,J)-BA(I,J)-BA(J,I)+GN(I,J)
1090 GM(J,I)=GM(I,J)
1100 GO TO 1100
1110 CALL SCOV (NS,SC,W1,CWR,CWI,NS,SC,W1,CWR,CWI,CC,GM)
1120 IF (NC.EQ.0) GO TO 1150
1130 DO 1120 I=1,NS
1140 DO 1120 J=1,NC
1150 PRO(I,J)=0
1160 DO 1110 K=1,NS
1170 PRO(I,J)=PFC(I,J)+GM(I,K)*FBGC(J,K)
1180 CCNT=INUE
1190 DO 1140 I=1,NC
1200 DO 1140 J=1,NC
1210 SC(I,J)=0
1220 DO 1130 K=1,NS
1230 SC(I,J)=SC(I,J)+FBGC(I,K)*PRO(K,J)
1240 CCNT=INUE
1250 IF (IREG .EQ. 0) GO TO 1170
1260 DO 1160 I=1,NS
1270 DO 1160 J=1,NS
1280 CQ(I,J)=GM(I,J)
1290 WRITE (6,170)
1300 CALL RAPRT (MH,MH,MH,5,GM,4,'(5(1X,1PD13.6))')
1310 IF (IR.GT.2) GO TO 1190
1320 DO 1180 I=1,MH
1330 DO 1180 J=1,MH
1340 CQ(I,J)=GN(I,J)+GM(I,J)
1350 CCNT=INUE
1360 WRITE (6,171)
1370 CALL RAPRT (MH,MH,MH,5,CQ,4,'(5(1X,1PD13.6))')
1380 IF (NC.EQ.0) GO TO 1210
1390 WRITE (6,172)
1400 DO 1200 I=1,NC
1410 DO 1200 J=1,NC
1420 SC(I,J)=SC(I,J)+CQ(I,I)
1430 IF (NC.EQ.0) GO TO 1240
1440 DO 1230 I=1,NC
1450 DO 1230 J=1,NC
1460 SC(I,J)=DSCT(SC(I,I))
1470 WRITE (6,174)
1480 DO 1250 I=1,NS
1490 IF (I.LE.NC) WRITE (6,175) CQ(I,I),SC(I,I)
1500 IF (I.GT.NC) WRITE (6,175) CQ(I,I)
1510 CCNT=INUE
1520 IF (ITF3 .EQ. 0) GC TC 1290
1530 IF (ITF3 .EQ. 0) FORM COMPENSATOR FROM MEAS TO INPUT AND COMPUTE TF
1540 DC 1280 I=1,NS

```

```

OPT112970
OPT112980
OPT112990
OPT113000
OPT113010
OPT113020
OPT113030
OPT113040
OPT113050
OPT113060
OPT113070
OPT113080
OPT113090
OPT113100
OPT113110
OPT113120
OPT113130
OPT113140
OPT113150
OPT113160
OPT113170
OPT113180
OPT113190
OPT113200
OPT113210
OPT113220
OPT113230
OPT113240
OPT113250
OPT113260
OPT113270
OPT113280
OPT113290
OPT113300
OPT113310
OPT113320
OPT113330
OPT113340
OPT113350
OPT113360
OPT113370
OPT113380
OPT113390
OPT113400
OPT113410
OPT113420
OPT113430
OPT113440

```

```

1270      DO 1280 J=1,NS
1280      SUM=0
      DO 1270 K=1,NC
      SUM=SUM+FBGE(I,K)*HC(K,J)
      CQ(I,J)=ACL(I,J)-SUM
      WRITE (6,176C)
      ITEX=3
      IZERO=0
      CALL TF (NS,NS,NSQ,CC,AA,NC,FBGE,BM,NC,FBGC,CM,IZERC,D,EB,CC,CP,
      1WR,WI,CWR,CW)
      CCONTINUE
      C----- COMPUTE PSD FUNCTIONS OF THE CONTROLLED SYSTEM -----
      IF (IPSD .EQ. 0) GO TO 1310
      IF (IYU .LT. 3) GO TO 1300
      CALL PSDCAL (M,NS,RM,X,NC,GM,GV,FBGC,NO,HY,HU,HQ,FBGE,NG,
      1GAM,ACL,BA,WR,WI,D1,D2,JCF,RES,Q,RC,BB,CC,1,IPSD,INORM)
      CALL PSDCAL (M,NS,RM,X,NC,GM,GV,FBGC,NO,HY,HU,HQ,FBGE,NG,
      1GAM,ACL,BA,WR,WI,D1,D2,JCF,RES,Q,RC,BB,CC,2,IPSD,INORM)
      GO TO 1310
      CALL PSDCAL (M,NS,PM,X,NC,GM,GV,FBGC,NO,HY,HU,HQ,FBGE,NG,
      1GAM,ACL,BA,WR,WI,D1,D2,JCF,RES,Q,RC,BB,CC,IYU,IPSD,INORM)
      IF (IS .EQ. 0) RETURN
      IF (INC .NE. 0) GO TO 1350
      DO 1320 I=1,NS
      DO 1320 J=1,NS
      ACL(I,J)=BA(I,J)
      CCONTINUE
      CALL MINV (NSQ,ACL,NS,DDD,D1,D2)
      CALL READW (NG,WR)
      WRITE (6,1770) (WR(I),I=1,NG)
      CO I340 I=1,NS
      WI(I)=0
      DO I340 J=1,NG
      WI(I)=WI(I)+GAM(I,J)*WR(J)
      DO I360 I=1,NS
      CR(I)=0
      DO I350 J=1,NS
      CR(I)=CR(I)-ACL(I,J)*WI(J)
      WRITE (6,1750) CR(I)
      CO I370 I=1,NC
      CI(I)=0
      DO I370 J=1,NS
      CI(I)=CI(I)+FBGC(I,J)*CR(J)
      WRITE (6,1750) (CI(I),I=1,NC)
      RETURN
      C-----
      C67C  FORMAT (2X,1P6D14.6,/,2X,6D14.6)

```

```

OPT113450
OPT113460
OPT113470
OPT113480
OPT113490
OPT113500
OPT113510
OPT113520
OPT113530
OPT113540
OPT113550
OPT113560
OPT113570
OPT113580
OPT113590
OPT113600
OPT113610
OPT113620
OPT113630
OPT113640
OPT113650
OPT113660
OPT113670
OPT113680
OPT113690
OPT113700
OPT113710
OPT113720
OPT113730
OPT113740
OPT113750
OPT113760
OPT113770
OPT113780
OPT113790
OPT113800
OPT113810
OPT113820
OPT113830
OPT113840
OPT113850
OPT113860
OPT113870
OPT113880
OPT113890
OPT113900
OPT113910
OPT113920

```



```

177C  FORMAT (//,EX,46HSTEADY DISTURBANCE VECTOR.....W.....//OPTI14410
1,10(1X,1PD12.4//))OPTI14420
1780  FORMAT (//,EX,45HSTEADY STATE VALUES OF STATE VAR. ARE.....//)OPTI14430
1790  FORMAT (//,EX,47HSTEADY STATE CONTROL IS .....//)OPTI14440
1/10(1X,1PD12.4//))OPTI14450
1800  FORMAT (//,EX,49HENTER THE MAGNITUDE OF THE DESTABILIZATION VECTOROPTI14460
1,8X,47HTC BE ADDED DOWN THE DIAGONAL OF THE "F"-MATRIX,/,8X,18HTOPTI14470
2C DESTABILIZE IT.,//)OPTI14480
C-----CFGRAPH DATA-----OPTI14490
C000  FORMAT(5X,2C30.14)OPTI14500
C-----OPTI14510
C=====OPTI14520
SUBROUTINE RAPRNT (NMWAX,M,N,L,A, IDIM,FMT)OPTI14530
REAL*8 A(NMAX,N)OPTI14540
DIMENSION FMT(IDIM)OPTI14550
NU=LDO 20 NL=1,N,LNU=NIF (NU.GT.N) NU=NDC 10 I=1,NWRITE (6,FMT) (A(I,J),J=R(L,NU)1C
2C
3C
C=====OPTI14580
SUBROUTINE RGAIN (M,NS,NC,NOB,WR,WI,VF,GN,W11,TCB,W21,LT,C,CI,CT,M1HS,MT)OPTI14590
IMPLICIT REAL*8 (A-H,O-Z)OPTI14600
DIMENSION WR(M),WI(M),VF(M,M),GN(NS,NS)OPTI14610
DIMENSION W11(NS,NS),TCB(M,M),W21(NS,NS),LT(NS),MT(NS)OPTI14620
DIMENSION C(NS),CI(NS),CT(NS,NS)OPTI14630
K=1KP=1KN=1NRZEV=0NCPZEV=0IF (K.GT.M) GO TO 21C
1C-----OPTI14640
C CHECK FOR SIGVAL AT OR NEAR J-OMEGA AXIS TO INCLUDE IN E-L EIGSYSOPTI14650
C TURN FIRST ONE POSITIVE AND SECOND ONE NEGATIVEOPTI14660
C-----OPTI14670
SIGVR=CABS(WR(K))OPTI14680
IF (EIGVR.GE.1.D-10) GO TO 60OPTI14690
IF (WI(K)) 40,20,40OPTI14700
NRZEV=NRZEV+1OPTI14710
IF (NRZEV.GT.1) GO TC 30OPTI14720
OPTI14730
OPTI14740
OPTI14750
OPTI14760
OPTI14770
OPTI14780
OPTI14790
OPTI14800
OPTI14810
OPTI14820
OPTI14830
OPTI14840
OPTI14850
OPTI14860
OPTI14870
OPTI14880

```

```

3C      WP(K)=EIGVP
        GO TO 80
        WR(K)=-EIGVF
        WRITE (6,25C)
        GO TO 150
4C      NCPZEV=NCPZEV+1
        IF (NCPZEV.GT.1) GO TO 50
        WP(K)=EIGVP
        WR(K+1)=EIGVR
        GO TO 110
5C      WR(K)=-EIGVF
        WR(K+1)=-EIGVR
        WRITE (6,30C)
        GO TO 180
6C      IF (WR(K)) 140,70,70
7C      IF (WI(K)) 110,80,110
8C      IF (NOB.EQ.C) GO TO 100
        C-----EIGENVECTOR FOR REAL EIGENVALUE, POSITIVE-----
9C      DO 90 J=1,N
        TCB(J,KP)=VF(J,K)
        K=KP+1
10C     GO TO 10
        C-----EIGENVECTOR FOR COMPLEX EIGENVALUE, POSITIVE REAL PART-----
11C     IF (NOB.EQ.C) GO TO 130
        DO 120 J=1,N
        FR=VF(J,K)
        FI=-VF(J,K+1)
        TCB(J,KP)=FR+FI
        TCB(J,KP+1)=FR-FI
        KP=KP+2
        K=K+2
12C     GO TO 10
        C-----EIGENVECTOR FOR REAL EIGENVALUE, NEGATIVE REAL PART-----
13C     IF (WI(K)) 180,150,120
        C-----EIGENVECTOR FOR COMPLEX EIGENVALUE, NEGATIVE REAL PART-----
14C     C(KN)=WR(K)
        C(KN)=WI(K)
        IF (NOB.NE.C) GO TO 170
        KNS=KN+NS
        DO 160 J=1,N
        TCB(J,KNS)=VF(J,K)
        KN=KN+1
        K=K+1
15C     GO TO 10
        C-----EIGENVECTOR FOR COMPLEX EIGENVALUE, NEGATIVE REAL PART-----
16C     PR=WR(K)
17C     RI=WI(K)
        C(KN)=PR

```

```

OPT1 4890
OPT1 4900
OPT1 4910
OPT1 4920
OPT1 4930
OPT1 4940
OPT1 4950
OPT1 4960
OPT1 4970
OPT1 4980
OPT1 4990
OPT1 5000
OPT1 5010
OPT1 5020
OPT1 5030
OPT1 5040
OPT1 5050
OPT1 5060
OPT1 5070
OPT1 5080
OPT1 5090
OPT1 5100
OPT1 5110
OPT1 5120
OPT1 5130
OPT1 5140
OPT1 5150
OPT1 5160
OPT1 5170
OPT1 5180
OPT1 5190
OPT1 5200
OPT1 5210
OPT1 5220
OPT1 5230
OPT1 5240
OPT1 5250
OPT1 5260
OPT1 5270
OPT1 5280
OPT1 5290
OPT1 5300
OPT1 5310
OPT1 5320
OPT1 5330
OPT1 5340
OPT1 5350
OPT1 5360

```



```

C(KN+1)=RR
C I(KN)=RI
C I(KN+1)=-RI
IF (NOB.NE.C) GO TO 200
KNS=KN+NS
DO 190 J=1,N
FR=VF(J,K)
FI=-VF(J,K+1)
TCB(J,KNS)=FR+FI
TCB(J,KNS+1)=FR-FI
KN=KN+2
K=K+2
GO TO 10
CONTINUE
IF (NOB.NE.C) GO TO 240
-----FORMATION OF W1-----
DO 220 I=1,NS
DO 220 J=1,NS
W1(I,J)=TCB(I,J+NS)
CT(I,J)=W1(I,J)
-----FORMATION OF W2-----
DO 230 I=1,NS
DO 230 J=1,NS
W2(I,J)=TCB(I+NS,J+NS)
IF (NOB.EQ.C) GO TO 260
DO 250 I=1,NS
DO 250 J=1,NS
W2(I,J)=-TCB(I,J)
W1(I,J)=TCB(I+NS,J)
CCNT INUE
-----INVERT W1-----
NSO=NS*NS
CALL MINV (NSQ,W1,NS,DETC,LI,MT)
-----CALCULATE THE RGAIN MATRIX-----
DO 270 IL=1,NS
DO 270 JL=1,NS
GN(IL,JL)=0.DO
DO 270 KL=1,NS
GN(IL,JL)=GN(IL,JL)+W2(I,KL)*W1(KL,JL)
IF (NOB.EQ.C) RETURN
DO 280 I=1,NS
DO 280 J=1,NS
CT(I,J)=W1(J,I)
RETURN
-----EULER-LAGRANGE EQUATIONS HAVE A REAL EIGENVALUE AT, OPT15810
114H OR NEAR ZERO./)
-----EULER-LAGRANGE EQUATIONS HAVE A COMPLEX PAIR OF ,400PT15840

```

```

1EIGENVALUES AT OR NEAR THE J-OMEGA AXIS.)
END
=====
SUBROUTINE MINV (NSQ,A,N,D,L,M)
IMPLICIT REAL*8 (A-H,O-Z)
DIMENSION A(NSQ),L(N),M(N)
COMPILE PRECISION A,C,BIGA,HOLD
NV=N*N
C=1.0D0
AK=-N
DO 180 K=1,N
  NK=NK+N
  L(K)=K
  M(K)=K
  KK=NK+K
  BIGA=A(KK)
  DO 20 J=K,N
    IZ=N*(J-1)
    CC 20 I=K,N
    IJ=IZ+I
    IF (DABS(BIGA)-DABS(A(IJ))) 10,20,20
  1C BIGA=A(IJ)
  L(K)=I
  M(K)=J
  2C CONTINUE
-----INTERCHANGE ROWS-----
J=L(K)
IF (J-K) 5C,50,30
KI=K-N
DO 40 I=1,N
  KI=KI+N
  HOLD=-A(KI)
  JI=KI-K+J
  A(KI)=A(JI)
  A(JI)=HOLD
  4C
5C I=M(K)
IF (I-K) 8C,80,60
JP=N*(I-1)
DO 70 J=1,N
  JK=NK+J
  JI=JP+J
  HOLD=-A(JK)
  A(JK)=A(JI)
  A(JI)=HOLD
  7C
C-----DIVIDE COLUMN BY MINUS PIVOT-----
C-----CF PIVOT ELEMENT IS CONTAINED IN BIGA)-----
8C IF (BIGA) 1C0,9C,1C0
  1C0
  1C1
  1C2
  1C3
  1C4
  1C5
  1C6
  1C7
  1C8
  1C9
  1C10
  1C11
  1C12
  1C13
  1C14
  1C15
  1C16
  1C17
  1C18
  1C19
  1C20
  1C21
  1C22
  1C23
  1C24
  1C25
  1C26
  1C27
  1C28
  1C29
  1C30
  1C31
  1C32

```

```

SC      D=0.0D0
RETURN
100     CO 120 I=1,N IIC,120,110
110     IK=NK+I
120     A(IK)=A(IK)/(-BIGA)
C-----REDUCE MATRIX-----
      DC 150 I=1,N
      IK=NK+I
      HOLD=A(IK)
      IJ=I-N
      DO 150 J=1,N
      IJ=IJ+N
      IF (I-K) 120,150,130
      IF (J-K) 140,150,140
130     KJ=IJ-I+K
140     A(IJ)=HOLD*A(KJ)+A(IJ)
150     CONTINUE
C-----DIVIDE ROW BY PIVOT-----
      KJ=K-N
      DO 170 J=1,N
      KJ=KJ+N
      IF (J-K) 160,170,160
160     A(KJ)=A(KJ)/BIGA
170     CONTINUE
C-----PRODUCT OF PIVOTS-----
      C=D*BIGA
C-----REPLACE PIVOT BY RECIPROCAL-----
      A(KK)=(1.0CC)/BIGA
180     CONTINUE
C-----FINAL ROW AND COLUMN INTERCHANGE-----
      K=N
      K=(K-1)
      IF (K) 260,260,200
      I=L(K)
      IF (I-K) 230,230,210
      JC=N*(K-1)
      JR=N*(I-1)
      CC 220 J=1,N
      JK=JC+J
      FOLD=A(JK)
      JI=JR+J
      A(JK)=-A(JI)
      A(JI)=FOLD
      JM(K)
      IF (J-K) 150,190,240
      KI=K-N
      200
      210
      220
      230
      240

```

```

DC 250 I=1,N
KI=KI+N
HOLD=A(KI)
JI=KI-K+J
A(KI)=-A(JI)
A(JI)=HOLD
GC TO 190
K=0
RETURN
END
C=====
SUBROUTINE SCOV (NL,NL,WL,WLI,VL1,VL2,NR,WR,WRI,VR1,VR2,Q,X)
REAL*8 VLI(NL),VL2(NL),WL(NL,NL),WLI(NL,NL),X(NL,NR),Q(NL,NR),
1 VRI(NR),VR2(NR),WR(NR,NR),WRI(NR,NR)
1 REAL*8 A,B,C,D,K1,K2,K3,K4
DC 20 I=1,NL
DO 20 J=1,NR
X(I,J)=0.
DC 20 II=1,NL
X(I,II)=X(I,J)+WLI(I,II)*Q(II,J)
CC 40 I=1,NL
CC 40 J=1,NR
Q(I,J)=0.
CC 30 JJ=1,NR
Q(I,J)=Q(I,J)+X(I,JJ)*WRI(J,JJ)
CONTINUE
I=1
IF (VL2(I)) 60,110,60
J=1
IF (VR2(J)) 80,90,80
A=VLI(I)+VRI(J)
B=-2.*VL2(I)*VR2(J)
C=A**2+VL2(I)**2+VR2(J)**2
C=C**2-B**2
K1=A*C/D
K2=- (VR2(J)*C+VL2(I)*B)/D
K3=- (VR2(J)*B+VL2(I)*C)/D
I=I+1
JI=J+1
X(I,J)=+K1*C(I,J)+K2*Q(I,J)+K3*Q(I,J)+K4*Q(I,J,J1)
X(I,J1)=-K2*Q(I,J)+K1*Q(I,J1)-K4*Q(I,J,J1)
X(I,J)=+K3*Q(I,J)+K1*Q(I,J1)+K2*Q(I,J,J1)
X(I,J1)=-K4*Q(I,J)+K3*Q(I,J1)-K2*Q(I,J,J1)
J=J+2
GC TO 100
A=VRI(J)+VLI(I)
B=A**2+VL2(I)**2

```

```

100 K1=A/B
    K2=VL2(I)/E
    X(I,J)=K1*C(I,J)-K2*C(I+1,J)
    X(I+1,J)=K2*Q(I,J)+K1*Q(I+1,J)
    J=J+1
    IF (J.LE.NR) GO TO 70
    I=I+2
    GO TO 160

110 J=1
120 IF (VR2(J)) 120,140,130
130 A=VR1(J)+VL1(I)
    B=A**2+VR2(J)**2
    K1=A/B
    K2=VR2(J)/E
    X(I,J)=K1*C(I,J)-K2*C(I,J+1)
    X(I,J+1)=K2*Q(I,J)+K1*Q(I,J+1)
    J=J+2
    GO TO 150

140 X(I,J)=Q(I,J)/(VR1(J)+VL1(I))
    J=J+1
    IF (J.LE.NR) GO TO 120

150 I=I+1
    IF (I.LE.NL) GC TO 50
    DO 170 I=1,NL
    DO 170 J=1,NR
    Q(I,J)=0.
    DO 170 I=1,NL
    DO 170 J=1,NR
    Q(I,J)=Q(I,J)+WL(I,I)*X(I,J)
    DO 180 J=1,NR
    DO 180 JJ=1,NR
    X(I,J)=X(I,J)+Q(I,JJ)*WR(J,JJ)
    CCNT=CCNT+1
    RETURN
END
C=====
C SUBROUTINE MCDE (WNORM,G,GNORM,NS,N1,N2,ICCN)
C
C WNORM TRANSFORMATION MATRIX U OR U-INV
C NS NO. OF STATES
C NC NO. OF INPUTS CP OUTPUTS
C ICCN CONTROL FLAG TO INDICATE WHICH TRANSFORMATION
C 0 = MCEAL GAMMA
C 1 = MCEAL H
C 2 = MCEAL C
C 3 = MCEAL K
C 4 = MCEAL K

```

```

OPTI 17290
OPTI 17300
OPTI 17310
OPTI 17320
OPTI 17330
OPTI 17340
OPTI 17350
OPTI 17360
OPTI 17370
OPTI 17380
OPTI 17390
OPTI 17400
OPTI 17410
OPTI 17420
OPTI 17430
OPTI 17440
OPTI 17450
OPTI 17460
OPTI 17470
OPTI 17480
OPTI 17490
OPTI 17500
OPTI 17510
OPTI 17520
OPTI 17530
OPTI 17540
OPTI 17550
OPTI 17560
OPTI 17570
OPTI 17580
OPTI 17590
OPTI 17600
OPTI 17610
OPTI 17620
OPTI 17630
OPTI 17640
OPTI 17650
OPTI 17660
OPTI 17670
OPTI 17680
OPTI 17690
OPTI 17700
OPTI 17710
OPTI 17720
OPTI 17730
OPTI 17740
OPTI 17750
OPTI 17760

```



```

C=====
END
SUBROUTINE CNORM (WZ,WY,VEC,NS,IWRITE,NSQ,CDD,D1,D2,WNORM,WNCPRM,HOPT)
10,CM,N1,N2,
C-----
      WZ(I)      REAL PART OF I-TH EIGENVALUE
      WY(I)      COMPLEX PART OF I-TH EIGENVALUE
      VEC        MATRIX OF RIGHT EIGENVECTORS STORED IN REAL FORM
      NS         FROM PQR2
      IWRITE     FLAG TO CONTROL FORMATS FOR DIFFERENT EIGENSYSTEMS
      WNORM      NORMALIZED MATRIX U OF RIGHT EIGENVECTORS STORED
      WNORMI     BY COLUMNS IN REAL FORM
      NSQ,DDC,D1,D2 - ARGUMENTS PASSED TO MINV
C=====
      IMPLICIT REAL*8 (A-H,O-Z)
      REAL*8 FIELDC,COMMA,SEMICOL,RIGHT,FMT
      DIMENSION WZ(2*NS),WY(NS),VEC(NS,NS),WNORM(NS,NS),WNORMI(NS,NS),STOR
      1E(6),D1(NS),D2(NS),FMT(14),HO(N1,N2),CM(N1,N2)
      DATA FIELDC/5E12.5/,COMMA/5H,/,SEMICOL/5H,/,RIGHT/1H)/,FMT/
      16H(1X,1P,12#1H/,SEMICOL/4H,/,/,
C-----NORMALIZE COMPLEX EIGENVECTORS BY LARGEST ELEMENT-----
      KK=0
      LR=0
      LC=0
      DO 50 K=1,NS
      IF (DABS(WY(K)).LT.1.0D-10) GO TO 50
      LC=LC+1
      FMAX=0
      DO 20 I=1,NS
      CMOD=VEC(I,K)**2+VEC(I,K+1)**2
      IF (CMOD-FMAX) 20,10,10
      FMAX=CMOD
      N=I
      GO TO 10
      20
      CCNT INUE
      VMR=VEC(M,K)
      VMI=VEC(M,K+1)
      DO 30 I=1,NS
      VR=VEC(I,K)
      VI=VEC(I,K+1)
      VECRN=(VR*VMR+VI*VMI)/FMAX
      30
      10
      20
      OPT118250
      OPT118260
      OPT118270
      OPT118280
      OPT118290
      OPT118300
      OPT118310
      OPT118320
      OPT118330
      OPT118340
      OPT118350
      OPT118360
      OPT118370
      OPT118380
      OPT118390
      OPT118400
      OPT118410
      OPT118420
      OPT118430
      OPT118440
      OPT118450
      OPT118460
      OPT118470
      OPT118480
      OPT118490
      OPT118500
      OPT118510
      OPT118520
      OPT118530
      OPT118540
      OPT118550
      OPT118560
      OPT118570
      OPT118580
      OPT118590
      OPT118600
      OPT118610
      OPT118620
      OPT118630
      OPT118640
      OPT118650
      OPT118660
      OPT118670
      OPT118680
      OPT118690
      OPT118700
      OPT118710
      OPT118720

```

```

      3C      VECIN=(-VR*VMI+VI*VMP)/EMAX
      4C      WNCNM(I,K)=VECRN
      5C      WNCNM(I,K+1)=VECIN
      6C      CCNT INUE
      7C      KK=1
      8C      GC TO 50
      9C      KK=0
      AC      CCNT INUE
      BC      NORMALIZE REAL EIGENVECTORS BY THE TOTAL LENGTH-----
      CC      DO 80 K=1,N
      DC      IF (DABS(WY(K)).GE.1.D-10) GO TO 80
      EC      LR=LR+1
      FC      REMOD=0
      GC      DO 60 I=1,N
      HC      REMOD=VEC(I,K)**2+REMOD
      IC      REMOD=DSQRT(REMOD)
      JC      DO 70 I=1,N
      KC      RVEC=VEC(I,K)/REMOD
      LC      WNCNM(I,K)=RVEC
      MC      CCNT INUE
      NC      CCNT INUE
      OC      GC TO (90,100,110,120,130), IWRITE
      PC      WRITE (6,32C)
      QC      GO TO 140
      RC      WRITE (6,33C)
      SC      GO TO 140
      TC      WRITE (6,34C)
      UC      GO TO 140
      VC      WRITE (6,35C)
      WC      GC TO 140
      XC      WRITE (6,36C)
      YC      KK=0
      ZC      NPRTW=0
      10C      NFMTW=1
      11C      IF (KK.EQ.1) GO TO 170
      12C      IF (DABS(WY(I)).GT.1.D-10) KK=1
      13C      PRINT OUT NC MORE THAN 6 WORDS, NOT SEPARATING CCMPLEX EIGVAL
      14C      IF (NPRTW.LT.5) OR (NPRTW.EQ.5) AND (KK.EQ.0) GC TO 150
      15C      FMT(NFMTW+1)=FIGHT
      16C      WRITE (6,FMT) (STORE(J),J=1,NPRTW)
      17C      NPRTW=0
      18C      NFMTW=1
      19C      NPRTW=NPRTW+1
      20C      NFMTW=NFMTW+1
      21C      IF (KK.EC.1) GO TO 160
      22C      STORE(NPRTW)=WZ(I)
      23C      FMT(NFMTW)=FIELD
      24C
      25C
      26C
      27C
      28C
      29C
      30C
      31C
      32C
      33C
      34C
      35C
      36C
      37C
      38C
      39C
      40C
      41C
      42C
      43C
      44C
      45C
      46C
      47C
      48C
      49C
      50C
      51C
      52C
      53C
      54C
      55C
      56C
      57C
      58C
      59C
      60C
      61C
      62C
      63C
      64C
      65C
      66C
      67C
      68C
      69C
      70C
      71C
      72C
      73C
      74C
      75C
      76C
      77C
      78C
      79C
      80C
      81C
      82C
      83C
      84C
      85C
      86C
      87C
      88C
      89C
      90C
      91C
      92C
      93C
      94C
      95C
      96C
      97C
      98C
      99C
      100C
      101C
      102C
      103C
      104C
      105C
      106C
      107C
      108C
      109C
      110C
      111C
      112C
      113C
      114C
      115C
      116C
      117C
      118C
      119C
      120C
      121C
      122C
      123C
      124C
      125C
      126C
      127C
      128C
      129C
      130C
      131C
      132C
      133C
      134C
      135C
      136C
      137C
      138C
      139C
      140C
      141C
      142C
      143C
      144C
      145C
      146C
      147C
      148C
      149C
      150C
      151C
      152C
      153C
      154C
      155C
      156C
      157C
      158C
      159C
      160C
      161C
      162C
      163C
      164C
      165C
      166C
      167C
      168C
      169C
      170C
      171C
      172C
      173C
      174C
      175C
      176C
      177C
      178C
      179C
      180C
      181C
      182C
      183C
      184C
      185C
      186C
      187C
      188C
      189C
      190C
      191C
      192C
      193C
      194C
      195C
      196C
      197C
      198C
      199C
      200C
      201C
      202C
      203C
      204C
      205C
      206C
      207C
      208C
      209C
      210C
      211C
      212C
      213C
      214C
      215C
      216C
      217C
      218C
      219C
      220C
      221C
      222C
      223C
      224C
      225C
      226C
      227C
      228C
      229C
      230C
      231C
      232C
      233C
      234C
      235C
      236C
      237C
      238C
      239C
      240C
      241C
      242C
      243C
      244C
      245C
      246C
      247C
      248C
      249C
      250C
      251C
      252C
      253C
      254C
      255C
      256C
      257C
      258C
      259C
      260C
      261C
      262C
      263C
      264C
      265C
      266C
      267C
      268C
      269C
      270C
      271C
      272C
      273C
      274C
      275C
      276C
      277C
      278C
      279C
      280C
      281C
      282C
      283C
      284C
      285C
      286C
      287C
      288C
      289C
      290C
      291C
      292C
      293C
      294C
      295C
      296C
      297C
      298C
      299C
      300C
      301C
      302C
      303C
      304C
      305C
      306C
      307C
      308C
      309C
      310C
      311C
      312C
      313C
      314C
      315C
      316C
      317C
      318C
      319C
      320C
      321C
      322C
      323C
      324C
      325C
      326C
      327C
      328C
      329C
      330C
      331C
      332C
      333C
      334C
      335C
      336C
      337C
      338C
      339C
      340C
      341C
      342C
      343C
      344C
      345C
      346C
      347C
      348C
      349C
      350C
      351C
      352C
      353C
      354C
      355C
      356C
      357C
      358C
      359C
      360C
      361C
      362C
      363C
      364C
      365C
      366C
      367C
      368C
      369C
      370C
      371C
      372C
      373C
      374C
      375C
      376C
      377C
      378C
      379C
      380C
      381C
      382C
      383C
      384C
      385C
      386C
      387C
      388C
      389C
      390C
      391C
      392C
      393C
      394C
      395C
      396C
      397C
      398C
      399C
      400C
      401C
      402C
      403C
      404C
      405C
      406C
      407C
      408C
      409C
      410C
      411C
      412C
      413C
      414C
      415C
      416C
      417C
      418C
      419C
      420C
      421C
      422C
      423C
      424C
      425C
      426C
      427C
      428C
      429C
      430C
      431C
      432C
      433C
      434C
      435C
      436C
      437C
      438C
      439C
      440C
      441C
      442C
      443C
      444C
      445C
      446C
      447C
      448C
      449C
      450C
      451C
      452C
      453C
      454C
      455C
      456C
      457C
      458C
      459C
      460C
      461C
      462C
      463C
      464C
      465C
      466C
      467C
      468C
      469C
      470C
      471C
      472C
      473C
      474C
      475C
      476C
      477C
      478C
      479C
      480C
      481C
      482C
      483C
      484C
      485C
      486C
      487C
      488C
      489C
      490C
      491C
      492C
      493C
      494C
      495C
      496C
      497C
      498C
      499C
      500C
      501C
      502C
      503C
      504C
      505C
      506C
      507C
      508C
      509C
      510C
      511C
      512C
      513C
      514C
      515C
      516C
      517C
      518C
      519C
      520C
      521C
      522C
      523C
      524C
      525C
      526C
      527C
      528C
      529C
      530C
      531C
      532C
      533C
      534C
      535C
      536C
      537C
      538C
      539C
      540C
      541C
      542C
      543C
      544C
      545C
      546C
      547C
      548C
      549C
      550C
      551C
      552C
      553C
      554C
      555C
      556C
      557C
      558C
      559C
      560C
      561C
      562C
      563C
      564C
      565C
      566C
      567C
      568C
      569C
      570C
      571C
      572C
      573C
      574C
      575C
      576C
      577C
      578C
      579C
      580C
      581C
      582C
      583C
      584C
      585C
      586C
      587C
      588C
      589C
      590C
      591C
      592C
      593C
      594C
      595C
      596C
      597C
      598C
      599C
      600C
      601C
      602C
      603C
      604C
      605C
      606C
      607C
      608C
      609C
      610C
      611C
      612C
      613C
      614C
      615C
      616C
      617C
      618C
      619C
      620C
      621C
      622C
      623C
      624C
      625C
      626C
      627C
      628C
      629C
      630C
      631C
      632C
      633C
      634C
      635C
      636C
      637C
      638C
      639C
      640C
      641C
      642C
      643C
      644C
      645C
      646C
      647C
      648C
      649C
      650C
      651C
      652C
      653C
      654C
      655C
      656C
      657C
      658C
      659C
      660C
      661C
      662C
      663C
      664C
      665C
      666C
      667C
      668C
      669C
      670C
      671C
      672C
      673C
      674C
      675C
      676C
      677C
      678C
      679C
      680C
      681C
      682C
      683C
      684C
      685C
      686C
      687C
      688C
      689C
      690C
      691C
      692C
      693C
      694C
      695C
      696C
      697C
      698C
      699C
      700C
      701C
      702C
      703C
      704C
      705C
      706C
      707C
      708C
      709C
      710C
      711C
      712C
      713C
      714C
      715C
      716C
      717C
      718C
      719C
      720C
      721C
      722C
      723C
      724C
      725C
      726C
      727C
      728C
      729C
      730C
      731C
      732C
      733C
      734C
      735C
      736C
      737C
      738C
      739C
      740C
      741C
      742C
      743C
      744C
      745C
      746C
      747C
      748C
      749C
      750C
      751C
      752C
      753C
      754C
      755C
      756C
      757C
      758C
      759C
      760C
      761C
      762C
      763C
      764C
      765C
      766C
      767C
      768C
      769C
      770C
      771C
      772C
      773C
      774C
      775C
      776C
      777C
      778C
      779C
      780C
      781C
      782C
      783C
      784C
      785C
      786C
      787C
      788C
      789C
      790C
      791C
      792C
      793C
      794C
      795C
      796C
      797C
      798C
      799C
      800C
      801C
      802C
      803C
      804C
      805C
      806C
      807C
      808C
      809C
      810C
      811C
      812C
      813C
      814C
      815C
      816C
      817C
      818C
      819C
      820C
      821C
      822C
      823C
      824C
      825C
      826C
      827C
      828C
      829C
      830C
      831C
      832C
      833C
      834C
      835C
      836C
      837C
      838C
      839C
      840C
      841C
      842C
      843C
      844C
      845C
      846C
      847C
      848C
      849C
      850C
      851C
      852C
      853C
      854C
      855C
      856C
      857C
      858C
      859C
      860C
      861C
      862C
      863C
      864C
      865C
      866C
      867C
      868C
      869C
      870C
      871C
      872C
      873C
      874C
      875C
      876C
      877C
      878C
      879C
      880C
      881C
      882C
      883C
      884C
      885C
      886C
      887C
      888C
      889C
      890C
      891C
      892C
      893C
      894C
      895C
      896C
      897C
      898C
      899C
      900C
      901C
      902C
      903C
      904C
      905C
      906C
      907C
      908C
      909C
      910C
      911C
      912C
      913C
      914C
      915C
      916C
      917C
      918C
      919C
      920C
      921C
      922C
      923C
      924C
      925C
      926C
      927C
      928C
      929C
      930C
      931C
      932C
      933C
      934C
      935C
      936C
      937C
      938C
      939C
      940C
      941C
      942C
      943C
      944C
      945C
      946C
      947C
      948C
      949C
      950C
      951C
      952C
      953C
      954C
      955C
      956C
      957C
      958C
      959C
      960C
      961C
      962C
      963C
      964C
      965C
      966C
      967C
      968C
      969C
      970C
      971C
      972C
      973C
      974C
      975C
      976C
      977C
      978C
      979C
      980C
      981C
      982C
      983C
      984C
      985C
      986C
      987C
      988C
      989C
      990C
      991C
      992C
      993C
      994C
      995C
      996C
      997C
      998C
      999C
      1000C

```



```

160      NFMTW=NFMTH+1
      FMT(NFMTH)=SEMCOL
      GO TO 180
      STORE(NPRTW)=WZ(I)
      FMT(NFMTH+1)=FIELD
      FMT(NFMTH+1)=COMMA
      STORE(NPRTW+1)=WY(I)
      FMT(NFMTH+2)=FIELD
      FMT(NFMTH+3)=SEMCOL
      NPRTW=NFMTH+3
      NPRTW=NPRTH+1
      GO TO 180
      KK=0
      CCNT INUE
      FMT(NFMTH)=SEMENTD
      FMT(NFMTH+1)=RIGHT
      FMT(NFMTH+1)=STORE(J) J=1,NPRTW
      IF (IWRITE.NE.1) GO TO 190
      WRITE(6,37C)
      GO TO 200
      WRITE(6,38C)
      CALL RAPRNT (NS,NS,NS,6,WNORM,4,(6(IX,1PC13.6)))
      GO TO 210
      CALL MCDE (WNORM,HD,CM,NS,N1,N2,5)
      CALL MCDE (WNORM,HD,CM,NS,N1,N2,6)
      GO TO 230
      CALL MCDE (WNORM,HD,CM,NS,N1,N2,6)
      GO TO 240
      WRITE(6,39C)
      GO TO 290
      WRITE(6,40C)
      GO TO 290
      WRITE(6,41C)
      GO TO 290
      WRITE(6,420)
      GO TO 290
      WRITE(6,43C)
      C-----SAVE U-INVERSE OPEN LOOP IN WNORMI-----
      IF (IWRITE.GT.1) GC TC 310
      DO 300 I=1,NS
      DO 300 J=1,NS
      WNORMI(I,J)=WNORM(I,J)
      CALL MINV (NSQ,WNORMI,NS,DDD,D1,D2)
      CALL RAPRNT (NS,NS,NS,6,WNORMI,4,(6(IX,1PC13.6)))
      RETURN
      CALL MINV (NSQ,WNORM,NS,DDD,D1,D2)
      CALL RAPRNT (NS,NS,NS,6,WNORM,4,(6(IX,1PC13.6)))
      RETURN
C-----

```

```

OPTI 19210
OPTI 19220
OPTI 19230
OPTI 19240
OPTI 19250
OPTI 19260
OPTI 19270
OPTI 19280
OPTI 19290
OPTI 19300
OPTI 19310
OPTI 19320
OPTI 19330
OPTI 19340
OPTI 19350
OPTI 19360
OPTI 19370
OPTI 19380
OPTI 19390
OPTI 19400
OPTI 19410
OPTI 19420
OPTI 19430
OPTI 19440
OPTI 19450
OPTI 19460
OPTI 19470
OPTI 19480
OPTI 19490
OPTI 19500
OPTI 19510
OPTI 19520
OPTI 19530
OPTI 19540
OPTI 19550
OPTI 19560
OPTI 19570
OPTI 19580
OPTI 19590
OPTI 19600
OPTI 19610
OPTI 19620
OPTI 19630
OPTI 19640
OPTI 19650
OPTI 19660
OPTI 19670
OPTI 19680

```



```

C=====
END
SUBROUTINE POLES (N,NM,A,AA,M,B,L,C,EVR,EVI,D1,D2,JCF,SC)
IMPLICIT REAL*8(A-H,C-Z)
DIMENSION A(N,N),AA(N,N),B(N,M),C(L,N),EVR(N),EVI(N),D1(N),D2(N),J
1CF(N),SC(N,N)
DO 10 I=1,N
DO 10 J=1,N
AA(I,J)=A(I,J)
CALL BALANC (NM,N,AA,LCH,IHIGH,D1)
CALL ORTHES (NM,N,LCH,IHIGH,AA,D2,SC)
CALL ORTRAN (NM,N,LCH,IHIGH,AA,D2,SC)
CALL HQR2 (NM,N,LOW,IHIGH,AA,EVR,EVI,SC,IERR)
IF (IERR.NE.0) GO TO 30
CALL BALBAK (NM,N,LCH,IHIGH,D1,N,SC)
WRITE (6,4C)
DO 20 I=1,N
C-----WRITE (4,2CC) EVR(I),EVI(I)-----OPTGRM DATA-----
C-----
C-----
2CWRITE (6,5C) EVR(I),EVI(I)
C-----
3CRETURN
C-----
4CFORMAT (//,28H TF DENOMINATOR EIGENVALUES:,//)
5CFORMAT (//,2X,2H (,F13.6,4H)+J(,F13.6,1H))
6CFORMAT (35F,FAILURE IN HQR2, CALCULATING PCLES)
C-----OPTGRM DATA-----
2000FORMAT(5X,2(30.14)
C-----
C-----
END
SUBROUTINE ZEROS (K1,K2,IFD,F,N,NM,A,AA,M,E,L,C,D,BB,CC,CP,EVR,EVI
1,D1,D2,EPS,ITFX)
IMPLICIT REAL*8(A-H,C-Z)
DIMENSION A(N,N),AA(N,N),B(N,M),C(L,N),D(L,M),BE(N),CC(N),CP(N),EVR
1E(N),EVI(N),D1(N),D2(N)
DOUBLE PRECISION SCL,DABS
C-----OPGRAPH DATA-----
IF (ITFX.EQ.1) IFL = 10
IF (ITFX.EQ.2) IFL = 1
IF (ITFX.EQ.3) IFL = 4
C-----
DO 10 I=1,N
BB(I)=B(I,K1)
CC(I)=C(K2,I)
DO 10 J=1,N

```

```

1C  AA(I,J)=A(I,J)
    WRITE (6,9C) K1,K2
    IF (IFCFW.EQ.0) GO TO 20
    H=D(K2,K1)
    IF (DABS(H).LE.EPS) GO TO 20
    JJ=N
    GO TO 50
2C  AN=N-1
    DO 30 I=1,NN
    H=SCL(N,BB,CC)
    CALL CCOMP(N,NM,AA,CC,CP)
    IF (DABS(H).GT.EPS) GO TO 40
    CONTINUE
    H=SCL(N,BB,CC)
    WRITE (6,10C) H
    KK=ITFX
    WRITE (IFL,300) KK,K2,K1
    ORDER = C.O
    WRITE (IFL,301) CRDER,H
3C  GO TO 70
4C  JJ=N-1
5C  WRITE (6,11C) JJ,H
    KK=ITFX
    WRITE (IFL,300) KK,K2,K1
    ORDER = FLOAT(JJ)
    WRITE (IFL,301) CRDER,H
6C  CALL ACOMP(N,NM,AA,BB,CC,H)
    CALL BALANC(NM,N,AA,LOW,HIGH,D1)
    CALL ORTHES(NM,N,LOW,HIGH,AA,D2)
    CALL HQR(N,N,LOW,HIGH,AA,EVR,EVI,IERR)
    IF (IERR.NE.0) GO TO 80
    WRITE (6,12C)
    DC 60 I=1,N
    WRITE (6,13C) EVR(I),EVI(I)
7C  WRITE (IFL,302) K2,K1
    DC 53 LL=1,N
    WRITE (IFL,301) EVR(LL),EVI(LL)
8C  RETURN
    WRITE (5,14C)
    RETURN
9C  FORMAT (///,17H TF FOR INPUT NO.,I3,15H ANC CUTPUT NO.,I3,1H:)

```

```

100 FORMAT (//,5X,27HNO FINITE ZEROS, TF GAIN =,E12.4)
110 FORMAT (//,3X,20HORDER OF NUMERATOR =,I3,9X,9H TF GAIN =,E12.4)
120 FORMAT (//,3X,57HNUMERATOR EIGENVALUES (INCLUDING EXTRANEOUS ZERO V
121 VALUES):
130 FCRMAT (//,4X,1H(,F13.6,4H)+J(,F13.6,1H))
140 FCRMAT (52H FAILURE IN HQR CALCULATING TRANSFER FUNCTION ZERES)
C-----OPGRAPH DATA-----
300 FCRMAT(5X,215)
301 FCRMAT(5X,2130.14)
302 FCRMAT(5X,215)
C-----
C=====
SUBROUTINE ACOMP (N,NM,A,B,C,T)
REAL*8 A,B,C,T
DIMENSION A(NM,N),B(N),C(N)
DO 10 I=1,N
DO 10 J=1,N
A(I,J)=A(I,J)-B(I)*C(J)/H
10 RETURN
END
C=====
SUBROUTINE CCOMP (N,NM,A,C,CC)
REAL*8 A,C,CC
DIMENSION A(NM,N),C(N),CC(N)
DO 10 I=1,N
CC(I)=0
DO 10 J=1,N
CC(I)=CC(I)+C(J)*A(J,I)
10 CC(I)=CC(I)
20 RETURN
END
C=====
FUNCTION SCL (N,B,C)
REAL*8 B,C,CL
DIMENSION B(N),C(N)
SCL=0
DO 10 I=1,N
SCL=SCL+C(I)*B(I)
10 RETURN
END
C=====
SUBROUTINE RESID (K1,K2,N,JCF,M,BM,L,CM,PR,PI,RES,BB,CC,IPT)
IMPLICIT REAL*8(A-H,I-Z)
DIMENSION JCF(N),BM(N,M),CM(L,N),PR(N),PI(N),RES(N),BB(N),CC(N),PRPT
1T(4)
DATA SN/8H*5IN(B*T/,R1/8H */,R2/8HEXF(A*T/),5D/1H)/

```

```

C-----DATA ZERO/C,DO/,T1/4H*T**/,BLANK/8H-----OPT21610
C-----TEMPORARY MCD TILL JCF IS CALCULATED-----OPT21620
1C-----DC 10 I=1,N-----OPT21630
C-----JCF(I)=0-----OPT21640
C-----TEMPORARY MOD-----OPT21650
C-----IF (IPT,EC,1) WRITE (6,170)-----OPT21660
C-----DO 20 I=1,N-----OPT21670
C-----BB(I)=BM(I,K1)-----OPT21680
C-----CC(I)=CM(K2,I)-----OPT21690
C-----LOOP THROUGH THE POLES-----OPT21700
3C-----I=0-----OPT21710
C-----IF (I,GT,N) GO TO 160-----OPT21720
C-----IF (JCF(I),EQ,1) GO TO 60-----OPT21730
C-----IF (DABS(PI(I)),LT,10-D-10) GO TO 50-----OPT21740
C-----COMPUTE SIMPLE COMPLEX POLE RESIDUES AND PRINT BOTH-----OPT21750
C-----RES(I)=CC(I)*BB(I)+CC(I+1)*BB(I+1)-----OPT21760
C-----RES(I+1)=CC(I)*BB(I+1)-CC(I+1)*BB(I)-----OPT21770
C-----IF (IPT,EC,0) GO TO 40-----OPT21780
C-----PRT(I)=BLANK-----OPT21790
C-----PRT(2)=R2-----OPT21800
C-----IF (PI(I),EQ,0.00) PRT(2)=BLANK-----OPT21810
C-----PRT(3)=CS-----OPT21820
C-----PRT(4)=ED-----OPT21830
C-----WRITE (6,180) PR(I),PI(I),RES(I),(PRT(J),J=1,4)-----OPT21840
C-----I=I+1-----OPT21850
C-----PRT(3)=SN-----OPT21860
C-----WRITE (6,180) PR(I),PI(I),RES(I),(PRT(J),J=1,4)-----OPT21870
C-----GO TO 30-----OPT21880
4C-----I=I+1-----OPT21890
C-----GO TO 30-----OPT21900
5C-----CCONTINUE-----OPT21910
C-----COMPUTE SIMPLE REAL POLE RESIDUE-----OPT21920
C-----RES(I)=CC(I)*BB(I)-----OPT21930
C-----IF (IPT,EC,0) GO TO 30-----OPT21940
C-----PRT(1)=R1-----OPT21950
C-----PRT(2)=R2-----OPT21960
C-----PRT(3)=BLANK-----OPT21970
C-----PRT(4)=BLANK-----OPT21980
C-----WRITE (6,180) PR(I),PI(I),RES(I),(PRT(J),J=1,4)-----OPT21990
C-----GO TO 30-----OPT22000
C-----LOOK AHEAD TO DETERMINE SIZE OF THE JCRCAN BLOCK-----OPT22010
6C-----K=1-----OPT22020
C-----KT=N-I-----OPT22030
C-----DO 70 J=I,KT-----OPT22040
C-----IF (JCF(J),EQ,0) GO TO 80-----OPT22050
7C-----K=K+1-----OPT22060
C-----CCONTINUE-----OPT22070
C-----OPT22080

```

```

C-----
IF (DABS(PI(I)).LT. 1.D-10) GO TO 110
K=1
DO 130 J=I,KT
  RES(I)=CC(I)*BB(I)+CC(I+1)*BB(I+1)+CC(I+2)*BB(I+2)+CC(I+3)*BB(I+3)
  RES(I+1)=CC(I)*BB(I+1)-CC(I+1)*BB(I)+CC(I+2)*BB(I+3)-CC(I+3)*BB(I+2)
  RES(I+2)=CC(I)*BB(I+3)+CC(I+1)*BB(I+2)
  RES(I+3)=CC(I)*BB(I+2)-CC(I+1)*BB(I+3)
  IF (IPT.EQ. 0) GO TO 100
  PRT(1)=R1
  PRT(2)=R2
  IF (DABS(PR(I)).GT. 1.D-10) GO TO 90
  PRT(1)=BLANK
  PRT(2)=BLANK
  PRT(3)=CS
  PRT(4)=ED
  WRITE(6,18C) PR(I),PI(I),RES(I),(PRT(J),J=1,4)
  I=I+1
  WRITE(6,18C) PR(I),PI(I),RES(I),(PRT(J),J=1,4)
  PRT(1)=T1
  PRT(2)=R2
  IF (DABS(PR(I)).LT. 1.D-10) PRT(2)=BLANK
  PRT(3)=CS
  I=I+1
  WRITE(6,15C) PR(I),PI(I),RES(I),PRT(1),K,(PRT(J),J=2,4)
  PRT(3)=SN
  I=I+1
  WRITE(6,15C) PR(I),PI(I),RES(I),PRT(1),K,(PRT(J),J=2,4)
  GO TO 30
  I=I+3
  GO TO 30
C-----
110 COMPUTE REPEATED REAL PCLE RESIDUE AND PRINT CUT ALL K OF THEM-----
CONTINUE
KT=I+K-1
NN=0
DO 130 J=I,KT
  NN=NN+1
  RES(J)=ZERC
  CO 120 JJ=J,KT
  RES(J)=RES(J)+BB(J)*CC(JJ-NN+1)
CONTINUE
IF (IPT.EQ. 0) GO TO 150
NN=0
PRT(1)=T1
PRT(2)=R2
PRT(3)=BLANK
PRT(4)=BLANK

```

```

OPT222090
OPT222100
OPT222110
OPT222120
OPT222130
OPT222140
OPT222150
OPT222160
OPT222170
OPT222180
OPT222190
OPT222200
OPT222210
OPT222220
OPT222230
OPT222240
OPT222250
OPT222260
OPT222270
OPT222280
OPT222290
OPT222300
OPT222310
OPT222320
OPT222330
OPT222340
OPT222350
OPT222360
OPT222370
OPT222380
OPT222390
OPT222400
OPT222410
OPT222420
OPT222430
OPT222440
OPT222450
OPT222460
OPT222470
OPT222480
OPT222490
OPT222500
OPT222510
OPT222520
OPT222530
OPT222540
OPT222550
OPT222560

```

```

DC 140 J=I,KT
WRITE (6,I50) PR(J),PI(J),RES(J),PRT(1),NN,(PRT(JJ),JJ=2,4)
NN=NN+1
GO TO 30
150 I=KT
GO TO 30
160 CONTINUE
RETURN
C-----
170 FORMAT (//,3X,22RESIDUES AT THE POLES:/,T16,5HF 0 L E S,T41,15HR
1E S I C U E S//T9,7HR REAL(A),T26,7HIMAG(B))
180 FORMAT (//,4X,1H(,F13.6,4H)+J(,F13.6,1H),4X,1H(,F13.6,1H),3A8,A1)
190 FORMAT (//,4X,1H(,F13.6,4H)+J(,F13.6,1H),4X,1H(,F13.6,1H),A4,I2,2X,
12A8,A1)
END
C=====
SUBROUTINE BALANC (NM,N,A,LOW,IGH,SCALE)
INTEGER I,J,K,L,M,N,JJ,NM,IGH,LOW,IEXC
REAL*8 A(NM,N),SCALE(N)
REAL*8 C,F,G,R,S,B2,RADIX
LOGICAL NOCCNV
DATA RADIX/2421000CCCC000000/
C-----
B2=RADIX*RADIX
K=1
L=N
GO TO 60
C-----
1C SCALE(M)=J
IF (J.EQ.0) GO TO 40
DO 20 I=1,L
F=A(I,J)
A(I,J)=A(I,M)
A(I,M)=F
CONTINUE
DO 30 I=K,N
F=A(I,I)
A(J,I)=A(M,I)
A(M,I)=F
CONTINUE
GO TO (50,5C),IEXC
40 SEARCH FOR FOWS ISOLATING AN EIGENVALUE AND PUSH THEM DOWN-----
5C IF (L.EC.1) GO TO 230
L=L-1
DO 80 JJ=1,L
J=L+1-JJ
DO 70 I=1,L

```



```

7C      IF (I.EQ. J) GO TO 70
        IF (A(J,I).NE. 0.0D0) GO TO 80
        CONTINUE
        M=L
        IEXC=1
        GO TO 10
8C      CCNTINUE
        GO TO 100
        CC-----SEARCH FOR COLUMNS ISOLATING AN EIGENVALUE AND PUSH THEM LEFT-----
        SC      K=K+1
        IC      DO 120 J=K,L
        100     DO 110 I=K,L
        110     IF (I.EQ. J) GO TO 110
        110     IF (A(I,J).NE. 0.0D0) GO TO 120
        CCNTINUE
        M=K
        IEXC=2
        GO TO 10
12C      CCNTINUE
        CC-----NOW BALANCE THE SUBMATRIX IN ROWS K TO L-----
        12C      CO 130 I=K,L
        13C      SCALE(I)=1.0D0
        CC-----ITERATIVE LOOP FOR NORM REDUCTION-----
        14C      NOCONV=.FALSE.
        DO 220 I=K,L
        C=0.0D0
        R=0.0D0
        DO 150 J=K,L
        IF (J.EQ. I) GO TO 150
        C=C+DABS(A(J,I))
        R=R+DABS(A(I,J))
        CCNTINUE
15C      CC-----GUARD AGAINST ZERO C OR R DUE TO UNDERFLOW-----
        IF (C.EQ. 0.0D0 .OR. R.EQ. 0.0D0) GO TO 220
        G=P/RADIX
        F=1.0D0
        S=C+R
        16C      IF (C.GE. G) GO TO 170
        F=F*RADIX
        C=C*B2
        GO TO 160
        17C      G=R*RADIX
        18C      IF (C.LT. G) GO TO 190
        F=F/RADIX
        C=C/B2
        GO TO 180
        CC-----NOW BALANCE-----
        19C      IF ((C + R) / F .GE. 0.95D0 / S) GO TO 220

```

```

G=1.0D0/F
SCALE(I)=SCALE(I)*F
NCONV=.TRUE.
DO 200 J=K,N
  A(I,J)=A(I,J)*G
DO 210 J=1,I
  A(J,I)=A(J,I)*F
CONTINUE
IF (NCONV) GO TO 140
LCW=K
IGH=L
RETURN
END
=====
SUBROUTINE CRTHES (NM,N,LOW,IGH,A,ORT)
  INTEGER I,J,M,N,I1,JJ,LA,MP,NM,IGH,KP1,LCW
  REAL*8 A(NM,N),CRT(IGH)
  REAL*8 F,G,F,SCALE
  REAL*8 DSQRT,CABS,DSIGN
  LA=IGH-1
  KP1=LOW+1
  IF (LA.LT. KP1) GO TO 100
  DO 90 M=KP1,LA
    H=0.0D0
    CRT(M)=0.0D0
    SCALE=0.0D0
    SCALE COLUMN (ALGCL TOL THEN NOT NEEDED)
    DO 10 I=M,IGH
      F=SCALE+CABS(A(I,M-1))
      IF (SCALE .EQ. 0.0D0) GO TO 90
      MP=M+IGH
      DO 20 II=M,IGH
        I=MP-II
        CRT(I)=A(I,M-1)/SCALE
        H=H+ORT(I)*CRT(I)
      CONTINUE
      G=-DSIGN(DSQRT(H),CRT(M))
      F=H-ORT(M)*G
      CRT(M)=ORT(M)-G
      FORM (I-(U*UT)/H) * A
    DO 50 J=M,N
      F=0.0D0
      DO 30 II=M,IGH
        I=MP-II
        F=F+ORT(I)*A(I,J)
      CONTINUE
      F=F/H
      DO 40 I=M,IGH

```

```

4C      A(I,J)=A(I,J)-F*ORT(I)
5C      CONTINUE
C-----FORM (I-(U*UT)/H)*A*(I-(U*UT)/H)-----
C 80 I=1,IGH
F=0.0DC
C 60 JJ=M,IGH
J=MP-JJ
F=F+ORT(J)*A(I,J)
CONTINUE
F=F/H
C 70 J=M,IGH
A(I,J)=A(I,J)-F*ORT(J)
CONTINUE
C 8C CRT(M)=SCALE*ORT(M)
A(M,M-1)=SCALE*G
CONTINUE
RETURN
1C0 END
C=====
SUBROUTINE CRTRAN (NM,N,LOW,IGH,A,ORT,Z)
INTEGER I,J,N,KL,MM,MP,NM,IGH,LOW,MP1
REAL*8 A(NM,IGH),ORT(IGH),Z(NM,N)
REAL*8 G
C-----INITIALIZE Z TO IDENTITY MATRIX-----
DO 20 I=1,N
DO 10 J=1,N
Z(I,J)=0.0DC
Z(I,I)=1.0DC
CONTINUE
KL=IGH-LOW-1
IF (KL.LT.1) GO TO 80
DO 70 MM=1,KL
MP=IGH-MM
MP1=MP+1
IF (A(MP,MP-1) .EQ. 0.0DC) GO TO 70
MP1=MP+1
DO 30 I=MP1,IGH
CRT(I)=A(I,MP-1)
C 60 J=MP,IGH
G=0.0DC
DO 40 I=MP,IGH
G=G+ORT(I)*Z(I,J)
C-----DIVISOR BELOW IS NEGATIVE OF H FORMED IN ORTHES.-----
G=(G / ORT(MP))/A(MP,MP-1)
C 50 Z(I,J)=Z(I,J)+G*ORT(I)
CONTINUE
C 6C
7C
OPT2401C
OPT2402C
OPT2403C
OPT2404C
OPT2405C
OPT2406C
OPT2407C
OPT2408C
OPT2409C
OPT2410C
OPT2411C
OPT2412C
OPT2413C
OPT2414C
OPT2415C
OPT2416C
OPT2417C
OPT2418C
OPT2419C
OPT2420C
OPT2421C
OPT2422C
OPT2423C
OPT2424C
OPT2425C
OPT2426C
OPT2427C
OPT2428C
OPT2429C
OPT2430C
OPT2431C
OPT2432C
OPT2433C
OPT2434C
OPT2435C
OPT2436C
OPT2437C
OPT2438C
OPT2439C
OPT2440C
OPT2441C
OPT2442C
OPT2443C
OPT2444C
OPT2445C
OPT2446C
OPT2447C
OPT2448C

```



```

IF (L.EQ. EN) GO TC 220
Y=H(NA,NA)
W=H(EN,NA)*F(NA,EN)
IF (L.EQ. NA) GO TC 230
IF (ITS.EC. 30) GO TO 500
IF (ITS.NE. 10) AND (ITS.NE. 20) GO TO 80
C-----FORM EXCEPTIONAL SHIFT-----
T=T+X
DO 70 I=LOW,EN
H(I,I)=H(I,I)-X
S=DABS(H(EN,NA))+DABS(H(NA,ENM2))
X=0.75DO*S
Y=X
W=-0.4375DC*S*S
ITS=ITS+1
C-----LOOK FOR TWO CONSECUTIVE SMALL SUB-DIAGONAL ELEMENTS.-----
DO 90 MM=L,ENM2
M=ENM2+L-MM
ZZ=H(M,M)
R=X-ZZ
S=Y-ZZ
P=(R#S-W)/H(M+1,M)+H(M,M+1)
Q=H(M+1,M+1)-ZZ-R-S
R=H(M+2,M+1)
S=DABS(P)+DABS(Q)+DABS(R)
P=P/S
Q=Q/S
R=R/S
IF (M.EQ. 1) GO TO 100
IF (DABS(H(M,M-1))* (DABS(Q) + DABS(R)) .LE. MACHEP * DABS(P)
1 * (DABS(H(M-1,M-1)) + DABS(ZZ) + DABS(H(M+1,M+1)))) GO TO 100
SC
100
C-----CONTINUE
MP2=M+2
DO 110 I=MF2,EN
P(I,I-2)=0.CD0
IF (I.EQ. MP2) GO TC 110
H(I,I-3)=0.CD0
C-----CONTINUE
110
C-----DOUBLE CR STEP INVOLVING ROWS L TO EN AND COLUMNS M TO EN-----
DO 210 K=M,NA
NOTLAS=K.NE.NA
IF (K.EQ. P) GO TC 120
P=H(K,K-1)
Q=H(K+1,K-1)
R=0.CD0
IF (NOTLAS) R=H(K+2,K-1)
X=DABS(P)+DABS(Q)+DABS(R)
IF (X.EQ. (CD0)) GO TO 210

```

OPT24970
 OPT24980
 OPT24990
 OPT25000
 OPT25010
 OPT25020
 OPT25030
 OPT25040
 OPT25050
 OPT25060
 OPT25070
 OPT25080
 OPT25090
 OPT25100
 OPT25110
 OPT25120
 OPT25130
 OPT25140
 OPT25150
 OPT25160
 OPT25170
 OPT25180
 OPT25190
 OPT25200
 OPT25210
 OPT25220
 OPT25230
 OPT25240
 OPT25250
 OPT25260
 OPT25270
 OPT25280
 OPT25290
 OPT25300
 OPT25310
 OPT25320
 OPT25330
 OPT25340
 OPT25350
 OPT25360
 OPT25370
 OPT25380
 OPT25390
 OPT25400
 OPT25410
 OPT25420
 OPT25430
 OPT25440

```

P=P/X
Q=Q/X
R=R/X
S=DSIGN(DSCRT(P*P+Q*(R*R),P)
IF (K.EC.N) GC TC 130
H(K,K-1)=-S*X
GC TO 140
IF (L.NE.M) H(K,K-1)=-H(K,K-1)
P=P+S
X=P/S
Y=Q/S
ZZ=R/S
Q=Q/P
R=R/P
C-----ROW MODIFICATION-----
DO 160 J=K,N
P=H(K,J)+Q*(K+1,J)
IF (.NOT. NCTLAS) GO TC 150
P=P+R*H(K+2,J)
H(K+2,J)=H(K+2,J)-P*ZZ
H(K+1,J)=H(K+1,J)-P*Y
H(K,J)=H(K,J)-P*X
CCNT INUE
J=MINO(EN,K+3)
C-----COLUMN MODIFICATION-----
DO 180 I=1,J
P=X*H(I,K)+Y*H(I,K+1)
IF (.NOT. NCTLAS) GO TO 170
P=P+ZZ*H(I,K+2)
H(I,K+2)=H(I,K+2)-P*R
H(I,K+1)=H(I,K+1)-P*C
H(I,K)=H(I,K)-P
CCNT INUE
C-----ACCUMULATE TRANSFORMATIONS-----
DO 200 I=LCH,IGH
P=X*Z(I,K)+Y*Z(I,K+1)
IF (.NOT. NCTLAS) GC TO 190
P=P+ZZ*Z(I,K+2)
Z(I,K+2)=Z(I,K+2)-P*R
Z(I,K+1)=Z(I,K+1)-P*C
Z(I,K)=Z(I,K)-P
CCNT INUE
GO TO 40
C-----ONE ROOT FOUND-----
220 H(EN,EN)=X+7
WR(EN)=H(EN,EN)
WI(EN)=2.0CC

```

```

EN=NA
GO TO 30
C-----TWO ROOTS FOUND-----
230  P=(Y - X)/2.0D0
      C=P*P+W
      ZZ=DSQRT(DABS(Q))
      H(EN,EN)=X+Y
      X=H(EN,EN)
      H(NA,NA)=Y+T
      IF (Q .LT. C.0D0) GO TO 270
C-----REAL PAIR-----
      ZZ=P+DSIGN(ZZ,P)
      WR(NA)=X+ZZ
      WR(EN)=WR(NA)
      IF (ZZ .NE. C.0D0) WR(EN)=X-W/ZZ
      WI(NA)=0.0CC
      WI(EN)=0.0CC
      X=H(EN,NA)
      S=DABS(X)+[ABS(ZZ)
      P=X/S
      Q=ZZ/S
      R=DSQRT(P*F+Q*Q)
      P=P/R
      C=Q/R
C-----ROW MODIFICATION-----
      DO 240 J=NA,N
      ZZ=H(NA,J)
      H(NA,J)=Q*ZZ+P*H(EN,J)
      H(EN,J)=Q*F(EN,J)-P*ZZ
      CONTINUE
240  C-----COLUMN MODIFICATION-----
      DO 250 I=1,EN
      ZZ=H(I,NA)
      H(I,NA)=Q*ZZ+P*H(I,EN)
      H(I,EN)=Q*F(I,EN)-P*ZZ
      CONTINUE
250  C-----ACCUMULATE TRANSFORMATIONS-----
      DO 260 I=LCh,IGH
      ZZ=Z(I,NA)
      Z(I,NA)=Q*ZZ+P*Z(I,EN)
      Z(I,EN)=Q*Z(I,EN)-P*ZZ
      CONTINUE
      GC TO 280
260  C-----COMPLEX PAIR-----
      WR(NA)=X+P
      WR(EN)=X+P
      WI(NA)=ZZ
      WI(EN)=-ZZ
270

```

OPT25930
OPT25940
OPT25950
OPT25960
OPT25970
OPT25980
OPT25990
OPT26000
OPT26010
OPT26020
OPT26030
OPT26040
OPT26050
OPT26060
OPT26070
OPT26080
OPT26090
OPT26100
OPT26110
OPT26120
OPT26130
OPT26140
OPT26150
OPT26160
OPT26170
OPT26180
OPT26190
OPT26200
OPT26210
OPT26220
OPT26230
OPT26240
OPT26250
OPT26260
OPT26270
OPT26280
OPT26290
OPT26300
OPT26310
OPT26320
OPT26330
OPT26340
OPT26350
OPT26360
OPT26370
OPT26380
OPT26390
OPT26400

```

28C      EN=ENM2
C      GO TO 30
C-----ALL ROOTS FOUND. BACKSUBSTITUTE TO FIND-----
C-----VECTORS OF UPPER TRIANGULAR FORM-----
29C      IF (NORM.EC.C.OOD) GO TO 510
C      DO 450 NN=1,N
C      EN=N+1-NN
C      P=WR(EN)
C      Q=WI(EN)
C      NA=EN-1
C      IF (Q) 370,300,450
C-----REAL VECTOR-----
30C      M=EN
C      H(EN,EN)=1.CDO
C      IF (NA.EQ.Q) GO TO 450
C      DO 360 II=1,NA
C      I=EN-II
C      W=H(I,I)-P
C      R=H(I,EN)
C      IF (M.GT.NA) GO TO 320
C      DO 310 J=M,NA
C      R=P+H(I,J)*F(J,EN)
31C      IF (WI(I).GE.Q.OOD) GO TO 330
32C      ZZ=W
C      S=R
C      GO TO 360
C      M=I
C      IF (WI(I).NE.Q.OOD) GO TO 340
C      T=W
C      IF (W.EQ.C.OOD) T=MACHEP*NORM
C      H(I,EN)=R/T
C      GO TO 360
C-----SOLVE REAL EQUATIONS-----
33C      X=H(I,I+1)
C      Y=H(I+1,I)
C      C=(WR(I)-P)+WI(I)*WI(I)
C      T=(X*S-ZZ*R)/Q
C      H(I,EN)=T
C      IF (DABS(X).LE.DABS(ZZ)) GO TO 350
C      H(I+1,EN)=(-R-W*T)/X
C      GO TO 360
35C      H(I+1,EN)=(-S-Y*T)/ZZ
36C      CONTINUE
C-----END REAL VECTOR-----
C      GO TO 450
C-----COMPLEX VECTOR-----
37C      M=NA
C-----LAST VECTOR COMPONENT CHOSEN IMAGINARY SC THAT-----
OPT26410
OPT26420
OPT26430
OPT26440
OPT26450
OPT26460
OPT26470
OPT26480
OPT26490
OPT26500
OPT26510
OPT26520
OPT26530
OPT26540
OPT26550
OPT26560
OPT26570
OPT26580
OPT26590
OPT26600
OPT26610
OPT26620
OPT26630
OPT26640
OPT26650
OPT26660
OPT26670
OPT26680
OPT26690
OPT26700
OPT26710
OPT26720
OPT26730
OPT26740
OPT26750
OPT26760
OPT26770
OPT26780
OPT26790
OPT26800
OPT26810
OPT26820
OPT26830
OPT26840
OPT26850
OPT26860
OPT26870
OPT26880

```



```

C-----EIGENVECTR MATRIX IS TRIANGULAR-----
IF (DABS(H(EN,NA))) .LE. DABS(H(NA,EN))) GC TC 380
H(NA,NA)=Q/F(EN,NA)
H(NA,EN)=-(F(EN,EN) - P)/H(EN,NA)
GO TO 390
380 Z3=DCMPLX(C.ODO,-H(NA,EN))/DCMPLX(H(NA,NA)-P,Q)
H(NA,NA)=DREAL(Z3)
H(NA,EN)=DIMAG(Z3)
390 H(EN,NA)=C.ODO
H(EN,EN)=1.CDO
ENM2=NA-1
IF (ENM2 .EQ. 0) GC TO 450
GO 440 I=1,ENM2
I=NA-I
P=H(I,I)-P
RA=O.ODO
SA=H(I,EN)
DO 400 J=M,NA
RA=RA+H(I,J)*H(J,NA)
SA=SA+H(I,J)*H(J,EN)
CNT INUE
400 IF (WI(I) .GE. O.ODO) GO TO 410
ZZ=W
R=RA
S=SA
GO TO 440
410 M=I
IF (WI(I) .NE. C.ODO) GO TO 420
Z3=DCMPLX(-RA,-SA)/DCMPLX(W,Q)
H(I,NA)=DREAL(Z3)
H(I,EN)=DIMAG(Z3)
GO TO 440
C-----SOLVE COMPLEX EQUATIONS-----
420 X=H(I,I+1)
Y=H(I+1,I)
VR=(WR(I) - P)*(WR(I) - P)+WI(I)*WI(I)-Q*Q
VI=(WR(I) - P)*2.ODO*Q
IF (VR .EQ. O.ODO .AND. VI .EQ. O.ODO) VR=MACFEP*NORM*(DABS(W) +
1ABS(Q) + DABS(X) + DABS(Y) + DABS(Z3))
Z3=DCMPLX(X*VR-Z3*RA+Q*SA,X*S-Z3*SA-Q*RA)/DCMPLX(VR,VI)
H(I,NA)=DREAL(Z3)
H(I,EN)=DIMAG(Z3)
IF (DABS(X) .LE. DABS(Z3) + DABS(Q)) GO TO 430
H(I+1,NA)=(-RA - W * H(I,NA) + Q * H(I,EN))/X
H(I+1,EN)=(-SA - W * H(I,EN) - Q * H(I,NA))/X
GO TO 440
430 Z3=DCMPLX(-R-Y*H(I,NA)-S-Y*H(I,EN))/DCMPLX(Z3,C)
H(I+1,NA)=DREAL(Z3)

```

```

440 H(I+1,EN)=C*IMAG(Z3)
C CONTINUE
450 CONTINUE-----END COMPLEX VECTOR-----
C-----
C-----END BACK SUBSTITUTION. VECTORS OF ISOLATED ROOTS-----
DO 470 I=1,N
IF (I.EQ. LOW .AND. I .LE. IGH) GO TO 470
CC 460 J=I,N
Z(I,J)=H(I,J)
460 CONTINUE
470 CONTINUE-----MULTIPLY BY TRANSFORMATION MATRIX TO GIVE-----
C-----VECTORS OF ORIGINAL FULL MATRIX.-----
DO 490 JJ=LCH,N
J=N+LOW-JJ
M=MINO(J,I,IGH)
DO 490 I=LCH,IGH
ZZ=0.000
CC 480 K=LCH,M
ZZ=ZZ+Z(I,K)*H(K,J)
480 Z(I,J)=ZZ
490 CONTINUE
GO TO 510
C-----SET ERROR --->NO CONVERGENCE TO AN-----
C-----EIGENVALUE AFTER 30 ITERATIONS-----
CC IERR=EN
510 RETURN
C-----
C-----
C-----SUBROUTINE BALBAK (N,N,LOW,IGH,SCALE,M,Z)
INTEGER I,J,K,M,N,II,NM,IGH,LCW
REAL*8 SCALE(N),Z(NM,M),S
IF (M.EQ.0) GO TO 60
IF (IGH.EQ. LOW) GO TO 30
CC 20 I=LCH,IGH
S=SCALE(I)
C-----LEFT HAND EIGENVECTORS ARE BACK TRANSFORMED-----
C-----IF THE FORGECING STATEMENT IS REPLACED BY-----
C-----S=1.000/SCALE(I).-----
CC 10 J=1,M
Z(I,J)=Z(I,J)*S
CC CONTINUE
CC 50 II=1,N
I=II
IF (I.EQ. LOW .AND. I .LE. IGH) GO TO 50
IF (I.LT. LOW) I=LCH-II
K=SCALE(I)
IF (K.EQ.0) GO TO 50
CC 40 J=1,M

```

```

S=Z(I,J)
Z(I,J)=Z(K,J)
Z(K,J)=S
CCONTINUE
RETURN
END
=====
SUBROUTINE FOR (NM,N,LOW,IGH,H,WR,WI,IERR)
INTEGER I,J,K,L,M,N,EN,LL,MM,NA,NM,IGH,ITS,LCW,MP2,ENM2,IERR
REAL*8 H(NM,N),WR(N),WI(N)
REAL*8 P,Q,F,S,T,W,X,Y,ZZ,NORM,MACHEP
REAL*8 DSQRT,DABS,DSIGN
INTEGER MIND
LOGICAL NOTLAS
DATA MACHEP/Z3410000C00000000/
IERR=0
NORM=0.0D0
K=1
C-----STORE RCCTS ISOLATED BY BALANC AND COMPUTE MATRIX NORM-----
DO 20 I=1,N
DO 10 J=K,N
NORM=NORM+ABS(H(I,J))
K=I
IF (I.GE. LCW .AND. I.LE. IGH) GO TO 20
WR(I)=H(I,I)
WI(I)=0.0D0
CONTINUE
EN=IGH
T=0.0D0
C-----SEARCH FOR NEXT EIGENVALUES-----
IF (EN.LT. LOW) GO TO 250
ITS=0
NA=EN-1
ENM2=NA-1
C-----LOCK FOR SINGLE SMALL SUR-DIAGONAL ELEMENT-----
DO 50 LL=LCW,EN
L=EN+LCW-LL
IF (L.EQ. LCW) GO TO 60
S=DABS(H(L-1,L-1))+DABS(H(L,L))
IF (S.EQ. C.0D0) S=NORM
IF (DABS(H(L,L-1)).LE. MACHEP * S) GO TO 60
CONTINUE
C-----FORM SHIFT-----
X=H(EN,EN)
IF (L.EC. EN) GO TO 200
Y=H(NA,NA)
W=H(EN,NA)*F(NA,EN)

```

```

IF (L .EQ. NA) GO TO 210
IF (ITS .EQ. 30) GO TO 240
IF (ITS .NE. 10 .AND. ITS .NE. 20) GO TO 80
-----FORM EXCEPTIONAL SHIFT-----
T=T+X
DO 70 I=LQ,EN
  F(I,I)=H(I,I)-X
  S=DABS(H(EK,NA))+DABS(H(NA,ENM2))
  X=X+.75DO*S
  Y=X
  W=-O.4375DO*S*S
  ITS=ITS+1
-----LOOK FOR TWO CONSECUTIVE SMALL SUB-DIAGONAL ELEMENTS.-----
DO 90 MM=L,ENM2
  M=ENM2+L-MM
  ZZ=H(M,M)
  R=X-ZZ
  S=Y-ZZ
  P=(R+M+1,M+1)/H(M+1,M)+H(M,M+1)
  Q=H(M+1,M+1)-ZZ-R-S
  R=H(M+2,M+1)
  S=DABS(P)+DABS(Q)+DABS(R)
  P=P/S
  Q=Q/S
  R=R/S
IF (M .EQ. L) GO TO 100
IF (DABS(H(M,M-1)) * (DABS(Q) + DABS(R)) .LE. MACHEP * DABS(P))
  1 * (DABS(H(M-1,M-1)) + DABS(ZZ) + DABS(H(M+1,M+1))) GO TO 100
CONTINUE
MP2=M+2
DO 110 I=MP2,EN
  F(I,I-2)=O.(DO
  IF (I .EQ. MP2) GO TO 110
  F(I,I-3)=C.(DO
  CONTINUE
OR STEP INVOLVING ROWS L TC EN AND COLUMNS M TO EN-----
DO 190 K=M,NA
  NCTLAS=K.NE.NA
  IF (K .EQ. N) GO TO 120
  P=H(K,K-1)
  Q=H(K+1,K-1)
  R=O.ODO
  IF (NOTLAS) R=H(K+2,K-1)
  X=DABS(P)+DABS(Q)+DABS(R)
  IF (X .EQ. C.OOO) GO TO 190
  P=P/X
  Q=Q/X
  R=R/X

```

OPT28330
OPT28340
OPT28350
OPT28360
OPT28370
OPT28380
OPT28390
OPT28400
OPT28410
OPT28420
OPT28430
OPT28440
OPT28450
OPT28460
OPT28470
OPT28480
OPT28490
OPT28500
OPT28510
OPT28520
OPT28530
OPT28540
OPT28550
OPT28560
OPT28570
OPT28580
OPT28590
OPT28600
OPT28610
OPT28620
OPT28630
OPT28640
OPT28650
OPT28660
OPT28670
OPT28680
OPT28690
OPT28700
OPT28710
OPT28720
OPT28730
OPT28740
OPT28750
OPT28760
OPT28770
OPT28780
OPT28790
OPT28800

```

120 S=DSIGN(DSCRT(P*P+Q*C+R*R),P)
    IF (K.EQ.M) GO TO 130
    H(K,K-1)=-S*X
    GO TO 140
130 IF (L.NE.M) H(K,K-1)=-H(K,K-1)
140 P=P+S
    X=P/S
    Y=Q/S
    ZZ=R/S
    Q=Q/P
    R=R/P
C-----ROW MODIFICATION-----
DO 160 J=K,EN
P=H(K,J)+C*F(K+1,J)
IF (.NOT. NCTLAS) GO TO 150
P=P+R*H(K+2,J)
H(K+2,J)=H(K+2,J)-P*ZZ
H(K+1,J)=F(K+1,J)-P*Y
H(K,J)=H(K,J)-P*X
CCNT INUE
J=MINO(EN,K+3)
C-----COLUMN MODIFICATION-----
DO 180 I=L,J
P=X*H(I,K)+Y*H(I,K+1)
IF (.NOT. NCTLAS) GO TO 170
P=P+ZZ*H(I,K+2)
H(I,K+2)=H(I,K+2)-P*R
H(I,K+1)=H(I,K+1)-P*C
H(I,K)=H(I,K)-P
CCNT INUE
GO TO 40
170 WR(EN)=X+T
180 WI(EN)=O.OCC
190 EN=NA
    GO TO 30
C-----ONE ROOT FOUND-----
200 P=(Y - X)/2.OOO
    C=P*P+Q
    ZZ=DSQRT(DABS(Q))
    X=X+T
    IF (Q.LT.C.OOO) GO TO 220
C-----TWO ROOTS FOUND-----
210 ZZ=P+DSIGN(ZZ,P)
    WR(NA)=X+ZZ
    WR(EN)=WR(NA)
    IF (ZZ.NE.C.OOO) WR(EN)=X-W/ZZ
C-----REAL PAIR-----

```

OPT28810
 OPT28820
 OPT28830
 OPT28840
 OPT28850
 OPT28860
 OPT28870
 OPT28880
 OPT28890
 OPT28900
 OPT28910
 OPT28920
 OPT28930
 OPT28940
 OPT28950
 OPT28960
 OPT28970
 OPT28980
 OPT28990
 OPT29000
 OPT29010
 OPT29020
 OPT29030
 OPT29040
 OPT29050
 OPT29060
 OPT29070
 OPT29080
 OPT29090
 OPT29100
 OPT29110
 OPT29120
 OPT29130
 OPT29140
 OPT29150
 OPT29160
 OPT29170
 OPT29180
 OPT29190
 OPT29200
 OPT29210
 OPT29220
 OPT29230
 OPT29240
 OPT29250
 OPT29260
 OPT29270
 OPT29280

```

WI(NA)=0.0DC
WI(EN)=0.0DC
GC TO 230
-----COMPLEX PAIR-----
220 WR(NA)=X+P
    WR(EN)=X+P
    WI(NA)=ZZ
    WI(EN)=ZZ
    EN=ENM2
    GC TO 30
230
-----SET ERROR --- NO CONVERGENCE TO AN-----
    EIGENVALUE AFTER 30 ITERATIONS-----
240 IERR=EN
250 RETURN
    END
C=====
SUBROUTINE PSDCAL (N2,NS,FA,X,NC,GW,GV,C,AC,HY,HU,H,
1 FBGE,NG,GAM,ACL,F,WR,WI,D1,D2,JCF,RES,G,R,EP,CC,IYU,
2 IPSD,INORM)
C=====
PSDCAL COMPUTES THE PSD OF OUTPUTS OR CONTROLS OF
A CONTROLLED SYSTEM
C=====
IYU= 1      CUTPUT PSD
      = 2    CONTROL PSD
      = 3    BOTH OUTPUT AND CONTROL PSD
IPSD= 1      PSD
      = 2    PSD AND TF RESIDUES
INORM= 1,2,... NG NORMALIZED BY ITH PROCESS NOISE
      = 1,... NG+NG NORMALIZED BY ITH MEAS NOISE
C=====
DOUBLE PRECISION FA,X,GW,GV,C,HY,H,FBGE,GAM,ACL,F,WR,WI,D1,D2,RES,
188,CC,C,R,PSD,W,DNORM,DN1,EMAX,ELOG,EMOD,CH,ST,CM,RE,AI,HU,DW1
C=====
COMPLEX X*16D,ZN,ZZ
DIMENSION FA(N2,N2),X(N2,N2),GW(N2,NG),C(NC,NS),HY(NC,N2),H(NC,NS),
1 FBGE(NS,NC),GAM(NS,NG),ACL(NS,NS),F(NS,NS),WF(N2),D1(N2),D2(N2),
22(N2),RES(N2),QING,NG1,R(NC,NC),PSD(30),W(30),BE(N2),CC(N2),GV(N2),
3NOI,HU(NC,N2),DW1(4)
INTEGER JCF(N2)
DATA DW1/1.0,2.0,5.0,10.0/
IF (IYU.EC.0) IYU=1
IF (INORM.EQ.0) INORM=1
IPT=0
IF (IPSD.EC.1) IPT=1
IF (INORM.NG

```

```

IF (IX .GT. 0) WRITE (6,330) IX
IF (IX .LE. 0) WRITE (6,340) INORM
NSQ=N2#N2
C----- COMPUTE EIGENSYSTEM OF CONTROLLED SYSTEM; FCRM FA-----
DO 10 I=1,NS
DO 10 J=1,NS
FA(I,J)=ACL(I,J)
FA(NS+I,J)=C.D0
DC 30 I=1,NS
DC 30 J=1,NS
ST=0.D0
DO 20 K=1,NC
ST=ST+FBGE(I,K)*H(K,J)
FA(I,NS+J)=-ST
FA(NS+I,NS+J)=F(I,J)-ST
CALL RAPRNT (N2,N2,N2,9,FA,4,'(9(IX,1PD13.6))')
C----- DEBUG ABOVE-----
CALL BALANC (N2,N2,FA,LCW,IHIGH,D1)
CALL ORTHES (N2,N2,LCW,IHIGH,FA,D2)
CALL ORTRAN (N2,N2,LCW,IHIGH,FA,D2,X)
CALL HQR2 (N2,N2,LOW,IHIGH,FA,WR,WI,X,IERR)
IF (IERR .NE. 0) GO TO 320
CALL BALBAK (N2,N2,LCW,IHIGH,D1,N2,X)
CALL RAPRNT (N2,N2,N2,5,X,4,'(9(IX,1PD13.6))')
C----- DEBUG ABOVE; DETERMINE MODAL MATRICES-----
IF (IYU .EC. 1) GO TO 60
C----- HSUBU-----
DO 50 I=1,NC
DO 50 J=1,N2
ST=0.D0
DO 40 K=1,NS
ST=ST-C(I,K)*X(K,J)
HU(I,J)=ST
GO TO 90
C----- HSUBY-----
DO 80 I=1,NC
DO 80 J=1,N2
ST=0.D0
DO 70 K=1,NS
ST=ST+H(I,K)*X(K,J)-H(I,K)*X(NS+K,J)
HY(I,J)=ST
CALL RAPRNT (NO,NC,N2,9,HY,4,'(9(IX,1PD13.6))')
C----- DEBUG ABOVE-----
CALL MINV (NSC,X,N2,ST,D1,D2)
CALL RAPRNT (N2,N2,N2,5,X,4,'(9(IX,1PD13.6))')
C----- DEBUG ABOVE-----
DC 110 I=1,N2

```

```

OPT29770
OPT29780
OPT29790
OPT29800
OPT29810
OPT29820
OPT29830
OPT29840
OPT29850
OPT29860
OPT29870
OPT29880
OPT29890
OPT29900
OPT29910
OPT29920
OPT29930
OPT29940
OPT29950
OPT29960
OPT29970
OPT29980
OPT30000
OPT30010
OPT30020
OPT30030
OPT30040
OPT30050
OPT30060
OPT30070
OPT30080
OPT30090
OPT30100
OPT30110
OPT30120
OPT30130
OPT30140
OPT30150
OPT30160
OPT30170
OPT30180
OPT30190
OPT30200
OPT30210
OPT30220
OPT30230
OPT30240

```

```

100 CC 110 J=1,NG
110 ST=0.000
    DO 100 K=1,NS
    GW(I,J)=ST
    CALL RAPRNT (N2,N2,NG,9,GW,4,'(9(IX,1PD13,6))')
C-----
    IF (INORM .LE. NG) DNORM=1.00/0.00(INORM,INORM)
    IF (INORM .GT. NG) DNORM=1.00/R(INORM-NG,INORM-NG)
C-----
    EMAX=0.00
    DO 120 I=1,N2
    EMOD=DABS(WF(I)*2 +WI(I)*2)
    IF (EMOD .GT. EMAX) EMAX=EMOD
120 CCNT INUE
    EMOD=DSORT(EMAX)
    EMOD=2*EMOD
C-----
    ROUND UP TO NEAREST 2,4,5,8,10
    ELOG=DLOG10(EMOD)
    IF (ELOG .LT. 0.00) IPOW=-IDINT(DABS(ELOG) + 1)
    IF (ELOG .GE. 0.00) IPOW=IDINT(ELOG)
    EMAX=EMOD*10**(-IPOW)
    IF (EMAX .GT. 2.00) EMOD=2.00
    IF (EMAX .GT. 4.00) EMOD=4.00
    IF (EMAX .GT. 5.00) EMOD=5.00
    IF (EMAX .GT. 8.00) EMOD=8.00
    IF (EMAX .GE. 10.00) EMOD=10.00
    EMAX=EMOD*10**IPOW
    CW=EMAX/20.00
C-----
    IF (EMOD .LT. 5.0) GC TO 130
    EMAX=1.001
    IK=3
    GC TO 140
    EMAX=5.00
    IK=2
130 CCNT INUE
140 C-----
    STORE 30 FREQUENCIES
    DO 150 I=1,20
    W(I)=DW*(I-1)
    DO 160 J=1,3
    IP=20+2*(I-1)
    CG 160 J=1,3
    IX=MOD(IK+J-1,2)+1
    JJ=0
    IF (IK .EQ. 2 .AND. J .GE. 2) JJ=1
    W(IP+JJ)=DW*(IX)*10**J*(IPOW+I-1+JJ+IK-2)
150 CCNT INUE
160

```



```

IX=MOD(IK,2)+1
W(30)=DW1(I)*10**(I*POW+3 +IK-2)
C-----LARGE LOOP THRU OUTPUTS-----
IF (IYU.EQ.1) NL=NC
IF (IYU.EQ.2) NL=NC
DO 310 I=1,NL
DO 170 I=1,20
PSD(I)=0.D0
C-----LCCP THRU PROCESS NOISE-----
DO 220 I=1,NG
CNI=DNCRM*(I,I)
IF (IYU.EQ.1) AND. IPT.EQ.1) WRITE (6,350) I,L
IF (IYU.EQ.2) AND. IPT.EQ.1) WRITE (6,360) I,L
IF (IYU.EQ.1) CALL RESID (I,L,N2,JCF,NG,GW,NL,HY,WR,WI,
1RES,BB,CC,IPT)
IF (IYU.EQ.2) CALL RESID (I,L,N2,JCF,NG,GW,NL,HU,WR,WI,
1RES,BB,CC,IPT)
DO 210 K=1,20
ZZ=DCMPLX(0.D0,0.D0)
OW=W(K)
DO 200 I=1,N2
IF (WI(I)) 200,180,190
ZZ=DCMPLX(-WR(I),OW-WI(I))
ZZ=RES(I)/ZZ+ZZ
GO TO 200
RE=WR(I)
AI=WI(I)
ZZ=DCMPLX(RES**2 + AI**2 - OW**2 - 2.D0*RE*CM)
ZN=DCMPLX(RES(I+1)*AI-RES(I)*RE,RES(I)*CM)
ZZ=ZZ+ZN/ZZ
CCNT INUE
PSD(K)=PSD(K)+DN1*(ZZ*DCONJG(ZZ))
CCNT INUE
C-----GSUBV-----
DO 240 I=1,N2
DO 240 J=1,NC
ST=0.D0
DO 230 K=1,NS
ST=ST+X(I,K)*FBGE(K,J)+X(I,NS+K)*FBGE(K,J)
GV(I,J)=ST
CALL RAPRNT (N2,N2,NC,9,GV,4,'(9(IX,IPD13.6))')
C-----DEBUG ABOVE, LOOP THRU MEAS NOISE-----
DO 300 I=1,NC
CNI=DNCRM*(I,I)
IF (IYU.EQ.1) AND. IPT.EQ.1) WRITE (6,370) I,L
IF (IYU.EQ.2) AND. IPT.EQ.1) WRITE (6,380) I,L
IF (IYU.EQ.1) CALL RESID (I,L,N2,JCF,NG,GV,NL,HY,WR,WI,RES,
1BB,CC,IPT)

```

```

      IF (IYU.EQ.2) CALL RESID (I,L,N2,JCF,NO,GV,NL,HU,WR,WI,RES,
1    BB,CC,IFT)
      DO 290 K=1,30
      ZZ=DCMPLX(C.DC,0.D0)
      CM=W(K)
      DO 270 I=1,N2
      IF (WI(I)) Z7C,Z5C,26C
      ZD=DCMPLX(-WR(I),OM-WI(I))
      ZZ=ZZ+RES(I)/ZD
      GO TO 270
      RE=WR(I)
      AI=WI(I)
      ZC=DCMPLX(RE**2 + AI**2 -OM**2,-2.D0*RE*OM)
      ZN=DCMPLX(RES(I+1)*AI-RES(I)*RE,RES(I)*CM)
      ZZ=ZZ+ZN/ZC
      CCNTINUE
      IF (IYU.EC.2.OR. I.NE. L) GO TC 280
      PSD(K)=PSD(K)+DNI
      CCNTINUE
      IF (IYU.EC.1) WRITE (6,390) L
      IF (IYU.EC.2) WRITE (6,400) L
      WRITE (6,410) (W(I),PSD(I),I=1,30)
      CCNTINUE
      RETURN
      CALL EXEXIT (N2,FA,IERR)
      RETURN
-----
      FORMAT (/,4F SUBSEQUENT PSD IS NORMALIZED BY MEAS NO.,I3,/)
      FORMAT (/,50F SUBSEQUENT PSD IS NORMALIZED BY PROCESS NOISE NC.,I3
1,/)
      FORMAT (/,38F TRANSFER FUNCTION FROM PROCESS NCISE ,I2,3F TC,13H ME
1ASUREMENT ,I2,/)
      FORMAT (/,36F TRANSFER FUNCTION FROM PROCESS NCISE ,I2,3F TC,9F CONO
1TROL ,I2,/)
      FORMAT (/,36F TRANSFER FUNCTION FROM MEASUREMENT ,I2,16H TO MEASURE
1MENT ,I2,/)
      FORMAT (/,36F TRANSFER FUNCTION FROM MEASUREMENT ,I2,12H TO CCNTPOL
1,/)
      FORMAT (/,14F PSD OF OUTPUT,I3,32H FORCED BY ALL NCISE-(RAD FRFQ.,
115HNORMALIZED PSD)/)
      FORMAT (/,14F PSD OF CCNTROL,I3,32H FORCED BY ALL NCISE-(RAD FRFQ.,
115HNORMALIZED PSD)/)
      FORMAT (4(I,1H,E11.4,1H,E11.4,1H,E11.4,1H))
      END
=====

```

```

OPT31210
OPT31220
OPT31230
OPT31240
OPT31250
OPT31260
OPT31270
OPT31280
OPT31290
OPT31300
OPT31310
OPT31320
OPT31330
OPT31340
OPT31350
OPT31360
OPT31370
OPT31380
OPT31390
OPT31400
OPT31410
OPT31420
OPT31430
OPT31440
OPT31450
OPT31460
OPT31470
OPT31480
OPT31490
OPT31500
OPT31510
OPT31520
OPT31530
OPT31540
OPT31550
OPT31560
OPT31570
OPT31580
OPT31590
OPT31600
OPT31610
OPT31620
OPT31630
OPT31640
OPT31650
OPT31660
OPT31670
OPT31680

```

```

C-----
SUBROUTINE EREXIT (N,A,IERR)
EREXIT RETURNS THE NUMBER OF THE EIGENVALUE WHERE HQR2
FAILS, THEN STOPS THE PROGRAM.
C-----
      INTEGER IERR
      DOUBLE PRECISION A
      DIMENSION A(N,N)
      WRITE (5,17) IERR
      CALL RAPRNT (N,N,N,9,A,4,'(9(1X,1PD13.6))')
      RETURN
10  FORMAT (35H FAILURE IN HQR2 ON EIGENVALUE NO. ,13)
      END
C-----
SUBROUTINE READF (NS,ISAF,BA)
INTERACTIVELY INPUTS THE "F" MATRIX ELEMENT BY ELEMENT.
C-----
      REAL*8  BA(NS,NS),DUM,ANSR
      INTEGER I,J,K,L,IAN,ISAF
      DATA IY/,Y/,IZ/,N,/
      IF (ISAF.EC.1) GO TO 40
      WRITE (5,13C)
      DO 20 I=1,NS
      DO 10 J=1,NS
      WRITE (5,12C) I,J
      CALL RCREAL (ANSR)
      BA(I,J)=ANSR
      CCNT=CCNT+1
      CCNT INUE
      CCNT INUE
      CALL FRTCMS ('CLRSCRN ')
      CCNT INUE
      WRITE (5,14C)
      CALL MATPRT (BA,NS,NS)
      WRITE (5,15C)
      CALL RDOCHAR (IAN)
      IF ((IAN.NE.IY).AND.(IAN.NE.IZ)) GO TO 60
      GO TO 70
      WRITE (5,16C)
      CCNT INUE
      CCNT INUE
      IF (IAN.EC.1Z) GO TO 110
      IF (IAN.EC.IY) GO TO 80
      WRITE (5,17C)
      CALL RDCINT (IAPIS)
      K=IAN
      WRITE (5,18C)
      CALL RDCINT (IAN)
      L=IAN

```

```

OPT31690
OPT31700
OPT31710
OPT31720
OPT31730
OPT31740
OPT31750
OPT31760
OPT31770
OPT31780
OPT31790
OPT31800
OPT31810
OPT31820
OPT31830
OPT31840
OPT31850
OPT31860
OPT31870
OPT31880
OPT31890
OPT31900
OPT31910
OPT31920
OPT31930
OPT31940
OPT31950
OPT31960
OPT31970
OPT31980
OPT31990
OPT32000
OPT32010
OPT32020
OPT32030
OPT32040
OPT32050
OPT32060
OPT32070
OPT32080
OPT32090
OPT32100
OPT32110
OPT32120
OPT32130
OPT32140
OPT32150
OPT32160

```

C
C

10

C
C

10
20
30
40

50

60

70

80

```

WRITE (5,12C) K,L
CALL RCRREAL (ANSR)
CUM=ANSR
DO 100 I=1,NS
DO 90 J=1,NS
IF ((I.EQ.K).AND.(J.EQ.L)) BA(I,J)=DUM
CCNTINUE
GO TO 30
CCNTINUE
CALL FRTCMS ('CLRSCRN ')
RETURN
-----
120 FORMAT (5X,14H THE ELEMENT F(I2,1H,I2,2H)=)
130 FORMAT (/,EX,26H ENTER THE SYSTEM MATRIX "F"-MATRIX,/,10X,41HDIMENSIONAL MATRIX "F" STATES NS& X # STATES NS&)
140 FORMAT (//,EX,33H THE SYSTEM MATRIX "F"-MATRIX,/,10X,41HDIMENSIONAL MATRIX "F" STATES NS& X # STATES NS&)
150 FORMAT (//,EX,54H DO YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELEMENT?//,10X,19H TYPE "YES" OR "NO".)
160 FORMAT (//,EX,54H WARNING: IMPROPER DATA ENTRY ENTER "YES" OR "NO".)
170 FORMAT (5X,14H ENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.)
180 FORMAT (5X,53H ENTER THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED.)
1. END
C=====
SUBROUTINE READH (NO,NS,ISAH,HO)
INTERACTIVELY INPUTS THE "H" MATRIX MEASUREMENT SCALING MATRIX.
C=====
REAL*8 HO(NO,NS),DUM,ANSR
INTEGER IANS,IJ,K,L,ISAH
DATA IV,Y,IJ,N/
C-----
IF (ISAH.EQ.1) GO TO 40
WRITE (5,12C)
DO 20 I=1,NC
DO 10 J=1,NS
WRITE (5,11C) I,J
CALL RCRREAL (ANSR)
H(I,J)=ANSR
CCNTINUE
CCNTINUE
10
20
30
40
CALL FRTCMS ('CLRSCRN ')
CCNTINUE
WRITE (5,12C)
CALL MATPRT (HO,NO,NS)
WRITE (5,14C)
CALL RDOCHAR (IANS)
50

```

```

6C      IF ((IANS.NE.IV).AND.(IANS.NE.IZ)) GO TO 60
        GO TO 70
        WRITE (5,15C)
        GC TO 50
        CCNTINUE
70      IF (IANS.EQ.IZ) GO TC 100
        WRITE (5,16C)
        CALL RCINT (IANS)
        K=IANS
        WRITE (5,17C)
        CALL RDINT (IANS)
        L=IANS
        WRITE (5,11C) K,L
        CALL RCREAL (ANSR)
        DUM=ANSR
        DO 90 I=1,NC
        DO 80 J=1,NS
8C      IF ((I.EQ.K).AND.(J.EQ.L)) HO(I,J)=DUM
9C      CCNTINUE
        GO TO 30
100     CCNTINUE
        CALL FRTCMS ('CLRSCRN ')
        RETURN
-----
110     FORMAT (5X,14H THE ELEMENT H(I,I2,1H,I2,2H)=)
120     FORMAT (//,5X,50H ENTER THE MEASUREMENT SCALING MATRIX "H"-MATRIX &
130     1//,10X,47H DIMENSION = # OBSERVATIONS NC&X # STATES NS&
        1//,10X,46H THE MEASUREMENT SCALING MATRIX "H"-MATRIX &000,/OPT32920
140     1//)
        FORMAT (//,5X,54H DO YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELEMENT
150     1ENT?//,10X,15H TYPE "YES" OR "NO".)
        FORMAT (//,1X,21H WARNING: IMPROPER DATA ENTRY ENTER "YES" OR "NO".) OPT32970
160     FORMAT (5X,20H ENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.) OPT32980
170     FORMAT (5X,52H ENTER THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED
        1)
        END
C=====
        SUPROUTINE READ (NC,NC,D)
        INPUTS THE "D" MATRIX MEASUREMENT FEED-FORWARD DIST. MATRIX &.
C=====
        REAL*8 D(NC,NC),DUM,ANSR
        INTEGER IANS,I,J,K,L
        DATA I/Y,I2/N,I2/N,I2/N,I2/N
        WRITE (5,11C)
        DO 20 I=1,NC
        DO 10 J=1,NC
        WRITE (5,11C) I,J
OPT32650
OPT32660
OPT32670
OPT32680
OPT32690
OPT32700
OPT32710
OPT32720
OPT32730
OPT32740
OPT32750
OPT32760
OPT32770
OPT32780
OPT32790
OPT32800
OPT32810
OPT32820
OPT32830
OPT32840
OPT32850
OPT32860
OPT32870
OPT32880
OPT32890
OPT32900
OPT32910
OPT32920
OPT32930
OPT32940
OPT32950
OPT32960
OPT32970
OPT32980
OPT32990
OPT33000
OPT33010
OPT33020
OPT33030
OPT33040
OPT33050
OPT33060
OPT33070
OPT33080
OPT33090
OPT33100
OPT33110
OPT33120

```

```

100 CALL RCREAL (ANSR)
110 D(I,J)=ANSR
120 CCNT INUE
130 CCNT INUE
140 CALL FRICMS ('CLRSCRN ')
150 WRITE (5,12C)
160 CALL MATPR1 (D,NO,NC)
170 WRITE (5,13C)
180 CALL RDCCHAR (IANS)
190 IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 50
200 GO TO 60
210 WRITE (5,14C)
220 GO TO 40
230 CCNT INUE
240 IF (IANS.EQ.IZ) GO TO 90
250 WRITE (5,15C)
260 CALL RDCINT (IANS)
270 K=IANS
280 WRITE (5,16C)
290 CALL RDCINT (IANS)
300 L=IANS
310 WRITE (5,17C) K,L
320 CALL RDCREAL (ANSR)
330 CUM=ANSR
340 DO 80 I=1,NC
350 DO 70 J=1,NC
360 IF ((I.EQ.K).AND.(J.EQ.L)) D(I,J)=DUM
370 CCNT INUE
380 GO TO 30
390 CCNT INUE
400 CALL FRICMS ('CLRSCRN ')
410 RETURN
420
430 FCRMAT (5X,14HTHE ELEMENT D(,12,1H,12,2H)=)
440 FCRMAT (/,5X,54HENTER THE MEASUREMENT FEEDTHROUGH MATRIX / FEEDFOROPT33480
450 IWARD,/,5X,34H DISTRIBUTION MATRIX "D"-MATRIXE.,//.8X,4SHDIMENSIONOPT33490
460 2=# OBSERVATIONS NC&X# CONTROLS NC&)
470 FCRMAT (//,5X,50HTHE FEEDFORWARD DISTRIBUTION MATRIX "C"-MATRIXE.OPT33510
480 1,/)
490 FCRMAT (//,5X,54HDO YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELEMENTOPT33520
500 1ENT?//,10X,15HTYPE "YES" OR "NO".)
510 FCRMAT (1X,15HWARNING: IMPROPER DATA ENTRY ENTER "YES" OR "NO".)OPT33530
520 FCRMAT (5X,54HENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.OPT33540
530 FCRMAT (5X,53HENTER THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED.OPT33550
540 1,.)
550 END
OPT33560
OPT33570
OPT33580
OPT33590
OPT33600

```

```

C=====OPT333610
C SUBROUTINE READG (NS,NC,ISAG,G)OPT333620
C INTERACTIVELY INPUTS THE "G" MATRIX CONTROL DISTRIBUTION MATRIXE=OPT333630
C=====OPT333640
REAL*8 G(NS,NC),DUM,ANSR
INTEGER IANS,IJ,K,L,ISAG
DATA IY//,IY//,IZ//,N//
IF (ISAG.EQ.1) GO TO 40
WRITE (5,12C)
DO 20 I=1,NS
DO 10 J=1,NC
WRITE (5,11C) I,J
CALL RCREAL (ANSR)
G(I,J)=ANSR
CCNT INUE
CCNT INUE
1C-----
2C-----
3C-----
4C-----
5C-----
6C-----
7C-----
80-----
9C-----
10C-----
C-----
CALL FRTCMS ('CLRSCRN ')
CCNT INUE
WRITE (5,13C)
CALL MATPR1 (G,NS,NC)
WRITE (5,14C)
CALL RCHAR (IANS)
IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 60
GO TO 70
WRITE (5,15C)
GO TO 50
CCNT INUE
IF (IANS.EQ.IZ) GO TO 100
WRITE (5,16C)
CALL RCONT (IANS)
K=IANS
WRITE (5,17C)
CALL RDINT (IANS)
L=IANS
WRITE (5,11C) K,L
CALL RCREAL (ANSR)
DUM=ANSR
DO 30 I=1,NS
DO 30 J=1,NC
IF ((I.EQ.K).AND.(J.EQ.L)) G(I,J)=DUM
CCNT INUE
GO TO 30
CCNT INUE
CALL FRTCMS ('CLRSCRN ')
RETURN
C-----OPT333650
OPT333660
OPT333670
OPT333680
OPT333690
OPT333700
OPT333710
OPT333720
OPT333730
OPT333740
OPT333750
OPT333760
OPT333770
OPT333780
OPT333790
OPT333800
OPT333810
OPT333820
OPT333830
OPT333840
OPT333850
OPT333860
OPT333870
OPT333880
OPT333890
OPT333900
OPT333910
OPT333920
OPT333930
OPT333940
OPT333950
OPT333960
OPT333970
OPT333980
OPT333990
OPT340000
OPT340010
OPT340020
OPT340030
OPT340040
OPT340050
OPT340060
OPT340070
OPT340080

```

```

110 FORMAT (5X,14HTHE ELEMENT G(I,I2,1H,I2,2H)=)
120 FORMAT (//,5X,5HTHE CONTROL DISTRIBUTION MATRIX "G"-MATRIX ELEMENTS)
130 FORMAT (//,10X,4HTHE STATES NS&X # CONTROL MATRIX "G"-MATRIX ELEMENTS)
140 FORMAT (//,10X,4HTHE CONTROL DISTRIBUTION MATRIX "G"-MATRIX ELEMENTS)
150 FORMAT (//,5X,54HDO YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELEMENT?//,10X,5HTYPE "YES" OR "NO".)
160 FORMAT (//,1X,5HTHWARNING: IMPROPER DATA ENTRY ENTER "YES" CR "NO".)
170 FORMAT (5X,5HTHENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.)
180 FORMAT (5X,5HTHENTER THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED.)
190
200
210
220
230
240
250
260
270
280
290
300
310
320
330
340
350
360
370
380
390
400
410
420
430
440
450
460
470
480
490
500
510
520
530
540
550
560
570
580
590
600
610
620
630
640
650
660
670
680
690
700
710
720
730
740
750
760
770
780
790
800
810
820
830
840
850
860
870
880
890
900
910
920
930
940
950
960
970
980
990

```



```

100 DO 80 I=1,NC
110 DO 70 J=1,NC
120 IF ((I.EQ.K).AND.(J.EQ.L)) FBGC(I,J)=DUM
130 CCNT INUE
140 CCNT INUE
150 GO TO 30
160 CCNT INUE
170 CALL FRTCMS ('CLRSCRN ')
180 RETURN
190
200 FORMAT (5X,14HTPE ELEMENT C(I2,1H,I2,2H)=)
210 FORMAT (//,5X,52HTPE THE FEEDBACK GAIN CCNTRCL MATRIX "C"-MATRIX
220 18,//,10X,24HTPE NSE.# CONTROLS NC&X # STATES "NSE.")
230 FORMAT (//,10X,45HTPE FEEDBACK GAIN CONTROL MATRIX "C"-MATRIX&,//)
240 1)
250 FORMAT (//,5X,54HDO YCU WISH TO CHANGE THE VALUE OF ANY MATRIX ELEMENT
260 1ENT?//,10X,19HTPE "YES" OR "NO".)
270 FCFORMAT (//,1X,11HTPE "IMPROPER DATA ENTRY ENTER "YES" CR "AC".)
280 FORMAT (5X,52HTPE THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.)
290 1)
300 FORMAT (5X,53HTPE THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED
310 1)
320 END
330
340 SUBROUTINE READAY (NC,ISAA,AY)
350 INPUTS THE "A" MATRIX DIAGONAL OUTPUT COST MATRIX&.
360
370 REAL*8 AY(NC,NO),DUM,ANSR
380 INTEGER IANS,IJ,K,L
390 DATA IY,Y,Y,Y,I2//N://
400 IF (ISAA.EQ.1) GO TO 30
410 WRITE (5,11C)
420 DO 20 I=1,NC
430 DO 10 J=1,NC
440 WRITE (5,11C) I,J
450 CALL RDR&AL (ANSR)
460 AY(I,J)=ANSR
470 CCNT INUE
480
490 CALL FRTCMS ('CLRSCRN ')
500 WRITE (5,12C)
510 CALL MATPRT (AY,NO,NC)
520 WRITE (5,13C)
530 CALL RDR&AL (IANS)
540 IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 50
550 WRITE (5,14C)
560 GO TO 40

```



```

C-----
2C      CALL FRICMS ('CLRSCRN ')
        WRITE (5,13C)
        CALL MATPR1 (B,NC,NC)
3C      WRITE (5,13C)
        CALL ROCHAR (IANS)
        IF ((IANS.NE.IV).AND.(IANS.NE.IZ)) GO TO 40
        GO TO 50
4C      WRITE (5,12C)
        GO TO 30
5C      CCNTINUE
        IF (IANS.EQ.IZ) GO TC 70
        WRITE (5,13C)
        CALL RCDINT (IANS)
        K=IANS
        WRITE (5,14C)
        CALL RCDINT (IANS)
        L=IANS
        WRITE (5,8C) K,L
        CALL RCREAL (ANSR)
        DUM=ANSR
        DO 60 I=1,NC
        DO 60 J=1,NC
        IF ((I.EQ.K).AND.(J.EQ.L)) B(I,J)=DUM
        CCNTINUE
        GO TO 20
7C      CCNTINUE
        CALL FRICMS ('CLRSCRN ')
        RETURN
C-----
8C      FFORMAT (5X,14HTYPE ELEMENT B(I,1H,I2,2H)=)
9C      FFORMAT (1X,52HENTER THE CONTROL COST WEIGHTING MATRIX "B"-MATRIX
        1X,/,10X,42HENSION = # CONTROL COST NC&X # CCNTRLCLS NC&)
100     FFORMAT (1X,10X,37HTHE CONTROL COST MATRIX. . . . .B. . . . .)
110     FFORMAT (1X,54HDO YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELEMENT? ,/,10X,19HTYPE "YES" OF "NO".)
120     FFORMAT (1X,11HWARNING: IMPROPER DATA ENTRY ENTER "YES" OR "NO".)
130     FFORMAT (5X,1EENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.)
140     FFORMAT (5X,52HENTER THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED)
        1) END
C=====
SUBROUTINE READG2 (N&NG,IGAM,GAM)
C      INPUTS THE "GAM" MATRIX PROCESS NOISE DISTRIBUTION MATRIX&.
C=====
        REAL*8  GAM(NS,NG),DUM,ANSR
        INTEGER IANS,I,J,K,L,IGAM
        DATA IY,IY',IY'',I2//N'/'

```

```

10C IF (IGAM.EQ.1) GO TO 40
11C WRITE (5,12C)
12C DO 20 I=1,NS
13C DO 10 J=1,NG
14C WRITE (5,11C) I,J
15C CALL RCREAL (ANSR)
16C GAM(I,J)=ANSR
17C CONTINUE
18C CONTINUE
19C
20C CALL FRTCMS ('CLRSCRN ')
21C CONTINUE
22C WRITE (5,13C)
23C CALL MATPRT (GAM,NS,NG)
24C WRITE (5,14C)
25C CALL RCHAR (IANS)
26C IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 60
27C GO TO 70
28C WRITE (5,15C)
29C GO TO 50
30C CONTINUE
31C IF (IANS.EQ.IZ) GO TO 100
32C WRITE (5,16C)
33C CALL RDINT (IANS)
34C K=IANS
35C WRITE (5,17C)
36C CALL RDINT (IANS)
37C L=IANS
38C WRITE (5,11C) K,L
39C CALL RCREAL (ANSR)
40C DUM=ANSR
41C DO 90 I=1,NS
42C DO 80 J=1,NG
43C IF ((I.EQ.K).AND.(J.EQ.L)) GAM(I,J)=DUM
44C CONTINUE
45C CONTINUE
46C GO TO 30
47C CONTINUE
48C CALL FRTCMS ('CLRSCRN ')
49C RETURN
50C
51C
52C
53C
54C
55C
56C
57C
58C
59C
60C
61C
62C
63C
64C
65C
66C
67C
68C
69C
70C
71C
72C
73C
74C
75C
76C
77C
78C
79C
80C
81C
82C
83C
84C
85C
86C
87C
88C
89C
90C
91C
92C
93C
94C
95C
96C
97C
98C
99C
100C
101C
102C
103C
104C
105C
106C
107C
108C
109C
110C
111C
112C
113C
114C
115C
116C
117C
118C
119C
120C
121C
122C
123C
124C
125C
126C
127C
128C
129C
130C
131C
132C
133C
134C
135C
136C
137C
138C
139C
140C
141C
142C
143C
144C
145C
146C
147C
148C
149C
150C
151C
152C
153C
154C
155C
156C
157C
158C
159C
160C
161C
162C
163C
164C
165C
166C
167C
168C
169C
170C
171C
172C
173C
174C
175C
176C
177C
178C
179C
180C
181C
182C
183C
184C
185C
186C
187C
188C
189C
190C
191C
192C
193C
194C
195C
196C
197C
198C
199C
200C
201C
202C
203C
204C
205C
206C
207C
208C
209C
210C
211C
212C
213C
214C
215C
216C
217C
218C
219C
220C
221C
222C
223C
224C
225C
226C
227C
228C
229C
230C
231C
232C
233C
234C
235C
236C
237C
238C
239C
240C
241C
242C
243C
244C
245C
246C
247C
248C
249C
250C
251C
252C
253C
254C
255C
256C
257C
258C
259C
260C
261C
262C
263C
264C
265C
266C
267C
268C
269C
270C
271C
272C
273C
274C
275C
276C
277C
278C
279C
280C
281C
282C
283C
284C
285C
286C
287C
288C
289C
290C
291C
292C
293C
294C
295C
296C
297C
298C
299C
300C
301C
302C
303C
304C
305C
306C
307C
308C
309C
310C
311C
312C
313C
314C
315C
316C
317C
318C
319C
320C
321C
322C
323C
324C
325C
326C
327C
328C
329C
330C
331C
332C
333C
334C
335C
336C
337C
338C
339C
340C
341C
342C
343C
344C
345C
346C
347C
348C
349C
350C
351C
352C
353C
354C
355C
356C
357C
358C
359C
360C
361C
362C
363C
364C
365C
366C
367C
368C
369C
370C
371C
372C
373C
374C
375C
376C
377C
378C
379C
380C
381C
382C
383C
384C
385C
386C
387C
388C
389C
390C
391C
392C
393C
394C
395C
396C
397C
398C
399C
400C
401C
402C
403C
404C
405C
406C
407C
408C
409C
410C
411C
412C
413C
414C
415C
416C
417C
418C
419C
420C
421C
422C
423C
424C
425C
426C
427C
428C
429C
430C
431C
432C
433C
434C
435C
436C
437C
438C
439C
440C
441C
442C
443C
444C
445C
446C
447C
448C
449C
450C
451C
452C
453C
454C
455C
456C
457C
458C
459C
460C
461C
462C
463C
464C
465C
466C
467C
468C
469C
470C
471C
472C
473C
474C
475C
476C
477C
478C
479C
480C
481C
482C
483C
484C
485C
486C
487C
488C
489C
490C
491C
492C
493C
494C
495C
496C
497C
498C
499C
500C
501C
502C
503C
504C
505C
506C
507C
508C
509C
510C
511C
512C
513C
514C
515C
516C
517C
518C
519C
520C
521C
522C
523C
524C
525C
526C
527C
528C
529C
530C
531C
532C
533C
534C
535C
536C
537C
538C
539C
540C
541C
542C
543C
544C
545C
546C
547C
548C
549C
550C
551C
552C
553C
554C
555C
556C
557C
558C
559C
560C
561C
562C
563C
564C
565C
566C
567C
568C
569C
570C
571C
572C
573C
574C
575C
576C
577C
578C
579C
580C
581C
582C
583C
584C
585C
586C
587C
588C
589C
590C
591C
592C
593C
594C
595C
596C
597C
598C
599C
600C
601C
602C
603C
604C
605C
606C
607C
608C
609C
610C
611C
612C
613C
614C
615C
616C
617C
618C
619C
620C
621C
622C
623C
624C
625C
626C
627C
628C
629C
630C
631C
632C
633C
634C
635C
636C
637C
638C
639C
640C
641C
642C
643C
644C
645C
646C
647C
648C
649C
650C
651C
652C
653C
654C
655C
656C
657C
658C
659C
660C
661C
662C
663C
664C
665C
666C
667C
668C
669C
670C
671C
672C
673C
674C
675C
676C
677C
678C
679C
680C
681C
682C
683C
684C
685C
686C
687C
688C
689C
690C
691C
692C
693C
694C
695C
696C
697C
698C
699C
700C
701C
702C
703C
704C
705C
706C
707C
708C
709C
710C
711C
712C
713C
714C
715C
716C
717C
718C
719C
720C
721C
722C
723C
724C
725C
726C
727C
728C
729C
730C
731C
732C
733C
734C
735C
736C
737C
738C
739C
740C
741C
742C
743C
744C
745C
746C
747C
748C
749C
750C
751C
752C
753C
754C
755C
756C
757C
758C
759C
760C
761C
762C
763C
764C
765C
766C
767C
768C
769C
770C
771C
772C
773C
774C
775C
776C
777C
778C
779C
780C
781C
782C
783C
784C
785C
786C
787C
788C
789C
790C
791C
792C
793C
794C
795C
796C
797C
798C
799C
800C
801C
802C
803C
804C
805C
806C
807C
808C
809C
810C
811C
812C
813C
814C
815C
816C
817C
818C
819C
820C
821C
822C
823C
824C
825C
826C
827C
828C
829C
830C
831C
832C
833C
834C
835C
836C
837C
838C
839C
840C
841C
842C
843C
844C
845C
846C
847C
848C
849C
850C
851C
852C
853C
854C
855C
856C
857C
858C
859C
860C
861C
862C
863C
864C
865C
866C
867C
868C
869C
870C
871C
872C
873C
874C
875C
876C
877C
878C
879C
880C
881C
882C
883C
884C
885C
886C
887C
888C
889C
890C
891C
892C
893C
894C
895C
896C
897C
898C
899C
900C
901C
902C
903C
904C
905C
906C
907C
908C
909C
910C
911C
912C
913C
914C
915C
916C
917C
918C
919C
920C
921C
922C
923C
924C
925C
926C
927C
928C
929C
930C
931C
932C
933C
934C
935C
936C
937C
938C
939C
940C
941C
942C
943C
944C
945C
946C
947C
948C
949C
950C
951C
952C
953C
954C
955C
956C
957C
958C
959C
960C
961C
962C
963C
964C
965C
966C
967C
968C
969C
970C
971C
972C
973C
974C
975C
976C
977C
978C
979C
980C
981C
982C
983C
984C
985C
986C
987C
988C
989C
990C
991C
992C
993C
994C
995C
996C
997C
998C
999C
1000C

```



```

SC      CONTINUE
      CALL FRTCMS ('CLRSCRN ')
      RETURN
C-----
100     FORMAT (5X,14H"THE ELEMENT Q(I,I2,1H,I2,2H)=)
110     FORMAT (//,5X,44H"ENTER THE PROCESS NOISE PSD WEIGHTING MATRIX,/,5X,42H"PROCESS NOISE SOURCES NG&
110     1,12H"Q"MATRIX&.,//,5X,42H"PROCESS NOISE SOURCES NG&
120     2,X,/,17X,27H"PROCESS NOISE SOURCES NG&
130     FORMAT (//,5X,42H"THE PROCESS NOISE WEIGHTING MATRIX,/,5X,42H"PROCESS NOISE SOURCES NG&
140     1,12H"Q"MATRIX&.,//,5X,42H"PROCESS NOISE SOURCES NG&
150     FORMAT (//,5X,42H"THE PROCESS NOISE WEIGHTING MATRIX,/,5X,42H"PROCESS NOISE SOURCES NG&
160     1,12H"Q"MATRIX&.,//,5X,42H"PROCESS NOISE SOURCES NG&
      END
C=====
C      SUBROUTINE READR (NC,RC)
C      INTERACTIVELY INPUTS THE "R" MATRIX=
C      MEASUREMENT NOISE DISTRIBUTION MATRIX.
C=====
      REAL*8 RC(NO,NO),DUM,ANSR
      INTEGER IANS,I,J,K,L
      DATA IY,Y,Y,I2,N:/
      WRITE (5,90)
      DO 10 I=1,NC
      DO 10 J=1,NC
      WRITE (5,80) I,J
      CALL RCREAL (ANSR)
      RCT(I,J)=ANSR
1C-----
2C     CALL FRTCMS ('CLRSCRN ')
      WRITE (5,100)
      CALL MATPRT (RC,NO,NC)
      WRITE (5,110)
      CALL RDCHAR (IANS)
      IF ((IANS.NE.IY).AND.(IANS.NE.I2)) GO TO 40
      GO TO 50
      WRITE (5,120)
      GO TO 30
      CONTINUE
      IF (IANS.EC.I2) GO TO 70
      WRITE (5,130)
      CALL RDINT (IANS)
      K=IANS
      WRITE (5,140)
      CALL RDINT (IANS)
      L=IANS

```

```

WRITE (5,8C) K,L
CALL RDRREAL (ANSR)
DUM=ANSR
DO 60 I=1,NC
DO 60 J=1,NC
IF ((I.EQ.K).AND.(J.EQ.L)) RC(I,J)=DUM
GO TO 20
CCNTINUE
CALL FRTCMS ('CLRSCRN ')
RETURN
-----
8C  FORMAT (5X,14H THE ELEMENT R(,I2,1H, I2,2H)=)
9C  FORMAT (/,5X,60H ENTER THE MEASUREMENT NOISE DISTRIBUTION MATRIX
1R"MATRIX&.,//,5X,53H DIMENSION = # OBSERVATIONS NO& X # OBSERVATIONS
2NS NO&)
10C  FORMAT (//,15X,50H THE MEASUREMENT NOISE DISTRIBUTION MATRIX.....R.
110  1.,//)
110  FORMAT (//5X,54H DO YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELEMENT
120  1ENT?//,10X,19H TYPE "YES" OR "NO".)
120  FORMAT (//,1X,11H WARNING: IMPROPER DATA ENTRY ENTER "YES" OR "NO".)
130  FORMAT (5X,50H ENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.)
140  FORMAT (5X,52H ENTER THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED
1)
END
C=====
SUBROUTINE READFE (NS,NO,FBGE)
C INTERACTIVELY INPUTS THE "K" FEEDBACK GAIN ESTIMATOR MATRIX&
C=====
REAL*8 FBGE(NS,NO),CUM,ANSR
INTEGER IANS,I,J,K,L
DATA IY,'Y',IZ,'N'//
WRITE (5,11C)
DO 20 I=1,NC
DO 10 J=1,NC
WRITE (5,11C) I,J
CALL RDRREAL (ANSR)
FBGE(I,J)=ANSR
CONTINUE
1C
2C
3C  CALL FRTCMS ('CLRSCRN ')
3C  WRITE (5,12C)
3C  CALL MATPRT (FBGE,NS,NO)
4C  WRITE (5,13C)
4C  CALL RDCHAP (IANS)
IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 50
GO TO 50
5C  WRITE (5,14C)

```

```

60      GO TO 40
      CONTINUE
      IF (IANS.EQ.1Z) GO TO 90
      WRITE (5,15C)
      CALL RDCINT (IANS)
      K=IANS
      WRITE (5,16C)
      CALL RDCINT (IANS)
      L=IANS
      WRITE (5,10C) K,L
      CALL RDRREAL (ANSR)
      DUM=ANSR
      DO 80 I=1,NS
      DO 70 J=1,NC
      IF ((I.EQ.K).AND.(J.EQ.L)) FBGE(I,J)=DUM
      CONTINUE
      GC TO 30
      CONTINUE
      GC TO 30
      CONTINUE
      CALL FRTCMS ('CLRSCRN ')
      RETURN
-----
100  FORMAT (5X,14HTHE ELEMENT K(I2,1H,I2,2H)=)
110  FORMAT (//5X,54HTHE FEEDBACK GAIN ESTIMATOR MATRIX "K"-MATRIX
120  1IX&://,10X,48HDIMENSION = # STATES' NS& X # CBSERVATICS' NCS&.)
130  FORMAT (//,15X,47HTHE FEEDBACK GAIN ESTIMATOR MATRIX "K"-MATRIX&,
140  1//)
150  FORMAT (//,5X,54HDC YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELE
160  1MENT?://,10X,19HTYPE "YES" OR "NO".)
170  FORMAT (//,1X,51HWARNING: IMPROPER DATA ENTRY ENTER "YES" CR "NO".)
180  FORMAT (5X,52CHENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.)
190  FORMAT (5X,52CHENTER THE COLUMN NUMBER OF THE ELEMENT TO BE CHANGED
200  1)
210  END
C=====
C      SUBROUTINE READW (NG,WR)
C      INTERACTIVELY INPUTS THE "W0" MATRIX STEADY DISTURBANCE VECTOR =
C      MATRIX& ELEMENT BY ELEMENT.
C=====
220  REAL*8 WR(NG),DUM,ANSR
230  INTEGER IANS,I,K
240  DATA IY,Y,Z,I2/'N'/'
250  WRITE (5,10C)
260  DO 10 I=1,NC
270  WRITE (5,80) I
280  CALL RDRREAL (ANSR)
290  WR(I)=ANSR
300  CONTINUE
310  C
320  C
330  C
340  C
350  C
360  C
370  C
380  C
390  C
400  C
410  C
420  C
430  C
440  C
450  C
460  C
470  C
480  C
490  C
500  C
510  C
520  C
530  C
540  C
550  C
560  C
570  C
580  C
590  C
600  C
610  C
620  C
630  C
640  C
650  C
660  C
670  C
680  C
690  C
700  C
710  C
720  C
730  C
740  C
750  C
760  C
770  C
780  C
790  C
800  C
810  C
820  C
830  C
840  C
850  C
860  C
870  C
880  C
890  C
900  C
910  C
920  C
930  C
940  C
950  C
960  C
970  C
980  C
990  C
1000 C

```



```

C-----
2C  CALL FRTCMS ('CLRSCRN ')
    WRITE (5,11C) (WR(I),I=1,NG)
3C  WRITE (5,12C)
    CALL RCHAR (IANS)
    IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 40
4C  GO TO 50
    WRITE (5,13C)
5C  GO TO 30
    CCNTINUE
    IF (IANS.EC.IZ) GO TO 70
    WRITE (5,14C)
    CALL RDINT (IANS)
    K=IANS (5,8C) K
    CALL RREAL (ANSR)
    CUM=ANSR
    DO 60 I=1,NG
6C  IF (I.EQ.K) WR(I)=DUM
    CCNTINUE
7C  GO TO 20
    CCNTINUE
    CALL FRTCMS ('CLRSCRN ')
    RETURN
C-----
8C  FORMAT (5X,15HTHE ELEMENT W0(,I2,2H)=)
9C  FORMAT (F12.5)
10C  FORMAT (/,5X,57HENTER THE STEADY DISTURBANCE VECTOR MATRIX "W0"-M
    1ATRX6. //,10X,44HDIMENSION = # PROCESS NOISE SOURCES NGE X 1)
110  FORMAT (//,15X,53HTHE STEADY DISTURBANCE VECTOR MATRIX "W0"-MATR
    1X6. //)
12C  FORMAT (//,5X,54HDO YOU WISH TO CHANGE THE VALUE OF ANY MATRIX ELE
    1ENT? //,10X,19HTYPE "YES" OR "NO".)
130  FORMAT (1X,11HWARNING: IMPROPER DATA ENTRY ENTER "YES" OR "NO".)
14C  FORMAT (5X,50HENTER THE ROW NUMBER OF THE ELEMENT TO BE CHANGED.)
    END
C=====
C  SUBROUTINE RREAL --- INTERACTIVELY READS A REAL NUMBER REPLY
C  INTO A FORTRAN PROGRAM. IF THE USER INADVERTENTLY ENTERS A NULL
C  STRING THE S/R ISSUES A WARNING AND ALLOWS A RECOVERY.
C=====
    SUBROUTINE RREAL (ANSR)
    REAL*8 ANSR
    INTEGER COUNT
C-----
1C  COUNT=0
    CCNTINUE
    OPT38410
    OPT38420
    OPT38430
    OPT38440
    OPT38450
    OPT38460
    OPT38470
    OPT38480
    OPT38490
    OPT38500
    OPT38510
    OPT38520
    OPT38530
    OPT38540
    OPT38550
    OPT38560
    OPT38570
    OPT38580
    OPT38590
    OPT38600
    OPT38610
    OPT38620
    OPT38630
    OPT38640
    OPT38650
    OPT38660
    OPT38670
    OPT38680
    OPT38690
    OPT38700
    OPT38710
    OPT38720
    OPT38730
    OPT38740
    OPT38750
    OPT38760
    OPT38770
    OPT38780
    OPT38790
    OPT38800
    OPT38810
    OPT38820
    OPT38830
    OPT38840
    OPT38850
    OPT38860
    OPT38870
    OPT38880

```

```

CCOUNT=COUNT+1
IF (COUNT.LT.3) GO TC 20
WRITE (5,6C)
GO TO 40
CCNT INUE
READ (5,*,END=30,ERR=30) ANSR
RETURN
REWIND 5
WRITE (5,50)
GO TO 10
CCNT INUE
STOP
C-----
5C  FORMAT (1X,64HWARNING:  NULL STRINGS ARE NOT ALLOWED, ENTER A NUMERICAL VALUE.)
6C  FORMAT (//,5X,47HPROGRAM TERMINATION - TWO NULL STRINGS ENTERED)
END
C=====
C  SUBROUTINE RDINT --- INTERACTIVELY READS AN INTEGER REPLY
C  INTO A FORTRAN PROGRAM. IF THE USER INADVERTENTLY ENTERS AN IMPROPER
C  DATA CHARACTER THE S/R ISSUES A WARNING AND ALLWS A RECOVERY.
C=====
SUBROUTINE RDINT (IANS)
INTEGER CCLNT,IANS
C-----
1C  CCLNT=0
CCNT INUE
CCOUNT=COUNT+1
IF (COUNT.LT.3) GO TC 20
WRITE (5,6C)
GO TO 50
CCNT INUE
READ (5,*,END=40,ERR=40) IANS
IF (IANS) 4C,40,30
RETURN
REWIND 5
WRITE (5,7C)
GO TO 10
CCNT INUE
STOP
C-----
6C  FORMAT (//,5X,49HPROGRAM TERMINATION - TWO IMPROPER DATA ENTRIES)
7C  FORMAT (1X,56HWARNING:  IMPROPER DATA ENTRY  ENTER A POSITIVE INTEGER.)
END
C=====

```



```

IF (NCOL.EC.11) WRITE (5,110) ((PRIT(I,J),J=1,NCOL),I=1,NROW)
IF (NCOL.EC.12) WRITE (5,120) ((PRIT(I,J),J=1,NCOL),I=1,NROW)
IF (NCOL.EC.13) WRITE (5,130) ((PRIT(I,J),J=1,NCOL),I=1,NROW)
IF (NCOL.EC.14) WRITE (5,140) ((PRIT(I,J),J=1,NCOL),I=1,NROW)
IF (NCOL.EC.15) WRITE (5,150) ((PRIT(I,J),J=1,NCOL),I=1,NROW)
IF (NCOL.EC.16) WRITE (5,160) ((PRIT(I,J),J=1,NCOL),I=1,NROW)
RETURN
-----
FORMAT (F12.5)
FORMAT (2F12.5)
FORMAT (3F12.5)
FORMAT (4F12.5)
FORMAT (5F12.5)
FORMAT (6F12.5)
FORMAT (6F12.5,/,F12.5,/,/)
FORMAT (6F12.5,/,2F12.5,/,/)
FORMAT (6F12.5,/,3F12.5,/,/)
FORMAT (6F12.5,/,4F12.5,/,/)
FORMAT (6F12.5,/,5F12.5,/,/)
FORMAT (6F12.5,/,6F12.5,/,/,F12.5,/,/)
FORMAT (6F12.5,/,6F12.5,/,/,2F12.5,/,/)
FORMAT (6F12.5,/,6F12.5,/,/,3F12.5,/,/)
FORMAT (6F12.5,/,6F12.5,/,/,4F12.5,/,/)
END
=====
C SUBROUTINE RDMATF -- READS THE FLAGS AND MATRIX SIZES FROM
C THE DATA FILE CN FILEDEF 9. ASKS IF YOU WANT TO USE THE MATRICES.
C=====
SUBROUTINE RDMATF (NS,NC,NOB,NG,ISAF,ISAG,ISAM,ISAA,ISAB,IRDMAT,INO,IAN,S,K
1AT)
DATA IYES,'Y',IND,'N'
INTEGER NS,NC,NOB,NG,ISAF,ISAG,ISAH,ISAM,IRDMAT,INO,IAN,S,K
REWIND 9
READ (5,24C,END=30,EPR=30) K,IAN
IF (IAN.EC.1) GO TO 10
GO TO 30
READ (9,25C) NS,NC,NOB,NG
WRITE (5,255)
CALL FRTCM5 ('CLRSCRN ')
CALL RDCINT (IAN)
IF (IAN.GT.3) GO TO 30
IF (IAN.EC.3) GO TO 30
IRDMAT=1
IF (IAN.EC.2) GO TO 40
ISAF=1
ISAG=1

```



```

1//5X, 'RUN TO BE USED IN THIS RUN?'
2MATRIX, 'WILL BE REDISPLAYED AT //5X, 34H THE PROPER INPUT SEQUENCE INTOPT411290
3SERVAL, //5X, 40H AND YOU WILL HAVE THE OPTION OF CHANGING, //5X, 27H INTOPT411300
4INDIVIDUAL MATRIX ELEMENTS, //15X, 19H TYPE "YES" OR "NO" INTOPT411310
FORMAT (//5X, 52H DO YOU WISH TO SAVE THE "GAMMA" MATRIX FROM THE OPT411320
LAST //5X, 'RUN TO BE USED IN THIS RUN?' INTOPT411330
1THE MATRIX, 'WILL BE REDISPLAYED AT //5X, 34H THE PROPER INPUT SEQUENCE INTOPT411340
2SERVAL, //5X, 40H AND YOU WILL HAVE THE OPTION OF CHANGING, //5X, 27H INTOPT411350
4INDIVIDUAL MATRIX ELEMENTS, //15X, 19H TYPE "YES" OR "NO" INTOPT411360
FORMAT (//5X, 52H DO YOU WISH TO SAVE THE "A" MATRIX FROM THE LAST OPT411370
1//5X, 'RUN TO BE USED IN THIS RUN?' INTOPT411380
2SERVAL, 'WILL BE REDISPLAYED AT //5X, 34H THE PROPER INPUT SEQUENCE INTOPT411390
4INDIVIDUAL MATRIX ELEMENTS, //15X, 19H TYPE "YES" OR "NO" INTOPT411400
FORMAT (//5X, 52H DO YOU WISH TO SAVE THE "B" MATRIX FROM THE LAST OPT411410
1//5X, 'RUN TO BE USED IN THIS RUN?' INTOPT411420
2SERVAL, 'WILL BE REDISPLAYED AT //5X, 34H THE PROPER INPUT SEQUENCE INTOPT411430
4INDIVIDUAL MATRIX ELEMENTS, //15X, 19H TYPE "YES" OR "NO" INTOPT411440
FORMAT (//5X, 52H DO YOU WISH TO SAVE THE "C" MATRIX FROM THE LAST OPT411450
1//5X, 'RUN TO BE USED IN THIS RUN?' INTOPT411460
2SERVAL, 'WILL BE REDISPLAYED AT //5X, 34H THE PROPER INPUT SEQUENCE INTOPT411470
4INDIVIDUAL MATRIX ELEMENTS, //15X, 19H TYPE "YES" OR "NO" INTOPT411480
FORMAT (1X, 51H WARNING: IMPROPER DATA ENTRY ENTER "YES" OR "NO" INTOPT411490
END OPT411500
C===== OPT411510
C SUBROUTINE RDMAT -- READS THE F, G, H, GAM, A AND B MATRICES FROM OPT411520
C MATRICES FROM THE DATA FILE OPTMAT ON FILE DEF 9. = OPT411530
C===== OPT411540
SUBROUTINE RDMAT(BA,G,H,GAM,FBGC,FBGE,AY,B,NS,NC,NG,IRDMAT) OPT411550
IMPLICIT REAL*8(A-H,C-Z) OPT411560
DIMENSION BA(NS,NS),G(NS,NC),H(NO,NS),GAM(NS,NG),FBGC(AC,NS), OPT411570
LAY(NO,NO),B(NC,NC),FBGE(NS,NO) OPT411580
IF(IRDMAT.EC.0) RETURN OPT411590
IF(IND 9) K=1,ANS OPT411600
READ (9,20) K,ANS OPT411610
READ (9,10) ((BA(I,J),J=1,NS),I=1,NS) OPT411620
READ (9,10) ((G(I,J),J=1,NC),I=1,NS) OPT411630
READ (9,10) ((H(I,J),J=1,NG),I=1,NS) OPT411640
READ (9,10) ((GAM(I,J),J=1,NS),I=1,NS) OPT411650
READ (9,10) ((FBGC(I,J),J=1,NC),I=1,NS) OPT411660
READ (9,10) ((FBGE(I,J),J=1,NO),I=1,NO) OPT411670
READ (9,10) ((LAY(I,J),J=1,NC),I=1,NC) OPT411680
READ (9,10) ((B(I,J),J=1,NC),I=1,NC) OPT411690
RETURN OPT411700
C----- OPT411710
10 FORMAT(4D2C.13) OPT411720
20 FCRMAT(415) OPT411730
END OPT411740
C----- OPT411750
C SUBROUTINE WRDMAT -- WRITES THE F, G, HO & GAM MATRICES TO = OPT411760

```


APPENDIX C
OPTGRAPH PROGRAM LISTING

This portion of the thesis contains the OPTGRAPH FORTRAN program (54 pages).


```

3C      CALL FRTCMS('CLRSCRN ')
        WRITE(6,92C)
        WRITE(6,750)
        WRITE(6,76C)
        CALL RCINT(IANS)
        IF(IANS.GT.4000.IANS.LT.1) GO TO 34
        GO TO 36
34      WRITE(6,505)
        GO TO 35
36      CCNTINUE
        IF(IANS.EQ.1) IFL = 10
        IF(IANS.EQ.2) IFL = 1
        IF(IANS.EQ.3) IFL = 4
        IF(IANS.EQ.4) GO TO 95
C-----
C-----
        READ(IFL,10C) IA,IB,NS,NC,NOB,IE,ITFX
        IF(IE.EQ.0) GO TO 41
        IF(ITFX.EQ.1) WRITE(6,510)
        IF(ITFX.EQ.2) WRITE(6,511)
        IF(ITFX.EQ.3) WRITE(6,512)
        GO TO 35
41      IF(NS.EQ.0) GO TO 42
        WRITE(6,513)
        GO TO 35
42      IF(NC.EQ.0) GO TO 43
        IF(ITFX.EQ.1) WRITE(6,515)
        IF(ITFX.EQ.2) WRITE(6,517)
        IF(ITFX.EQ.3) WRITE(6,516)
        GO TO 35
43      IF(NOB.EQ.0) GO TO 44
        IF(ITFX.EQ.1) WRITE(6,516)
        IF(ITFX.EQ.2) WRITE(6,516)
        IF(ITFX.EQ.3) WRITE(6,515)
        GO TO 35
C-----
C-----
        MARKCV CRITERIA FOR DETERMINING EXTRANEOUS ZEPES
44      IF(IE.EQ.0) IE = 6
        CC = 10.**( -IE)
C-----
C-----
        DENOMINATOR
        CC 50 I = 1,NS
5C      REAC(IFL,120) OLD(I,1),OLD(I,2)
        CCNTINUE
C-----
C-----
        NUMERATOR / GAIN / ORDER
        NN = NOB*NC
        DO 90 I = 1,NN
        READ(IFL,10C) KK,K2,K1
        READ(IFL,12C) GAN(1,K2,K1),GAN(2,K2,K1)
        IF(GAN(1,K2,K1).NE.0.0) GO TO 72
        GO TO 960

```

```

DC 70 LL = 1,NS
CLN(LL,1,K2,K1) = 0.0C
CLN(LL,2,K2,K1) = 0.0C
CCNTINUE
GC TO 75
CCNTINUE
DO 75 LL = 1,NS
  READ(IFL,120) OLN(LL,1,K2,K1),OLN(LL,2,K2,K1)
CCNTINUE
CALL GRAPH(NS,NC,NOB,IE,ITFX)
GC TO 30
CALL DCNEPL
STOP
-----
100 FORMAT(11,I4,515)
101 FORMAT(5X,215)
120 FORMAT(5X,2030.14)
120C FORMAT(5X,215)
509 FORMAT(/,5X,***** ERROR *****//,10X,'IMPROPER DATA ENTRY',/)
510 *'PROPER DATA FILE IS NOT AVAILABLE FOR OPEN LOOP TF ANALYSIS')
511 FORMAT(/,5X,***** ERROR *****//,10X,'IMPROPER DATA ENTRY',/)
512 *'PROPER DATA FILE IS NOT AVAILABLE FOR NOISE TF ANALYSIS')
513 *'PROPER DATA FILE IS NOT AVAILABLE FOR CCNFSATOR TF ANALYSIS')
515 *'MUST INPUT "F" MATRIX IN OPTSYSX PROGRAM')
515 *'MUST INPUT "G" MATRIX IN OPTSYSX PROGRAM')
516 *'MUST INPUT "H" MATRIX IN OPTSYSX PROGRAM')
517 *'MUST INPUT "GAMMA" MATRIX IN OPTSYSX PROGRAM')
750 *'MUST INPUT "CO YOU DESIRE TO ANALYZE: ',/
*10X,1.0, 'OPEN LOOP TRANSFER FUNCTION',/
*10X,2.0, 'CCNFSATOR TRANSFER FUNCTION',/
*10X,3.0, 'EXIT OPTGRAPH',/
*10X,4.0, 'EXIT OPTGRAPH',/
FORMAT(5X, 'ENTER OPTION NUMBER.',/
FORMAT(/,20X,'OPTGRAPH',//)
END
=====
C
SUBROUTINE GRAPH(NS,NC,NOB,IE,ITFX)
C
CALLS GRAPHICS ROUTINES FOR POLE-ZERO PLOTS, ROOT LOCUS, AND

```



```

C-----POLE-ZERO-----OPT01930
110 CALL PZERO(NS,JJ,II,ITFX)OPT01940
GO TO 100OPT01950
C-----ROOT LOCUS-----OPT01960
120 CALL RTLC(NS,JJ,II,ITFX)OPT01970
GO TO 100OPT01980
C-----BODE-----OPT01990
130 CALL BCDE(NS,JJ,II,ITFX)OPT02000
GO TO 100OPT02010
C-----NYQUIST-----OPT02020
140 CALL NYQST(NS,JJ,II,ITFX)OPT02030
GO TO 100OPT02040
C-----NICHOLS-----OPT02050
150 CALL NICHOL(NS,JJ,II,ITFX)OPT02060
GO TO 100OPT02070
C-----EXIT OPGRAPH-----OPT02080
160 CONTINUEOPT02090
RETURNOPT02100
500 FORMAT(//,5X,***** WARNING *****//,5X,'IMPRPER DATA ENTRY ',OPT02110
*3X,'ENTER "YES" OR "NO".',//)OPT02120
509 FORMAT(//,5X,***** ERROR *****//,10X,'IMPROPER DATA ENTRY',//)OPT02130
510 FORMAT(//,1X,WARNING: THE TRANSFER FUNCTION INPUT# MUST NOT BE LESSOPT02140
* THAN 1 NOR GREATER THAN 13,TRANSFER,)//OPT02150
520 FORMAT(//,1X,WARNING: THE TRANSFER FUNCTION OUTPUT# MUST NOT BE LESSOPT02160
* THAN 1 NOR GREATER THAN 13,TRANSFER,)//OPT02170
600 FORMAT(//,5X,'AN OPEN LOOP POLE-ZERO, ROOT, LCCLS, BODE, NYQUIST,OPT02180
* AND/OR NICHOLS, //,5X,'PLOT IS DESIRED FOR:',//)OPT02190
610 FORMAT(//,10X,'INPUT # ?')OPT02200
620 FORMAT(//,10X,'INPUT # ?')OPT02210
710 FORMAT(//,5X,'OPEN LCCF TRANSFER FUNCTION',//)OPT02220
711 FORMAT(//,5X,'NOISE TRANSFER FUNCTION',//)OPT02230
712 FORMAT(//,5X,'COMPENSATOR TRANSFER FUNCTION',//)OPT02240
720 FORMAT(//,10X,'INPUT # =,13)OPT02250
730 FORMAT(//,10X,'OUTPUT # =,13)OPT02260
750 FORMAT(//,5X,'DO YOU DESIRE GRAPHICAL RESPONSE AND/OR TABULAR DATAOPT02270
* FOR:',//,PCLE-ZERO MAP',//,OPT02280
*10X,1. RECT-LOCUS',//,OPT02290
*10X,2. BODE',//,OPT02300
*10X,3. NYQUIST (POLAR PLOT)',//,OPT02310
*10X,4. NICHOLS',//,OPT02320
*10X,5. ANOTHER INPUT/OUTPUT COMBINATION (SAME TRANSFER FUNCTION)OPT02330
*10X,6. ANOTHER TYPE TRANSFER FUNCTION /EXIT CPTGRAPH')OPT02340
*10X,7. ANOTHER OPTION NUMBER,')OPT02350
760 FORMAT(//,5X,'ENTER OPTION NUMBER,')OPT02360
500 FORMAT(//,20X,'OPGRAPH',//)OPT02370
501 FORMAT(//,5X,'THE OPEN LOOP TRANSFER SYSTEM OBTAINED FROM CPTSYS CONTOPT02380
OPT02390
OPT02400

```

```

902 #AINS:','//)
903 #FORMAT(5X,'THE NOISE TRANSFER SYSTEM OBTAINED FROM OPTSYS CONTAINS
904 #NTAINS:','//)
905 #FORMAT(5X,'THE COMPENSATOR TRANSFER SYSTEM OBTAINED FROM OPTSYS CO
906 #NTAINS:','//)
907 #FOR4AT(10X,'1. NUMBER OF STATES = ',I3,/,
908 #10X,'2. NUMBER OF MEASUREMENTS (OUTPUTS) = ',I3,/,
909 #10X,'3. NUMBER OF MARKOV PARAMETERS = 10.0*-',I2,/,
910 #15X,'CLEAR SCREEN TO CONTINUE',//////////)
911
912 C-----
913 END
914
915 C-----
916 SUBROUTINE FZERO (NS,K2,K1,ITFX)
917 INTERACTIVELY PLOTS A POLE-ZERO PLOT USING DISSPLA GRAPHICS GIVEN
918 THE ZERO AND POLE LOCATIONS
919
920 C-----
921 REAL*8 OLN,CLD,ORNUM,GAN,CO,ZERO
922 REAL*4 XDC,YDC,XNO,YNO,XMIN,XMAX,YMIN,YMAX,XAXIS,YAXIS,PAGEX,
923 PAGEY,XX,YY,GOL,XL,YL,TS,TH,TH1,T1,T2,T3,T4,T5,T6,T7,T8,T9,T10
924 INTEGER NS,IPTR,K1,K2,NN,NL,LINES,IANS,ICHG,LINE,J1,ORD,LL,
925 IPT,IPP,IZR,ITFX
926 COMMON /GRAFF/ OLN(55,2,12,12),OLD(99,2),GAN(2,12,12),CC
927 COMMON /SGRAF/ XDO(500),YDO(500),XNO(500),YNO(500)
928 COMMON /SHEAD/ LINES(4,18),LINE(9)
929 COMMON /SCALE/ TS,TH,TH1,T1,T2,T3,T4,T5,T6,T7,T8,T9,T10
930 DATA IV,Y/,I2,N/,
931
932 C-----
933 CALL FRTCMS('CLRSCRN')
934 WRITE(6,12C)
935 IF(ITFX.EQ.1) WRITE(6,710)
936 IF(ITFX.EQ.2) WRITE(6,711)
937 IF(ITFX.EQ.3) WRITE(6,712)
938 CALL PRTPLOT(IPP)
939 GO TO (201,202,80),IPP
940
941 C-----
942 J1 = 0
943 CC 5 LL = 1,NS
944 XNO(LL) = C.O
945 YNO(LL) = C.O
946 XDO(LL) = SAGL(OLD(LL,1))
947 YDO(LL) = SAGL(OLD(LL,2))
948 IF(DABS(OLN(LL,1,K2,K1)).LE.CO).AND.(DABS(OLN(LL,2,K2,K1)).LE.CO)
949 * GO TO 6
950 J1 = J1+1
951 XNO(J1) = SAGL(OLN(LL,1,K2,K1))
952 YNO(J1) = SAGL(OLN(LL,2,K2,K1))

```

```

CONTINUE
ORD = DINT (GAN(1,K2,K1))
IF (ORD.GT.J1) J1 = ORD
GOL = SNGL (GAN(2,K2,K1))

C-----PLOT SETUP-----
4C
ICHG = 0
CALL FRTCMS('CLRSCRN')
IF (ICHG.EQ.1) GO TO 41
WRITE(6,120)
IF (ITFX.EQ.1) WRITE(6,710)
IF (ITFX.EQ.2) WRITE(6,711)
IF (ITFX.EQ.3) WRITE(6,712)
CALL GSETUP(IPTR,PAGEX,PAGEY)
IF (ICHG.EQ.1) GC TO 50
5C
CALL FRTCMS('CLRSCRN')
CALL GGRAF(XMIN,XMAX,YMIN,YMAX)
IF (ICHG.EQ.1) GO TO 50
6C
CALL FRTCMS('CLRSCRN')
CALL GHEAD(1)
IF (ICHG.EQ.1) GO TO 90
7C
CONTINUE
IF (IPTR.EQ.2) GO TO 10
C-----TEK 618-----
CALL TEK618
CALL PAGE(PAGEX,PAGEY)
CALL HWRGT('AUTO')
CALL HWSCL('SCREEN')
CALL NCBDR
GC TO 20
C-----COMPRS-----
1C
CONTINUE
CALL COMPRS
CALL PAGE(PAGEX,PAGEY)
2C
CONTINUE
C-----SCALING CONSTANTS-----
CALL PSCL(PAGEY)
C-----PLOT EXECUTION-----
CALL NOCHEK
CALL GRACE(C)
CALL PHYSOR(T1,T1)
XAXIS = PAGEY - 2.*T1
YAXIS = PAGEY - T1 - T2
CALL AREA2C(XAXIS, YAXIS)
CALL TRIPLX
CALL HEIGHT(TH)
CALL XNAME(' $',100)
CALL HEIGHT(TH)

```

```

OPT02890
OPT02900
OPT02910
OPT02920
OPT02930
OPT02940
OPT02950
OPT02960
OPT02970
OPT02980
OPT02990
OPT03000
OPT03010
OPT03020
OPT03030
OPT03040
OPT03050
OPT03060
OPT03070
OPT03080
OPT03090
OPT03100
OPT03110
OPT03120
OPT03130
OPT03140
OPT03150
OPT03160
OPT03170
OPT03180
OPT03190
OPT03200
OPT03210
OPT03220
OPT03230
OPT03240
OPT03250
OPT03260
OPT03270
OPT03280
OPT03290
OPT03300
OPT03310
OPT03320
OPT03330
OPT03340
OPT03350
OPT03360

```



```

CALL YNAME(' $',100)
CALL GRAF(XMIN,SCALE,XMAX,YMIN,SCALE,YMAX)
XL = (XMAX-XMIN)*0.1
YL = (YMAX-YMIN)*0.1
CALL RLVEC(XMAX+XL,0.0,XMIN-XL,0.0,0000)
CALL RLVEC(C.0,YMAX+YL,0.0,YMIN-YL,0000)
HEADING
C-----
NN = NL + 1
IF(NL.EQ.0) GO TO 35
DC 35 I=1,NL
CALL CLINE(I)
CALL HEADIN(LINE,100,T3,NN)
35 CONTINUE
IF(ITFX.EQ.1)
* CALL HEADIN('OPEN LOOP TRANSFER POLE-ZERO MAP$',100,T3,NN)
* IF(ITFX.EQ.2)
* CALL HEADIN('NOISE TRANSFER POLE-ZERO MAP$',100,T3,NN)
* IF(ITFX.EQ.3)
* CALL HEADIN('COMPENSATOR TRANSFER POLE-ZERO MAP$',100,T3,NN)
C-----
CALL MARKER(4)
CALL SCLPIC(2)
CALL CURVE(XDO,YDO,NS,-1)
C-----
IF(J1.EQ.0) GO TO 36
CALL MARKER(16)
CALL SCLPIC(2)
CALL CURVE(XNO,YNO,J1,-1)
36 CONTINUE
C-----
XX = XAXIS - T7
YY = YAXIS + T8
CALL HEIGHT(TH1)
CALL MESSAG('INPUT # = $',100,XX+T8,YY+T10)
CALL HEIGHT(TH1)
CALL INTNO(K1,'ABUT','ABUT')
CALL HEIGHT(TH1)
CALL MESSAG('OUTPUT # = $',100,XX+T8,YY+T9)
CALL HEIGHT(TH1)
CALL INTNO(K2,'ABUT','ABUT')
CALL HEIGHT(TH1)
CALL MESSAG('DC GAIN = $',100,XX+T8,YY+T8)
CALL HEIGHT(TH1)
CALL REALNC(GOL,-3,'ABUT','ABUT')
CALL BLREC(XX,YY,T5,T6,3.32)
C-----
CALL DCT
C-----
GRIC
C-----

```

```

CALL GRID(1,1)
CALL RESET('DOT')
CALL ENDPL(0)
IF(IPTR.NE.2) GO TO 50
CALL FRTCMS('CLRSCRN ')
WRITE(6,130)
-----CHANGES TO FLCT-----
5C
CCNT INUE
CALL FRTCMS('CLRSCRN ')
WRITE(6,120)
IF(ITFX.EQ.1) WRITE(6,710)
IF(ITFX.EQ.2) WRITE(6,711)
IF(ITFX.EQ.3) WRITE(6,712)
IF(ITE(6,120))
WRITE(6,120)
CALL RDINT(IANS)
IF(IANS.GT.500.IANS.LT.1) GO TO 15
GO TO 25
WRITE(6,510)
GO TO 30
CCNT INUE
ICHG = 1
GO TO (40,50,60,70,200),IANS
-----TABULAR DATA-----
202
CCNT INUE
J1 = 0
CRD = 0
DINT(GAN(1,K2,K1))
ZERO = 0
CALL FRTCMS('CLRSCRN ')
WRITE(6,120)
IF(ITFX.EQ.1) WRITE(6,710)
IF(ITFX.EQ.2) WRITE(6,711)
IF(ITFX.EQ.3) WRITE(6,712)
CALL PRTR(IPT)
CALL FRTCMS('CLRSCRN ')
WRITE(6,120)
IF(ITFX.EQ.1) WRITE(IPT,710)
IF(ITFX.EQ.2) WRITE(IPT,711)
IF(ITFX.EQ.3) WRITE(IPT,712)
K1
K2
NS
WRITE(IPT,301)
WRITE(IPT,302)
WRITE(IPT,303)
WRITE(IPT,304)
WRITE(IPT,305)
WRITE(IPT,306)
WRITE(IPT,307)
WRITE(IPT,308)
WRITE(IPT,309)
WRITE(IPT,310)
WRITE(IPT,311)
WRITE(IPT,312)
WRITE(IPT,313)
WRITE(IPT,314)
WRITE(IPT,315)
WRITE(IPT,316)
WRITE(IPT,317)
WRITE(IPT,318)
WRITE(IPT,319)
WRITE(IPT,320)
WRITE(IPT,321)
WRITE(IPT,322)
WRITE(IPT,323)
WRITE(IPT,324)
WRITE(IPT,325)
WRITE(IPT,326)
WRITE(IPT,327)
WRITE(IPT,328)
WRITE(IPT,329)
WRITE(IPT,330)
WRITE(IPT,331)
WRITE(IPT,332)
WRITE(IPT,333)
WRITE(IPT,334)
WRITE(IPT,335)
WRITE(IPT,336)
WRITE(IPT,337)
WRITE(IPT,338)
WRITE(IPT,339)
WRITE(IPT,340)
DO 210 I = 1,NS
WRITE(IPT,340) OLD(I,1),OLD(I,2)
IF(ORD.EQ.0) GO TO 220
21C

```

```

110 WRITE(IPT,310) ORD
120 WRITE(IPT,350)
130 WRITE(IPT,340)
140 DO 220 I=1,INS
150 IF((DABS(OLN(I,1,K2,K1)).LE.CG).AND.(DABS(OLN(I,2,K2,K1)).LE.CO)
160 *) GO TO 220
170 J1=J1+1
180 WRITE(IPT,320) CLN(I,1,K2,K1),OLN(I,2,K2,K1)
190 CONTINUE
200 IZR=ORD - J1
210 IF (IZR.LE.C) GO TO 240
220 LC 225 I=1,IZR
230 WRITE(IPT,330) ZERO, ZERO
240 GO TO 240
250 WRITE(IPT,350)
260 WRITE(IPT,360)
270 -----CHANGES FOR TABULAP DATA-----
280 IF (IPT.EQ.2) WRITE (6,401)
290 IF (IPT.EQ.2) WRITE (6,402)
300 WRITE (6,400)
310 CALL RCHAR (IANS)
320 IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 245
330 GO TO 250
340 WRITE (6,500)
350 GO TO 240
360 CONTINUE
370 IF (IANS.EC.IY) GO TO 202
380 IF (IANS.EC.IZ) GO TO 200
390 RETURN
400 -----
410 FORMAT (//,5X,'DO YOU DESIRE TO MAKE ANY CHANGES TO:',//,10X,'1. GRAPH LIMITS',//,10X,'2. GRAPH SIZE',//,10X,'3. PLOT POLE-ZERO MAP',//,10X,'4. EXIT POLE-ZERO PLOTTING ROUTINE',//,10X,'5. NO CHANGES - ENTER OPTION NUMBER.',//)
420 FORMAT (//,5X,'ENTER OPTION NUMBER.',//)
430 FORMAT (//,10X,'POLE-ZERO MAP',//,10X,'1. DISPLA METAFILE HAS BEEN CREATED',//,10X,'2. CLEAR SCREEN TO CONTINUE',//,10X,'3. INPUT NUMBER =',//,10X,'4. OUTPUT NUMBER =',//,10X,'5. NUMERATOR ORDER =',//,10X,'6. DENOMINATOR ORDER =',//,10X,'7. TRANSFER FUNCTION (DC) GAIN =',//,10X,'8. PARTIAL ZERO LOCATIONS',//,10X,'9. REAL POLE LOCATIONS',//,10X,'10. IMAGINARY PART',//)
440 FORMAT (5X,'POLE LOCATIONS')
450
460
470
480
490
500
510
520
530
540
550
560
570
580
590
600
610
620
630
640
650
660
670
680
690
700
710
720
730
740
750
760
770
780
790
800
810
820
830
840
850
860
870
880
890
900
910
920
930
940
950
960
970
980
990

```

171

```

41 IF(ITFX.EQ.2) WRITE(6,711)
   IF(ITFX.EQ.3) WRITE(6,712)
   CALL GSETUP(IPTR,PAGEX,PAGEY)
5C IF(ICHG.EQ.1) GO TO 90
   CALL FRTCMS(,CLRSCRN, ,)
55 CALL GGRAF(XMIN,XMAX,YMIN,YMAX)
   IF(ICHG.EQ.1) GO TO 90
   CALL FRTCMS(,CLRSCRN, ,)
6C CALL RANGK(KMIN,KMAX)
   IF(ICHG.EQ.1) GO TO 90
   CALL FRTCMS(,CLRSCRN, ,)
7C CALL GHEAD(NL)
   IF(ICHG.EQ.1) GO TO 90
   CONTINUE
   IF(IPTR.EQ.2) GO TO 10
   -----TEK 618-----
   CALL TEK61E
   CALL PAGE(PAGEX,PAGEY)
   CALL HWRGT(,AUTO, ,)
   CALL HWSCL(,SCREEN, ,)
   CALL NCBRDF
   GO TO 20
   -----COMFRS-----
1C CONTINUE
   CALL COMPRS
   CALL PAGE(PAGEX,PAGEY)
2C CONTINUE
   -----SCALING CONSTANTS-----
   CALL PSCALE(PAGEX)
   -----PLOT EXECUTION-----
   CALL NCHEK
   CALL GRACE(C, ,)
   CALL PHYSOR(T1,T1)
   CALL XAXIS = PAGEY - T1 - T2
   CALL YAXIS = PAGEY - T1 - T2
   CALL AREA2C(XAXIS, YAXIS)
   CALL TRIPLX
   CALL HEIGHT(TH)
   CALL XNAME(, $, ,100)
   CALL YNAME(, $, ,100)
   CALL GGRAF(XMIN,SCALE',XMAX,YMIN,SCALE',YMAX)
   XL = (XMAX-XMIN)*0.1
   YL = (YMAX-YMIN)*0.1
   CALL RLVEC(XMAX+XL,0.0,XMIN-XL,0.0,0000)
   CALL PLVEC(C.0,YMAX+YL,0.0,YMIN-YL,0000)
   -----HEADING-----
   NN = NL + 1

```

```

OPT05290
OPT05300
OPT05310
OPT05320
OPT05330
OPT05340
OPT05350
OPT05360
OPT05370
OPT05380
OPT05390
OPT05400
OPT05410
OPT05420
OPT05430
OPT05440
OPT05450
OPT05460
OPT05470
OPT05480
OPT05490
OPT05500
OPT05510
OPT05520
OPT05530
OPT05540
OPT05550
OPT05560
OPT05570
OPT05580
OPT05590
OPT05600
OPT05610
OPT05620
OPT05630
OPT05640
OPT05650
OPT05660
OPT05670
OPT05680
OPT05690
OPT05700
OPT05710
OPT05720
OPT05730
OPT05740
OPT05750
OPT05760

```

```

IF(NL.EQ.0) GO TO 35
DC 35 I=1,NL
CALL CLINE(I)
CALL HEADIN(LINE,100,T3,NN)
35 CONTINUE
IF(ITFX.EQ.1)
* CALL HEADIN('ROOT-LOCUS PLOT (OPEN LOOP TF)',100,T3,NN)
* IF(ITFX.EQ.2)
* CALL HEADIN('ROOT-LOCUS PLOT (NCISE TF)',100,T3,NN)
* IF(ITFX.EQ.3)
* CALL HEADIN('ROOT-LOCUS PLOT (COMPENSATOR TF)',100,T3,NN)
C-----INPUT ARRAYS-----
ZERO = 0.0
J1 = 0
ND1 = NS + 1
ND2 = NS + 2
DC 5 LL = 1,NS
XNO(LL) = C.O
YNO(LL) = C.O
QT(LL) = 0.0
GR(LL) = 0.0
XDO(LL) = SGL(OLD(LL,1))
YDO(LL) = SGL(OLD(LL,2))
RTD(LL) = SGL(OLD(LL,1),OLD(LL,2))
RTN(LL) = SGL(OLD(LL,1),OLD(LL,2))
IF((DABS(OLN(LL,1,K2,K1)).LE.CO).AND.(DABS(OLN(LL,2,K2,K1)).LE.CO))
* GO TO 6
J1 = J1 + 1
XNO(J1) = SGL(OLN(LL,1,K2,K1))
YNO(J1) = SGL(OLN(LL,2,K2,K1))
RTN(J1) = SGL(OLN(LL,1,K2,K1),OLN(LL,2,K2,K1))
CCNTINUE
ORD = DINT(GAN(1,K2,K1))
IF(ORD.GT.J1) J1 = ORD
GOL = SGL(GAN(2,K2,K1))
GAIN = GAN(2,K2,K1)
C-----POLE-----
CALL MARKER(4)
CALL SCLPIC(2,1)
CALL CURVE(XDO,YDO,NS,-1)
C-----ZERO-----
IF(J1.EQ.0) GO TO 36
CALL MARKER(16)
CALL SCLPIC(2,1)
CALL CURVE(XNO,YNO,J1,-1)
36 CONTINUE
C-----POLYNOMIALS-----
OPT05770
OPT05780
OPT05790
OPT05800
OPT05810
OPT05820
OPT05830
OPT05840
OPT05850
OPT05860
OPT05870
OPT05880
OPT05890
OPT05900
OPT05910
OPT05920
OPT05930
OPT05940
OPT05950
OPT05960
OPT05970
OPT05980
OPT05990
OPT06000
OPT06010
OPT06020
OPT06030
OPT06040
OPT06050
OPT06060
OPT06070
OPT06080
OPT06090
OPT06100
OPT06110
OPT06120
OPT06130
OPT06140
OPT06150
OPT06160
OPT06170
OPT06180
OPT06190
OPT06200
OPT06210
OPT06220
OPT06230
OPT06240

```

C-----	CALL MAKPOL(NS,RTD,PLD)	-----DENOMENATOR-----	OPT06250
	CI(1) = 1.0		OPT06260
7	DO 7 I = 2,ND1		OPT06270
C-----	QI(I) = CREAL(PLD(ND2-I))	-----NUMERATOR-----	OPT06280
	IF(J1.EQ.0) GO TO 9		OPT06290
	CALL MAKPOL(J1,RTN,PLN)		OPT06300
	JJ = NS - J1 + 2		OPT06310
	QR(JJ-1) = 1.0		OPT06320
	DO 8 I = JJ,ND1		OPT06330
8	QR(I) = CREAL(PLN(ND2-I))		OPT06340
	GO TO 11		OPT06350
9	QR(ND1) = 1.0		OPT06360
	QR(1) = 0.0		OPT06370
C-----		-----ROOT FINDING ROUTINE-----	OPT06380
11	KIC = (KMAX-KMIN)/2000.		OPT06390
	K = KMIN		OPT06400
	DC 52 J = 1,2000		OPT06410
	DO 37 II = 1,ND1		OPT06420
	MAG(II) = CI(II) + K*GAIN*QR(II)		OPT06430
27	CONTINUE		OPT06440
	CALL ZRPOLY(MAG,NS,MN,IER)		OPT06450
	DO 51 II = 1,NS		OPT06460
	XR = DREAL(MN(II))		OPT06470
	XND(II) = SNGL(XR)		OPT06480
	YI = DIMAG(MN(II))		OPT06490
	YND(II) = SNGL(YI)		OPT06500
51	CONTINUE		OPT06510
	CALL MARKER(4)		OPT06520
	CALL SCLPIC(1.0)		OPT06530
	CALL CURVE(XND,YND,NS,-1)		OPT06540
	K=K+KIC		OPT06550
52	CONTINUE		OPT06560
C-----		-----LEGEND-----	OPT06570
	XX = XAXIS - T7		OPT06580
	YY = YAXIS + T8		OPT06590
	CALL HEIGHT(TH1)		OPT06600
	CALL MESSAG('INPUT # = \$',100,XX+T8,YY+T10)		OPT06610
	CALL HEIGHT(TH1)		OPT06620
	CALL INTNO(K1,'ABUT','ABUT')		OPT06630
	CALL HEIGHT(TH1)		OPT06640
	CALL MESSAG('OUTPUT # = \$',100,XX+T8,YY+T5)		OPT06650
	CALL INTNO(K2,'ABUT','ABUT')		OPT06660
	CALL HEIGHT(TH1)		OPT06670
	CALL MESSAG('DC GAIN = \$',100,XX+T8,YY+T8)		OPT06680
	CALL HEIGHT(TH1)		OPT06690
	CALL MESSAG('DC GAIN = \$',100,XX+T8,YY+T8)		OPT06700
	CALL HEIGHT(TH1)		OPT06710
	CALL MESSAG('DC GAIN = \$',100,XX+T8,YY+T8)		OPT06720

```

C-----GRID-----
CALL REALNC(GOL,-3,'ABUT','ABUT')
CALL BLREC(X,Y,Y,15,16,0.02)
CALL DOT
CALL GRID(1,1)
CALL RESET('DOT')
CALL ENOPL(C)
IF(IPTR.NE.2) GO TO 90
CALL FRTCMS('CLRSCRN')
WRITE(6,13C)
C-----CHANGES TO PLOT-----
C
CONTINUE
CALL FRTCMS('CLRSCRN')
WRITE(6,120)
IF(ITFX.EQ.1) WRITE(6,710)
IF(ITFX.EQ.2) WRITE(6,711)
IF(ITFX.EQ.3) WRITE(6,712)
WRITE(6,110)
CALL PCINT(IANS)
IF(IANS.GT.600.IANS.LT.1) GO TO 15
GO TO 25
15 WRITE(6,510)
GO TO 30
25 CONTINUE
ICHG = 1
GO TO (40,50,60,55,70,200),IANS
C-----TABULAR DATA-----
202 CONTINUE
ICHG = 0
CALL FRTCMS('CLRSCRN')
IF(ICHG.EQ.1) GO TO 249
WRITE(6,120)
IF(ITFX.EQ.1) WRITE(6,710)
IF(ITFX.EQ.2) WRITE(6,711)
IF(ITFX.EQ.3) WRITE(6,712)
CALL PTR(IPT)
IF(ICHG.EQ.1) GO TO 290
CALL FRTCMS('CLRSCRN')
CALL RANGK(KMIN,KMAX)
IF(ICHG.EQ.1) GO TO 290
CALL FRTCMS('CLRSCRN')
CALL NPTS(PTS)
IF(ICHG.EQ.1) GO TO 290
C-----TABULATE DATA-----
254 CONTINUE
ZERO = 0.0
J1 = 0

```



```

ND1 = NS + 1
ND2 = NS + 2
ORD = DINT (CAN(1,K2,K1))
CALL FRTCM(2,K2,K1)
WRITE(IPT,120) WRITE(IPT,710)
IF(ITFX.EQ.1) WRITE(IPT,711)
IF(ITFX.EQ.2) WRITE(IPT,712)
WRITE(IPT,720) K1
WRITE(IPT,730) K2
WRITE(IPT,740) CAN(2,K2,K1)
IF(ITFX.EQ.1) WRITE(IPT,121)
IF(ITFX.EQ.2) WRITE(IPT,122)
IF(ITFX.EQ.3) WRITE(IPT,123)
WRITE(IPT,311) NS
WRITE(IPT,320)
WRITE(IPT,330) OLD(1,1),OLD(1,2)
DC 210 I = 1,NS
IF(ORD.EQ.0) GO TO 230
WRITE(IPT,310) ORD
WRITE(IPT,320)
WRITE(IPT,330)
DC 220 I = 1,NS
RDN(I) = DCMPLX(OLD(I,1),OLD(I,2))
IF((DABS(OLD(I,1,K2,K1)).LE.CC).AND.(DABS(OLD(I,2,K2,K1)).LE.CC)
*) GO TO 22C
J1 = J1 + 1
RDN(J1) = CCMPLX(OLD(I,1,K2,K1),OLD(I,2,K2,K1))
WRITE(IPT,340) CLN(I,1,K2,K1),CLN(I,2,K2,K1)
CCNTINUE
IZR = ORD - J1
IF(IZR.LE.C) GO TO 240
DC 225 I = 1,IZR
WRITE(IPT,330) ZER0, ZER0
GO TO 240
WRITE(IPT,350)
WRITE(IPT,360)
C-----POLYNOMIALS-----
240 CONTINUE
CALL MAKPOL(NS,RTD,PLD)
QI(1) = 1.C
CC 207 I = 2,ND1
CI(I) = CREAL(PLD(ND2-I))
C-----NUMERATOR-----
207

```

```

IF(J1.EQ.0) GO TO 205
CALL MAKPOL(J1,RTN,PLN)
JJ = NS - J1 + 2
QP(JJ-1) = 1.0
DO 208 I = JJ,ND1
  QR(I) = CREAL(PLN(ND2-I))
GO TO 211
208 QR(ND1) = 1.0
209 QR(1) = 0.0
C-----ROOT FINDING ROUTINE-----
211 WRITE(IPT,220)
    KIC = (KMAX-KMIN)/DFLCAT(PTS)
    K = KMIN
    DO 262 J = 1,PTS
      DO 237 II = 1,ND1
        MAG(II) = CI(II) + K*GAIN*QR(II)
      CCNT INUE
      CALL ZRPOLY(MAG,NS,WA,IER)
      WRITE(IPT,240)
      DO 261 II = 1,NS
        XR = DREAL(WN(II))
        YI = DIMAG(WN(II))
      WRITE(IPT,230) XR,YI
      CCNT INUE
      K=K+KIC
      CONTINUE
261
262 C-----CHANGES TABULAR DATA-----
241 IF(IPT.EQ.2) WRITE (6,401)
    IF(IPT.EQ.2) WRITE (6,402)
    WRITE(6,400)
    CALL RDCHAR (IANS)
    IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 245
    GO TO 250
245 WRITE (6,500)
    GO TO 241
250 CCNT INUE
    IF (IANS.EQ.IY) GO TO 292
    IF (IANS.EC.IZ) GO TO 200
C-----CHANGES-----
290 CCNT INUE
    CALL FRTCMS('CLRSCRN ')
    WRITE(6,120)
    IF(ITFX.EQ.1) WRITE(6,710)
    IF(ITFX.EQ.2) WRITE(6,711)
    IF(ITFX.EQ.3) WRITE(6,712)
    WRITE(6,410)
291

```



```

6C      CALL FRTCMS('CLRSCRN ')
      CALL GHEAD(NL)
      IF(IJCHG.EQ.1) GO TO 90
      CONTINUE
      -----SCALING CONSTANTS-----
      CALL PSCALE(PAGEX)
      -----INPUT AFRAYS-----
      GOL = SNGL(GAN(2,K2,K1))
      FL = FMIN*.01
      FU = FMAX*.01
      YAXIS = PAGEY - 2.*T1
      YCYCLE = XAXIS/(ALOG10(FMAX)-ALOG10(FMIN))
      CALL FREQ(NS,K2,K1,FMIN,FMAX,N)
      DO 5 I = 1,N
      CMGA = 1/MAG(WN(I))
      XND(I) = SNGL(OMEGA)
      PA = 20.0*LOG10(MAG(I))
      YND(I) = SNGL(MA)
      YDO(I) = SNGL(QPSR(I))
      CONTINUE
      CALL MINMAX(N,YNO,MMIN,MMAX)
      MMIN = AINT(MMIN) - 1.0
      PCYCLE = (PMAX-MMIN)/YAXIS
      MCYCLE = AINT(MCYCLE) + 1.0
      CALL MINMAX(N,YDO,PMIN,PMAX)
      PMIN = AINT(PMIN) - 1.0
      PCYCLE = (FMAX-PMIN)/YAXIS
      PCYCLE = AINT(PCYCLE) + 1.0
      -----MAGNITUDE PLOT-----
      -----TEK 618-----
      IF(IPTR.EQ.2) GO TO 10
      CALL TEK618
      CALL PAGE(PAGEX,PAGEY)
      CALL HWROT('AUTO')
      CALL HNSCAL('SCREEN')
      CALL NOBRDR
      GO TO 20
      -----COMPRS-----
      1C      CONTINUE
      CALL CCMPRS
      CALL PAGE(PAGEX,PAGEY)
      20      CONTINUE
      -----PLOT EXECUTION-----
      CALL NCCHK
      CALL GRACE(C)
      CALL PHYSOR(T1,T1)
      CALL AREA2C(XAXIS, YAXIS)

```

```

CALL TRIPLX
CALL HEIGHT(TH)
CALL XNAME('FREQUENCY - RADIANS PER SECOND $',100)
CALL HEIGHT(TH)
CALL YNAME('MAGNITUDE - DECIBELS $',100)
CALL XLOG(FMIN,FCYCLE,MMIN,MCYCLE)
CALL RLVEC(FMAX+FU,0.0,FMIN-FL,0.0,0000)
C-----HEADING-----
NN = NL + 1
IF(NL.EQ.0) GO TO 35
DO 35 I=1,NL
  CALL CLINE(I)
  CALL HEADIN(LINE,100,T3,NN)
35 CONTINUE
  IF(ITFX.EQ.1)
    * CALL HEADIN('OPEN LOOP TF BODE MAGNITUDE$',100,T3,NN)
  * IF(ITFX.EQ.2)
    * CALL HEADIN('NOISE TF BODE MAGNITUDE$',100,T3,NN)
  * IF(ITFX.EQ.3)
    * CALL HEADIN('COMPENSATOR TF BODE MAGNITUDE$',100,T3,NN)
C-----MAGNITUDE-----
CALL CURVE(XNO,YNO,N,0)
C-----LEGEND-----
XX = XAXIS - T7
YY = YAXIS + T8
CALL HEIGHT(TH1)
CALL MESSAG('INPUT # = $',100,XX+T8,YY+T10)
CALL HEIGHT(TH1)
CALL INTNO(K1,'ABUT','ABUT')
CALL MESSAG('OUTPUT # = $',100,XX+T8,YY+T9)
CALL HEIGHT(TH1)
CALL INTNO(K2,'ABUT','ABUT')
CALL MESSAG('DC GAIN = $',100,XX+T8,YY+T8)
CALL HEIGHT(TH1)
CALL RFALNC(GOL,-3,'ABUT','ABUT')
CALL BLREC(XX,YY,T5,T6,0.02)
C-----GRID-----
CALL DOT
CALL GPID(1,1)
CALL RESET('DOT')
CALL ENDPL(C)
C-----PHASE PLOT-----
IF(IPTR.EQ.2) GO TO 11
CALL TEK618
CALL PAGE(PAGEX,PAGEY)

```

OPT09610
OPT09620
OPT09630
OPT09640
OPT09650
OPT09660
OPT09670
OPT09680
OPT09690
OPT09700
OPT09710
OPT09720
OPT09730
OPT09740
OPT09750
OPT09760
OPT09770
OPT09780
OPT09790
OPT09800
OPT09810
OPT09820
OPT09830
OPT09840
OPT09850
OPT09860
OPT09870
OPT09880
OPT09890
OPT09900
OPT09910
OPT09920
OPT09930
OPT09940
OPT09950
OPT09960
OPT09970
OPT09980
OPT09990
OPT10000
OPT10010
OPT10020
OPT10030
OPT10040
OPT10050
OPT10060
OPT10070
OPT10080

```

CALL HWROT('AUTO')
CALL HWSAL('SCREEN')
CALL NCBDRP
GO TO 21
-----COMFRS-----
11  CCNT INUE
    CALL CCMPRS
    CALL PAGE(PAGEX,PAGEY)
    CCNT INUE
-----PLOT EXECUTION-----
21  CALL NCHEK
    CALL GRACE(C)
    CALL PHYSOP(T1,T1)
    CALL AREA2C(XAXIS, YAXIS)
    CALL TRIPLX
    CALL HEIGHT(TH)
    CALL XNAME('FREQUENCY - RADIANS PER SECOND $',100)
    CALL YNAME('PHASE - DEGREES $',100)
    CALL XLOG(FMIN,FCYCLE,PMIN,PCYCLE)
    CALL RLVEC(FMAX+FU,180.0,FMIN-FL,180.0,0000)
    CALL RLVEC(FMAX+FU,-180.0,FMIN-FL,-180.0,0000)
    NN = NL + 1
    IF(NL.EQ.0) GO TO 36
    DO 36 I=1,NL
      CALL CLINE(I)
      CALL HEADIN(LINE,100,T3,NN)
      CCNT INUE
      IF(ITFX.EQ.1)
        * CALL HEADIN('OPEN LOOP TF BODE PHASE$',100,T3,NN)
        * IF(ITFX.EQ.2)
          * CALL HEADIN('NOISE TF BODE PHASE$',100,T3,NN)
          * IF(ITFX.EQ.3)
            * CALL HEADIN('COMPENSATOR TF BODE PHASE$',100,T3,NN)
            * CALL HEADIN('PHASE'
-----PHASE-----
C  CALL CURVE(XNC,YDO,N,0)
-----LEGEND-----
C  XX = XAXIS - T7
    YY = YAXIS + T8
    CALL HEISSAG('INPUT # = $',100,XX+T8,YY+T10)
    CALL HEIGHT(TH1)
    CALL HEISSAG('ABUT')
    CALL INTND(K1,'ABUT')
    CALL HEISSAG('OUTPUT # = $',100,XX+T8,YY+T9)
    CALL HEIGHT(TH1)
    CALL HEISSAG('ABUT')
    CALL INTND(K2,'ABUT')

```

```

CALL HEIGHT(TH1)
CALL MESSAG('DC GAIN =',100,XX+T8,YY+T8)
CALL HEIGHT(TH1)
CALL REALNC(GOL,-3,'ABUT','ABUT')
CALL BLREC(XX,YY,T5,T6,0.02)
C-----GRID-----
CALL DOT
CALL GRID(1,1)
CALL RESET('DOT')
CALL ENDPL(C)
IF(IPTR.NE.2) GO TO 75
CALL FRTCMS('CLRSCRN')
WRITE(6,13C)
C-----GAIN AND PHASE MARGIN-----
75 CALL FRTCMS('CLRSCRN')
WRITE(6,13E)
C-----GAIN MARGIN-----
DC 71 I = 2,N
IF(ABS(YDO(I-1)).LT.180.0.AND.ABS(YDO(I)).GE.180.0) GO TO 72
IF(ABS(YDO(I-1)).GT.180.0.AND.ABS(YDO(I)).LE.180.0) GO TO 72
GO TO 71
GM = 0.0 - YNO(I)
WRITE(6,14C) XNO(I), GM
CCNTINUE
72
71 C-----PHASE MARGIN-----
DC 76 I = 2,N
IF(YNO(I-1).GT.0.0.AND.YNO(I).LE.0.0) GO TO 77
GO TO 76
PM = 180.0 + YDO(I)
WRITE(6,15C) XNO(I), PM
CCNTINUE
76
C-----CHANGES TO PLOT-----
5C CCNTINUE
CALL FRTCMS('CLRSCRN')
CALL F(6,12C)
IF(ITFX.EQ.1) WRITE(6,710)
IF(ITFX.EQ.2) WRITE(6,711)
IF(ITFX.EQ.3) WRITE(6,712)
WRITE(6,10C)
WRITE(6,11C)
CALL RLIN(1,1ANS)
IF(1ANS.GT.50R.1ANS.LT.1) GO TO 15
GC TO 25
WRITE(6,51C)
GO TO 30
CCNTINUE
15
25 ICHG = 1

```



```

C-----GRAPHIC OR TABULAR OUTPUT-----OPTI 2490
200  CALL FRTCMS('CLRSCRN ')OPTI 2500
      WRITE(6,120)OPTI 2510
      IF(IITFX.EQ.1) WRITE(6,710)OPTI 2520
      IF(IITFX.EQ.2) WRITE(6,711)OPTI 2530
      IF(IITFX.EQ.3) WRITE(6,712)OPTI 2540
      CALL PRTPLOT(IPP)OPTI 2550
      GO TO (201,202,80),IPPOPTI 2560
C-----PLOT SETUP-----OPTI 2570
201  CONTINUEOPTI 2580
      N = 500OPTI 2590
      ICHG = 0OPTI 2600
      IF(GAN(2,K2,K1).EQ.0.0) GO TO 95OPTI 2610
      CALL FRTCMS('CLRSCRN ')OPTI 2620
      IF(ICHG.EQ.1) GO TO 41OPTI 2630
      WRITE(6,120)OPTI 2640
      IF(IITFX.EQ.1) WRITE(6,710)OPTI 2650
      IF(IITFX.EQ.2) WRITE(6,711)OPTI 2660
      IF(IITFX.EQ.3) WRITE(6,712)OPTI 2670
      CALL GSETUP(IPT,PAGEX,PAGEY)OPTI 2680
      IF(ICHG.EQ.1) GO TO 90OPTI 2690
      IF(ICHG.EQ.1) GO TO 90OPTI 2700
      CALL FRTCMS('CLRSCRN ')OPTI 2710
      IF(ICHG.EQ.1) GO TO 90OPTI 2720
      CALL FRTCMS('CLRSCRN ')OPTI 2730
      IF(ICHG.EQ.1) GO TO 90OPTI 2740
      IF(ICHG.EQ.1) GO TO 90OPTI 2750
      CONTINUEOPTI 2760
C-----SCALING CONSTANTS-----OPTI 2770
C-----INPUT ARRAYS-----OPTI 2780
      CALL PSCLF(PAGEX)OPTI 2790
      GOL = SNGL(GAN(2,K2,K1))OPTI 2800
      CALL FREQ(NS,K2,K1,FMIN,FMAX,N)OPTI 2810
      DO 5 I = 1,NOPTI 2820
        XNO(I) = SNGL(QR(I))OPTI 2830
        YNO(I) = SNGL(QI(I))OPTI 2840
      CONTINUEOPTI 2850
      CALL MINMAX(N,XNO,QRMIN,QRMAX)OPTI 2860
      CALL MINMAX(N,YNO,QIMIN,QIMAX)OPTI 2870
C-----PLOT LIMITS-----OPTI 2880
      XAXIS = PAGEX - 2.*T1OPTI 2890
      YAXIS = PAGEY - T1 - T2OPTI 2900
      IF(QRMIN.GT.-1.) QRMIN = -1.0OPTI 2910
      IF(QRMAX.LT.0.) QRMAX = 0.0OPTI 2920
      IF(QIMAX.LT.0.) QIMAX = 0.0OPTI 2930
      IF(QIMIN.GT.0.) QIMIN = 0.0OPTI 2940
      IF((QRMAX-QRMIN).GE.(QIMAX-QIMIN)) GO TO 6OPTI 2950
      RL = QIMAX - QIMINOPTI 2960

```



```

20 C-----PLOT EXECUTION-----
CALL CCMPRS
CALL PAGE(PAGEX,PAGEY)
CCNTINUE
CALL NOCHECK
CALL GRACE(C)
CALL PHYSOR(T1,T1)
CALL AREA2C(XAXIS, YAXIS)
CALL TRIPLX
CALL HEIGHT(TH)
CALL XNAME(' $',100)
CALL HEIGHT(TH)
CALL YNAME(' $',100)
C-----POLAR PLOT-----
CALL POLAR(THFAC,RSTEP,XDIST,YDIST)
C-----HEADING-----
NN = NL + 1
IF(NL.EQ.0) GO TO 35
DC 35 I=1,NL
CALL CLINE(I)
CALL HEADIN(LINE,100,T3,NN)
35 CONTINUE
IF(ITFX.EQ.1)
* CALL HEADIN('OPEN LOOP TRANSFER NYQUIST$',100,T3,NN)
* IF(ITFX.EQ.2)
* CALL HEADIN('NOISE TRANSFER NYQUIST$',100,T3,NN)
* IF(ITFX.EQ.3)
* CALL HEADIN('COMPENSATOR TRANSFER NYQUIST$',100,T3,NN)
C-----AXIS PLOT-----
XDO(1) = 0.C
XDO(2) = RL*2.0
YDO(1) = 0.C
YDO(2) = 0.C
DO 27 I=1,4
CALL CURVE(YCC,XDO,2.0)
YDO(1) = YCC(I) + 90.
CCNTINUE
27 C-----UNIT CIRCLE-----
CALL DCT
CALL GRID(1,1)
XDO(1) = 0.C
YDO(1) = 1.C
DC 28 I=1,360
XDO(I) = XCC(I-1) + 1.0
YDO(I) = 1.C
CCNTINUE
CALL CURVE(XDO,YDO,360,0)
CALL RESET('DCT')
28

```

```

C-----CURVE PLCT-----OPTI 3937
DO 29 I = 1,N
XNO(I) = SNGL(QPSR(I))
YNO(I) = SNGL(MAG(I))
25 CCNT INUE
CALL CURVE(XNO,YNO,N,O)
CALL FRAME
C-----LEGEND-----OPTI 3940
XX = XAXIS - T7
YY = YAXIS + T8
CALL HEIGHT(TH1)
CALL MESSAGE(,INPUT # = $,100,XX+T8,YY+T10)
CALL HEIGHT(TH1)
CALL HEIGHT(K1,ABUT,ABUT)
CALL INTNO(K1,ABUT)
CALL HEIGHT(TH1)
CALL MESSAGE(,OUTPUT # = $,100,XX+T8,YY+T9)
CALL HEIGHT(TH1)
CALL INTNO(K2,ABUT,ABUT)
CALL HEIGHT(TH1)
CALL HEIGHT(TH1)
CALL MESSAGE(,DC GAIN = $,100,XX+T8,YY+T8)
CALL HEIGHT(TH1)
CALL HEIGHT(TH1)
CALL REALNC(GOL,-3,ABUT,ABUT)
CALL BLREC(XX,YY,T5,T6,0.02)
C-----OPTI 4000
CALL ENOPL(C)
IF(IPT,NE,2) GO TO 75
CALL FRTCMS(,CLRSCRN)
WRITE(6,13C)
C-----GAIN AND PHASE MARGIN-----OPTI 4010
DC 73 I = 1,N
CMGA = DIMAG(WN(I))
XNO(I) = SNGL(OMEGA)
MA = 20.0*DLG10(MAG(I))
YNO(I) = SNGL(MA)
YDO(I) = SNGL(QPSR(I))
73 CCNT INUE
CALL FRTCMS(,CLRSCRN)
WRITE(6,13E)
C-----GAIN MARGIN-----OPTI 4020
DC 71 I = 2,N
IF(ABS(YDO(I-1)).LT.180.0.AND.ABS(YDO(I)).GE.180.0) GO TO 72
IF(ABS(YDO(I-1)).GT.180.0.AND.ABS(YDO(I)).LE.180.0) GO TO 72
GC TO 71
GM = 0.0 - YNO(I)
72 WRITE(6,14C) XNO(I), GM
CONTINUE
71 C-----PHASE MARGIN-----OPTI 4030
DO 76 I = 2,N
OPTI 4040

```

```

77 IF(YNO(I-1).GT.0.0.AND.YNO(I).LE.0.0) GO TC 77
GC TO 76
PM = 180.0 + YDO(I)
WRITE(6,150) XNO(I), PM
76 CCNT INUE
WRITE(6,160)
-----CHANGES TO PLOT-----
5C CCNT INUE
CALL FRTCMS('CLRSCRN ')
WRITE(6,120)
IF(IITFX.EQ.1) WRITE(6,710)
IF(IITFX.EQ.2) WRITE(6,711)
IF(IITFX.EQ.3) WRITE(6,712)
WRITE(6,100)
WRITE(6,110)
30 CALL RCINT(IANS)
IF(IANS.GT.5.OR.IANS.LT.1) GO TO 15
15 GO TO 25
WRITE(6,510)
25 CCNT INUE
ICHG = 1
GC TO (40,50,60,70,200),IANS
-----TABULAR DATA-----
202 CCNT INUE
IF(GAN(2,K2,K1).EQ.0.0) GO TO 95
ICHG = 0
CALL FRTCMS('CLRSCRN ')
251 WRITE(6,120)
IF(IITFX.EQ.1) GO TO 249
IF(IITFX.EQ.2) WRITE(6,710)
IF(IITFX.EQ.3) WRITE(6,711)
IF(IITFX.EQ.3) WRITE(6,712)
249 CALL PTR(IPT)
IF(IITFX.EQ.1) GO TC 290
252 CALL FRTCMS('CLRSCRN ')
CALL FGRAF(FMIN,FMAX)
IF(IITFX.EQ.1) GO TC 290
253 CALL FRTCMS('CLRSCRN ')
CALL NPTS(PTS)
IF(IITFX.EQ.1) GO TC 290
-----TABULATE DATA-----
254 CCNT INUE
ZERO = 0.0
J1 = 0
CRD = DINT(GAN(1,K2,K1))
GAIN = GAN(2,K2,K1)
CALL FRTCMS('CLRSCRN ')

```


AD-A152 148

DEVELOPMENT OF GRAPHICAL POLE-ZERO ROOT-LOCUS BODE
NYQUIST AND NICHOLS RESPONSES USING THE OPTSVSX PROGRAM
(U) NAVAL POSTGRADUATE SCHOOL MONTEREY CA M H LAPTAS
SEP 84 F/G 9/2

3/3


UNCLASSIFIED

NL

END

FILED

DATE



MICROCOPY RESOLUTION TEST CHART
NATIONAL BUREAU OF STANDARDS-1963 A

```

WRITE(IPT,120) WRITE(IPT,710)
IF(ITFX.EQ.1) WRITE(IPT,711)
IF(ITFX.EQ.2) WRITE(IPT,712)
WRITE(IPT,301) K1
WRITE(IPT,302) K2
WRITE(IPT,311) NS
WRITE(IPT,310) CRD
WRITE(IPT,320) GAN(2,K2,K1)
WRITE(IPT,350)
N = PIS
CALL FREQ(NS,K2,K1,FMIN,FMAX,N)
DO 220 I = 1,N
OMEGA = DIMAG(WNII)
WRITE(IPT,330) OMEGA,MAG(I),QPSR(I),QR(I),CI(I)
CCNTINUE
220-----CHANGES TABULAR DATA-----
IF(IPT.EQ.2) WRITE(6,401)
IF(IPT.EQ.2) WRITE(6,402)
WRITE(6,400)
CALL RCHAR(IANS)
IF((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 245
GO TO 250
WRITE(6,500)
GO TO 240
CCNTINUE
IF(IANS.EC.IY) GO TO 290
IF(IANS.EC.IZ) GO TO 200
245-----CHANGES-----
CCNTINUE
CALL FRTCMS('CLRSCRN ')
WRITE(6,120)
IF(ITFX.EQ.1) WRITE(6,710)
IF(ITFX.EQ.2) WRITE(6,711)
WRITE(6,712)
WRITE(6,410)
WRITE(6,411)
CALL PCINT(IANS)
IF(IANS.GT.500) IANS.LT.1) GO TO 292
GO TO 293
WRITE(6,510)
GO TO 291
CCNTINUE
ICHG = I
GO TO (251,252,253,254,200),IANS
251-----
252-----
253-----
CCNTINUE
RETURN
WRITE(6,520)
254-----

```

```

C-----
100  RETURN
    FCFORMAT(//,5X,'DO YOU DESIRE TO MAKE ANY CHANGES TO:',//,10X,'1. HEADIN
    *LOTTER // PAGE SIZE',//,10X,'2. FREQUENCY RANGE:',//,10X,'3. HEADIN
    *//,10X,'4. NO ADDITIONAL CHANGES - EXIT NYQUIST PLOTTING ROUTINE',//
    *5. NO CHANGES - EXIT NYQUIST PLOTTING ROUTINE',//
110  FCFORMAT(//,5X,'ENTER CPTION NUMBER',//)
120  FCFORMAT(//,15X,'NYQUIST PLOT',//)
130  FCFORMAT(//,15X,'A DISSPLA METAFILE HAS BEEN CREATED',//)
    *15X,'CLEAR SCREEN TC CONTINUE',//,15X,'CONTINUE',//,15X,'CONTINUE',//
125  FCFORMAT(//,15X,'GAIN CROSSOVER',//)
140  FCFORMAT(//,3X,'PHASE CROSSOVER',//)
    *GAIN MARGIN IS ,F10.4, DB
150  FCFORMAT(//,3X,'GAIN CROSSOVER',//)
    *PHASE MARGIN IS ,F10.4, DB
160  FCFORMAT(//,15X,'CLEAR SCREEN TO CONTINUE',//,15X,'CONTINUE',//,15X,'CONTINUE',//)
200  FCFORMAT(//,10X,'INPUT NUMBER = ',15)
300  FCFORMAT(//,10X,'NUMERATOR ORDER = ',15)
310  FCFORMAT(//,10X,'DENOMINATOR ORDER = ',15)
320  FCFORMAT(//,10X,'TRANSFER FUNCTION (DC) GAIN = ,D12.4, //)
330  FCFORMAT(//,10X,'TRANSFER FUNCTION (DC) GAIN = ,D12.4, //)
340  FCFORMAT(//,10X,'TRANSFER FUNCTION (DC) GAIN = ,D12.4, //)
    *3X,'REAL FREQUENCY',3X,'IMAGINARY',3X,'(DEGREES)',
    *//,5X,'(RAD/SEC)',3X,'DO YOU DESIRE TO MAKE ANY CHANGES?',//,
    *3X,'PART',3X,'DO YOU DESIRE TO MAKE ANY CHANGES?',//,
    *10X,'TYPE',5X,'YES' OR 'NO',//)
400  FCFORMAT(//,5X,'OUTPUT SENT TO PRINTER',//)
410  FCFORMAT(//,5X,'OUTPUT SENT TO LISTING FILE',//)
    *10X,'DO YOU DESIRE TO MAKE ANY CHANGES TO:',//,
    *10X,'1. OUTPUT DEVICE',//,
    *10X,'2. FREQUENCY RANGE',//,
    *10X,'3. NUMBER OF POINTS',//,
    *10X,'4. NO ADDITIONAL CHANGES - TABULATE DATA',//,
    *10X,'5. EXIT NYQUIST PLOTTING ROUTINE',//)
500  FCFORMAT(//,5X,'WARNING',//)
501  FCFORMAT(//,5X,'WARNING',//)
510  FCFORMAT(//,5X,'WARNING',//)
520  FCFORMAT(//,5X,'WARNING',//)
    *0.//)
710  FCFORMAT(//,5X,'OPEN LCCF TRANSFER FUNCTION',//)
711  FCFORMAT(//,5X,'NOISE TRANSFER FUNCTION',//)
712  FCFORMAT(//,5X,'COMPENSATOR TRANSFER FUNCTION',//)
C-----
END
OPT15370
OPT15380
OPT15390
OPT15400
OPT15410
OPT15420
OPT15430
OPT15440
OPT15450
OPT15460
OPT15470
OPT15480
OPT15490
OPT15500
OPT15510
OPT15520
OPT15530
OPT15540
OPT15550
OPT15560
OPT15570
OPT15580
OPT15590
OPT15600
OPT15610
OPT15620
OPT15630
OPT15640
OPT15650
OPT15660
OPT15670
OPT15680
OPT15690
OPT15700
OPT15710
OPT15720
OPT15730
OPT15740
OPT15750
OPT15760
OPT15770
OPT15780
OPT15790
OPT15800
OPT15810
OPT15820
OPT15830
OPT15840

```

```

C=====OPTI 5850
C=====OPTI 5860
C=====OPTI 5870
C=====OPTI 5880
C=====OPTI 5890
C=====OPTI 5900
C=====OPTI 5910
C=====OPTI 5920
C=====OPTI 5930
C=====OPTI 5940
C=====OPTI 5950
C=====OPTI 5960
C=====OPTI 5970
C=====OPTI 5980
C=====OPTI 5990
C=====OPTI 6000
C=====OPTI 6010
C=====OPTI 6020
C=====OPTI 6030
C=====OPTI 6040
C=====OPTI 6050
C=====OPTI 6060
C=====OPTI 6070
C=====OPTI 6080
C=====OPTI 6090
C=====OPTI 6100
C=====OPTI 6110
C=====OPTI 6120
C=====OPTI 6130
C=====OPTI 6140
C=====OPTI 6150
C=====OPTI 6160
C=====OPTI 6170
C=====OPTI 6180
C=====OPTI 6190
C=====OPTI 6200
C=====OPTI 6210
C=====OPTI 6220
C=====OPTI 6230
C=====OPTI 6240
C=====OPTI 6250
C=====OPTI 6260
C=====OPTI 6270
C=====OPTI 6280
C=====OPTI 6290
C=====OPTI 6300
C=====OPTI 6310
C=====OPTI 6320

SUBROUTINE NICHOL (NS,K2,K1,ITFX)
INTERATIVELY PLOTS A NICHOLS PLOT USING CISSPLA GRAPHICS GIVEN
THE ZERO ANC POLE LOCATIONS
=====
REAL*8 OLN,CLD,ORNUM,GI,QR,QPSR,MAG,GAN,CO,MA,OMEGA
REAL*4 XDO,YDO,XNO,YNO,FMIN,FMAX,MMIN,MMAX,XAXIS,YAXIS,FAGEX,
*PAGEY,PMAX,PL,B1,B2,B3,TH1,T9,T10
COMPLEX#16 RTN,PLN,RTD,PLD,WN
INTEGER NS,IPTR,K1,K2,NN,NL,LINES,IANS,ICHG,LINE,N,IPP,CRD,PTS,
*KK,J,I1,NI,IFF,OLN(99,2,12,12),OLD(99,2),GAN(2,12,12),CC
COMMON /SGRAF/ XDO(500),YDO(500),XNC(500),YNC(500)
COMMON /SHEAD/ LINES(4,18),LINE(9)
COMMON /FFREQ/ RTN(99),PLN(99),RTD(99),PLD(99),WN(500),GI(500),
*GR(500),QPSR(500),MAG(500)
COMMON /SCALE/ TS,TH,TH1,T1,T2,T3,T4,T5,T6,T7,T8,T9,T10
DATA IV,Y,Y1,IZ,N/
C-----GRAPHIC OR TABULAR OUTPUT-----
200 CALL FRTCMS('CLRSCRN')
WRITE(6,12C)
IF(ITFX.EQ.1) WRITE(6,710)
IF(ITFX.EQ.2) WRITE(6,711)
IF(ITFX.EQ.3) WRITE(6,712)
CALL PRTPLOT(IPP)
GO TO (201,202,80),IPP
C-----PLOT SETUP-----
201 CONTINUE
N=500
ICHG=0
IF(GAN(2,K2,K1).EQ.0.0) GO TO 95
CALL FRTCMS('CLRSCRN')
WRITE(6,12C)
IF(ITFX.EQ.1) GO TO 41
IF(ITFX.EQ.2) WRITE(6,710)
IF(ITFX.EQ.3) WRITE(6,711)
IF(ITFX.EQ.3) WRITE(6,712)
CALL GSETUP(IPTR,PAGEY,PAGEY)
IF(ICHG.EQ.1) GO TO 90
CALL FRTCMS('CLRSCRN')
CALL FCRADF(FMIN,FMAX)
IF(ICHG.EQ.1) GO TO 50
CALL FRTCMS('CLRSCRN')
CALL FHEAD(NL)
IF(ICHG.EQ.1) GO TO 50
CONTINUE
40 CONTINUE
41 CONTINUE
50 CONTINUE
60 CONTINUE
70 CONTINUE

```

```

C-----SCALING CONSTANTS-----OPTI 6330
C-----INPUT ARRAYS-----OPTI 6340
OPTI 6350
OPTI 6360
OPTI 6370
OPTI 6380
OPTI 6390
OPTI 6400
OPTI 6410
OPTI 6420
OPTI 6430
OPTI 6440
OPTI 6450
OPTI 6460
OPTI 6470
OPTI 6480
OPTI 6490
OPTI 6500
OPTI 6510
OPTI 6520
OPTI 6530
OPTI 6540
OPTI 6550
OPTI 6560
OPTI 6570
OPTI 6580
OPTI 6590
OPTI 6600
OPTI 6610
OPTI 6620
OPTI 6630
OPTI 6640
OPTI 6650
OPTI 6660
OPTI 6670
OPTI 6680
OPTI 6690
OPTI 6700
OPTI 6710
OPTI 6720
OPTI 6730
OPTI 6740
OPTI 6750
OPTI 6760
OPTI 6770
OPTI 6780
OPTI 6790
OPTI 6800

C-----PLOT LIMITS-----
C-----TEK 618-----
C-----COMPRS-----
C-----PLOT EXECUTION-----
C-----HEADING-----

CALL PSCALE(PAGEX)
CALL FREQ(NS,K2,K1,FMIN,FMAX,N)
DO 5 I=1,N
  WA = 20.0 * DLOG10(MAG(I))
  XDO(I) = SNGL(WA)
  YDO(I) = SNGL(QPSR(I))
  CCNT INUE
  CALL MINMAX(N,YDO,MMIN,MMAX)
  CALL MINMAX(N,XDO,PMIN,PMAX)
  XAXIS = PAGEX - 2 * T1
  YAXIS = PAGEY - T1 - T2
  IF(MMAX.LT.C.O) MMAX = 0.0
  IF(MMIN.GT.C.O) MMIN = 0.0
  IF(PMAX.LT.C.O) PMAX = 0.0
  IF(PMIN.GT.C.O) PMIN = 0.0
  IF(IPTR.EQ.2) GO TO 10
  CALL TEK618
  CALL PAGE(PAGEX,PAGEY)
  CALL HPROT('AUTO')
  CALL HWSCL('SCREEN')
  CALL NCBRDR
  GO TO 20
  CCNT INUE
  CALL CCMPRS
  CALL PAGE(PAGEX,PAGEY)
  CCNT INUE
  CALL NCCHCK
  CALL GRACE(C)
  CALL PHYSOR(T1,T1)
  CALL AREA2C(XAXIS, YAXIS)
  CALL TRIPLX
  CALL HEIGHT(TH)
  CALL XNAME('PHASE - DEGREES $',100)
  CALL HEIGHT(TH)
  CALL YNAME('MAGNITUDE - DECIBELS $',100)
  CALL GRAF(FMIN,SCALE,PMAX,MMIN,SCALE,MMAX)
  NN = NL + 1
  IF(NL.EQ.0) GO TO 35
  DC 35 I=1,NL
  CALL CLINE(I)

```

```

35      CALL HEADIN(LINE,100,T3,NN)
      CONTINUE EQ=1
      IF(ITFX.EQ.1)
        * CALL HEADIN('OPEN LOOP TRANSFER NICHOLS$',100,T3,NN)
      * IF(ITFX.EQ.2)
        * CALL HEADIN('NOISE TRANSFER NICHOLS$',100,T3,NN)
      * IF(ITFX.EQ.3)
        * CALL HEADIN('COMPENSATOR TRANSFER NICHOLS$',100,T3,NN)
      * CALL HEADIN('CURVE PLCT'
C-----
      CALL CURVE(XCO,YDO,N,C)
C-----
      XX = XAXIS - T7
      YY = YAXIS + T8
      CALL HEIGHT(TH1)
      CALL MESSAGE('INPUT # = $',100,XX+T8,YY+T10)
      CALL HEIGHT(TH1)
      CALL INTNO(K1,ABUT,'ABUT')
      CALL HEIGHT(TH1)
      CALL MESSAGE('OUTPUT # = $',100,XX+T8,YY+T9)
      CALL HEIGHT(TH1)
      CALL INTNO(K2,ABUT,'ABUT')
      CALL HEIGHT(TH1)
      CALL MESSAGE('DC GAIN = $',100,XX+T8,YY+T8)
      CALL HEIGHT(TH1)
      CALL REALNC(GOL,-3,ABUT,'ABUT')
      CALL BLREC(XX,YY,T3,T6,0.02)
C-----
      GRID
C-----
      CALL DOT(1,1)
      CALL RESET('DOT')
      CALL ENDPL(0)
      IF(ITPTR.NE.2) GO TO 75
      CALL FRTCMS('CLRSCRN ')
      WRITE(6,130)
C-----
      DO 73 I = 1,N
      CMGA = DIMAG(WN(I))
      XNO(I) = SNGL(OMEGA)
      MA = 20.0 * CLOG10(MAG(I))
      YNO(I) = SNGL(MA)
      YDO(I) = SNGL(QPSR(I))
      CONTINUE
      CALL FRTCMS('CLRSCRN ')
      WRITE(6,135)
C-----
      DO 71 I = 2,N
      IF(ABS(YDO(I-1)).LT.180.0.AND.ABS(YDO(I)).GE.180.0) GO TO 72

```

```

72 IF(ABS(YDO(I-1)).GT.180.0.AND.ABS(YDO(I)).LE.180.0) GO TO 72
   GM = 0.0 - YNO(I)
71 WRITE (6,14C) XNO(I), GM
   CONTINUE
-----PHASE MARGIN-----
DO 76 I = 1,N
IF(YNO(I-1).GT.0.0.AND.YNO(I).LE.0.0) GO TO 77
GO TO 76
77 PM = 180.0 + YDO(I)
76 WRITE (6,150) XNO(I), PM
   CONTINUE
   WRITE(6,160)
-----CHANGES TO PLOT-----
50 CONTINUE
   CALL FRTCMS('CLRSCRN ')
   WRITE(6,12C)
   IF(IITFX.EQ.1) WRITE(6,710)
   IF(IITFX.EQ.2) WRITE(6,711)
   IF(IITFX.EQ.3) WRITE(6,712)
   WRITE(6,100)
   WRITE(6,11C)
   CALL RDINT(IANS)
   IF(IANS.GT.5.OR.IANS.LT.1) GO TO 15
15 GO TO 25
25 WRITE(6,51C)
   GO TO 30
   CONTINUE
   ICPG = 1
   GO TO (40,50,60,70,200),IANS
-----TABULAR DATA-----
202 CONTINUE
   IF(GAN(2,K2,K1).EQ.0.0) GO TO 95
   ICHG = 0
   CALL FRTCMS('CLRSCRN ')
   IF(IICHG.EQ.1) GO TO 249
   WRITE(6,120)
   IF(IITFX.EQ.1) WRITE(6,710)
   IF(IITFX.EQ.2) WRITE(6,711)
   IF(IITFX.EQ.3) WRITE(6,712)
   CALL PRTR('PT')
   CALL CHG(EQ.1) GO TO 290
   IF(IICHG.EQ.1) GO TO 290
   CALL FRTCMS('CLRSCRN ')
   CALL FGRAE(FMIN,FMAX)
   IF(IICHG.EQ.1) GO TO 290
   CALL NPTS(PTS)
   IF(IICHG.EQ.1) GO TO 290

```



```

C-----TABULATE DATA-----OPT117770
254  CCNT INUE                                OPT117780
      ZERO = 0.0                            OPT117790
      J1 = 0                                OPT117800
      ORD = CINT (GAN(1,K2,K1))             OPT117810
      GAIN = GAN(2,K2,K1)                  OPT117820
      CALL FRTCMS('CLRSCRN ')              OPT117830
      WRITE(IPT,120)                        OPT117840
      IF(IIFX.EQ.1) WRITE(IPT,710)          OPT117850
      IF(IIFX.EQ.2) WRITE(IPT,711)          OPT117860
      IF(IIFX.EQ.3) WRITE(IPT,712)          OPT117870
      WRITE(IPT,300) K1                    OPT117880
      WRITE(IPT,301) K2                    OPT117890
      WRITE(IPT,311) NS                    OPT117900
      WRITE(IPT,310) ORD                   OPT117910
      WRITE(IPT,320) GAN(2,K2,K1)          OPT117920
      WRITE(IPT,350)                        OPT117930
      N = PTS                               OPT117940
      CALL FREQ(NS,K2,K1,FMIN,FMAX,N)        OPT117950
      DO 220 I = 1,N                       OPT117960
      CMGA = DIMAG(WN(I))                   OPT117970
      MA = 20.0 * DLOG10(MAG(I))            OPT117980
      WRITE(IPT,330) CMGA,MA,QPSR(I),QR(I),QI(I)
      CONTINUE                               OPT117990
      -----CHANGES TABULAR DATA-----OPT118000
220  IF(IPT.EQ.3) WRITE(6,401)              OPT118010
      IF(IPT.EQ.2) WRITE(6,402)            OPT118020
      WRITE(6,400)                          OPT118030
      CALL RDCMAP (IANS)                    OPT118040
      IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 245
      GO TO 250                              OPT118050
245  WRITE(6,500)                          OPT118060
      GO TO 240                             OPT118070
250  CCNT INUE                               OPT118080
      IF (IANS.EC.IY) GO TC 290             OPT118090
      IF (IANS.EC.IZ) GO TC 200             OPT118100
      -----CHANGES-----OPT118110
250  CCNT INUE                               OPT118120
      CALL FRTCMS('CLRSCRN ')              OPT118130
      WRITE(6,120)                          OPT118140
      IF(IIFX.EQ.1) WRITE(6,710)            OPT118150
      IF(IIFX.EQ.2) WRITE(6,711)            OPT118160
      IF(IIFX.EQ.3) WRITE(6,712)            OPT118170
      WRITE(6,410)                          OPT118180
      WRITE(6,110)                          OPT118190
      CALL RDCINT(IANS)                     OPT118200
      IF(IANS.GT.5.OR.IANS.LT.1) GO TO 292   OPT118210
      GO TO 293                             OPT118220
      OPT118230
      OPT118240

```

OP	182260	OP	182270	OP	182280	OP	182290	OP	182300	OP	182310	OP	182320	OP	182330	OP	182340	OP	182350	OP	182360	OP	182370	OP	182380	OP	182390	OP	182400	CP	184210	OP	184220	OP	184230	OP	184240	OP	184250	OP	184260	OP	184270	OP	184280	OP	184290	OP	184300	OP	184310	OP	184320	OP	184330	OP	184340	OP	184350	OP	184360	OP	184370	OP	184380	OP	184390	OP	184400	OP	184410	OP	184420	OP	184430	OP	184440	OP	184450	OP	184460	OP	184470	OP	184480	OP	184490	OP	184500	OP	184510	OP	184520	OP	184530	OP	184540	OP	184550	OP	184560	OP	184570	OP	184580	OP	184590	OP	184600	OP	184610	OP	184620	OP	184630	OP	184640	OP	184650	OP	184660	OP	184670	OP	184680	OP	184690	OP	184700	OP	184710	OP	184720	OP	184730	OP	184740	OP	184750	OP	184760	OP	184770	OP	184780	OP	184790	OP	184800	OP	184810	OP	184820	OP	184830	OP	184840	OP	184850	OP	184860	OP	184870	OP	184880	OP	184890	OP	184900	OP	184910	OP	184920	OP	184930	OP	184940	OP	184950	OP	184960	OP	184970	OP	184980	OP	184990	OP	185000	OP	185010	OP	185020	OP	185030	OP	185040	OP	185050	OP	185060	OP	185070	OP	185080	OP	185090	OP	185100	OP	185110	OP	185120	OP	185130	OP	185140	OP	185150	OP	185160	OP	185170	OP	185180	OP	185190	OP	185200	OP	185210	OP	185220	OP	185230	OP	185240	OP	185250	OP	185260	OP	185270	OP	185280	OP	185290	OP	185300	OP	185310	OP	185320	OP	185330	OP	185340	OP	185350	OP	185360	OP	185370	OP	185380	OP	185390	OP	185400	OP	185410	OP	185420	OP	185430	OP	185440	OP	185450	OP	185460	OP	185470	OP	185480	OP	185490	OP	185500	OP	185510	OP	185520	OP	185530	OP	185540	OP	185550	OP	185560	OP	185570	OP	185580	OP	185590	OP	185600	OP	185610	OP	185620	OP	185630	OP	185640	OP	185650	OP	185660	OP	185670	OP	185680	OP	185690	OP	185700	OP	185710	OP	185720	OP	185730	OP	185740	OP	185750	OP	185760	OP	185770	OP	185780	OP	185790	OP	185800	OP	185810	OP	185820	OP	185830	OP	185840	OP	185850	OP	185860	OP	185870	OP	185880	OP	185890	OP	185900	OP	185910	OP	185920	OP	185930	OP	185940	OP	185950	OP	185960	OP	185970	OP	185980	OP	185990	OP	186000	OP	186010	OP	186020	OP	186030	OP	186040	OP	186050	OP	186060	OP	186070	OP	186080	OP	186090	OP	186100	OP	186110	OP	186120	OP	186130	OP	186140	OP	186150	OP	186160	OP	186170	OP	186180	OP	186190	OP	186200	OP	186210	OP	186220	OP	186230	OP	186240	OP	186250	OP	186260	OP	186270	OP	186280	OP	186290	OP	186300	OP	186310	OP	186320	OP	186330	OP	186340	OP	186350	OP	186360	OP	186370	OP	186380	OP	186390	OP	186400	OP	186410	OP	186420	OP	186430	OP	186440	OP	186450	OP	1864
----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	--------	----	------


```

DELTF = 10.**CYCLE
DO 80 I = 1, NN
IF (I.GT.1) GO TO 5
WN(I) = DCMPLX(ZERO, FRMIN)
GO TO 6
WN(I) = WN(I-1) * DELTF
-----POLYNOMIAL-----
CPOL = 1.0
IF (J1.EQ.0) GO TO 7
DO 30 K = 1, J1
CPOL = CPOL*(WN(I)-RTN(K))/(WN(I)-RTD(K))
IF (J1.EQ.N) GO TO 8
JJ = J1 + 1
DO 40 K = JJ, NS
CPOL = CPOL*(WN(I)-RTD(K))
CPOL = CPOL*GAIN
-----MAGNITUDE-----
MAG(I) = CCABS(CPOL)
-----PHASE-----
QT(I) = CIMAG(CPOL)
CR(I) = CREAL(CPOL)
IF (QI(I)) 601, 602, 603
IF (QR(I)) 620, 621, 622
IF (QR(I)) 623, 751, 625
IF (QR(I)) 626, 627, 628
QPSR(I) = -180. + 57.29577951*DATAN(QI(I)/QR(I))
GO TO 555
QPSR(I) = -50.
GO TO 555
QPSR(I) = - 57.29577951*DATAN(-QI(I)/QR(I))
GO TO 555
QPSR(I) = 180.
GO TO 555
QPSR(I) = 0.0
GO TO 555
QPSR(I) = 180. - 57.29577951*DATAN(-QI(I)/QR(I))
GO TO 555
QPSR(I) = 50.
GO TO 555
QPSR(I) = 57.29577951*DATAN(QI(I)/QR(I))
GO TO 555
IF (IPHS.EQ.1) GO TO 640
IF ((QPSR(I-1).GT.90.) .AND. (QPSR(I).LT.-90.)) GO TO 630
IF ((QPSR(I-1).LT.-90.) .AND. (QPSR(I).GT.90.)) IPHS = 1
GC TO 640
N = I - 1
DO 650 L = 1, N
QPSR(L) = QPSR(L) - 360.

```



```

65 GC TO 70
   WRITE(6,510)
70 GO TO 60
   CCNTINUE
   PAGEX = ANSF
   RETURN
C-----VRSTEC PAGE SIZE-----
8C CCNTINUE
   PAGEX = 11.0
   PAGEY = 8.5
   RETURN
C-----
100 FORMAT(/,5X,'PLOTTER SELECTION AND PAGE SIZE',/,5X,
*1,/,/)
110 *15X,'2. VERSATEC',/,10X,'CHOCSE OPTION 1 CR 2',/,
130 *15X,'1. TEK618',/,
*1,/,)
140 *15X,'1.1X',/,10X,'PAGE SIZE (MAXIMUM = 21.0 INCHES BY 21.0 INCHES)',
150 *1,/,)
160 *15X,'1.1X',/,10X,'HEIGHT = ',/,)
170 *15X,'1.1X',/,10X,'WIDTH = ',/,)
180 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
190 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
200 *1,/,)
210 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
220 *1,/,)
230 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
240 *1,/,)
250 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
260 *1,/,)
270 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
280 *1,/,)
290 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
300 *1,/,)
310 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
320 *1,/,)
330 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
340 *1,/,)
350 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
360 *1,/,)
370 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
380 *1,/,)
390 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
400 *1,/,)
410 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
420 *1,/,)
430 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
440 *1,/,)
450 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
460 *1,/,)
470 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
480 *1,/,)
490 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
500 *1,/,)
510 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
520 *1,/,)
530 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
540 *1,/,)
550 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
560 *1,/,)
570 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
580 *1,/,)
590 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
600 *1,/,)
610 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
620 *1,/,)
630 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
640 *1,/,)
650 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
660 *1,/,)
670 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
680 *1,/,)
690 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
700 *1,/,)
710 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
720 *1,/,)
730 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
740 *1,/,)
750 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
760 *1,/,)
770 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
780 *1,/,)
790 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
800 *1,/,)
810 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
820 *1,/,)
830 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
840 *1,/,)
850 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
860 *1,/,)
870 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
880 *1,/,)
890 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
900 *1,/,)
910 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
920 *1,/,)
930 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
940 *1,/,)
950 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
960 *1,/,)
970 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
980 *1,/,)
990 *15X,'1.1X',/,10X,'***** ERROR MAXIMUM = 21 INCHES *****',/,)
1000 *1,/,)

```

```

C-----YMAX-----
CALL RDREAL(ANSR)
YMIN = ANSR
WRITE(6,14C)
CALL RCREAL(ANSR)
YMAX = ANSR
C-----CORRECTIONS-----
CALL FRTCMS('CLRSCRN ')
WRITE(6,10C)
WRITE(6,10F)
WRITE(6,15C)
WRITE(6,16C)
WRITE(6,12F)
WRITE(6,17C)
WRITE(6,18C)
WRITE(6,19C)
CALL RDCHAR(ANS)
IF((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 1C
GO TO 2C
1C
WRITE(6,50C)
GO TO 3C
2C
IF(IANS.EQ.IY) GO TO 4C
RETURN
C-----PLOTTING LIMITS FOR GRAPH'-----
100
101
102
103
104
105
106
107
108
109
110
111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167
168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224
225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281
282
283
284
285
286
287
288
289
290
291
292
293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349
350
351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405
406
407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461
462
463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516
517
518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572
573
574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628
629
630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681
682
683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738
739
740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788
789
790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846
847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903
904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958
959
960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006
1007
1008
1009
1010
1011
1012
1013
1014
1015
1016
1017
1018
1019
1020
1021
1022
1023
1024
1025
1026
1027
1028
1029
1030
1031
1032
1033
1034
1035
1036
1037
1038
1039
1040
1041
1042
1043
1044
1045
1046
1047
1048
1049
1050
1051
1052
1053
1054
1055
1056
1057
1058
1059
1060
1061
1062
1063
1064
1065
1066
1067
1068
1069
1070
1071
1072
1073
1074
1075
1076
1077
1078
1079
1080
1081
1082
1083
1084
1085
1086
1087
1088
1089
1090
1091
1092
1093
1094
1095
1096
1097
1098
1099
1100
1101
1102
1103
1104
1105
1106
1107
1108
1109
1110
1111
1112
1113
1114
1115
1116
1117
1118
1119
1120
1121
1122
1123
1124
1125
1126
1127
1128
1129
1130
1131
1132
1133
1134
1135
1136
1137
1138
1139
1140
1141
1142
1143
1144
1145
1146
1147
1148
1149
1150
1151
1152
1153
1154
1155
1156
1157
1158
1159
1160
1161
1162
1163
1164
1165
1166
1167
1168
1169
1170
1171
1172
1173
1174
1175
1176
1177
1178
1179
1180
1181
1182
1183
1184
1185
1186
1187
1188
1189
1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1203
1204
1205
1206
1207
1208
1209
1210
1211
1212
1213
1214
1215
1216
1217
1218
1219
1220
1221
1222
1223
1224
1225
1226
1227
1228
1229
1230
1231
1232
1233
1234
1235
1236
1237
1238
1239
1240
1241
1242
1243
1244
1245
1246
1247
1248
1249
1250
1251
1252
1253
1254
1255
1256
1257
1258
1259
1260
1261
1262
1263
1264
1265
1266
1267
1268
1269
1270
1271
1272
1273
1274
1275
1276
1277
1278
1279
1280
1281
1282
1283
1284
1285
1286
1287
1288
1289
1290
1291
1292
1293
1294
1295
1296
1297
1298
1299
1300
1301
1302
1303
1304
1305
1306
1307
1308
1309
1310
1311
1312
1313
1314
1315
1316
1317
1318
1319
1320
1321
1322
1323
1324
1325
1326
1327
1328
1329
1330
1331
1332
1333
1334
1335
1336
1337
1338
1339
1340
1341
1342
1343
1344
1345
1346
1347
1348
1349
1350
1351
1352
1353
1354
1355
1356
1357
1358
1359
1360
1361
1362
1363
1364
1365
1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392
1393
1394
1395
1396
1397
1398
1399
1400
1401
1402
1403
1404
1405
1406
1407
1408
1409
1410
1411
1412
1413
1414
1415
1416
1417
1418
1419
1420
1421
1422
1423
1424
1425
1426
1427
1428
1429
1430
1431
1432
1433
1434
1435
1436
1437
1438
1439
1440
1441
1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453
1454
1455
1456
1457
1458
1459
1460
1461
1462
1463
1464
1465
1466
1467
1468
1469
1470
1471
1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485
1486
1487
1488
1489
1490
1491
1492
1493
1494
1495
1496
1497
1498
1499
1500
1501
1502
1503
1504
1505
1506
1507
1508
1509
1510
1511
1512
1513
1514
1515
1516
1517
1518
1519
1520
1521
1522
1523
1524
1525
1526
1527
1528
1529
1530
1531
1532
1533
1534
1535
1536
1537
1538
1539
1540
1541
1542
1543
1544
1545
1546
1547
1548
1549
1550
1551
1552
1553
1554
1555
1556
1557
1558
1559
1560
1561
1562
1563
1564
1565
1566
1567
1568
1569
1570
1571
1572
1573
1574
1575
1576
1577
1578
1579
1580
1581
1582
1583
1584
1585
1586
1587
1588
1589
1590
1591
1592
1593
1594
1595
1596
1597
1598
1599
1600
1601
1602
1603
1604
1605
1606
1607
1608
1609
1610
1611
1612
1613
1614
1615
1616
1617
1618
1619
1620
1621
1622
1623
1624
1625
1626
1627
1628
1629
1630
1631
1632
1633
1634
1635
1636
1637
1638
1639
1640
1641
1642
1643
1644
1645
1646
1647
1648
1649
1650
1651
1652
1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709
1710
1711
1712
1713
1714
1715
1716
1717
1718
1719
1720
1721
1722
1723
1724
1725
1726
1727
1728
1729
1730
1731
1732
1733
1734
1735
1736
1737
1738
1739
1740
1741
1742
1743
1744
1745
1746
1747
1748
1749
1750
1751
1752
1753
1754
1755
1756
1757
1758
1759
1760
1761
1762
1763
1764
1765
1766
1767
1768
1769
1770
1771
1772
1773
1774
1775
1776
1777
1778
1779
1780
1781
1782
1783
1784
1785
1786
1787
1788
1789
1790
1791
1792
1793
1794
1795
1796
1797
1798
1799
1800
1801
1802
1803
1804
1805
1806
1807
1808
1809
1810
1811
1812
1813
1814
1815
1816
1817
1818
1819
1820
1821
1822
1823
1824
1825
1826
1827
1828
1829
1830
1831
1832
1833
1834
1835
1836
1837
1838
1839
1840
1841
1842
1843
1844
1845
1846
1847
1848
1849
1850
1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907
1908
1909
1910
1911
1912
1913
1914
1915
1916
1917
1918
1919
1920
1921
1922
1923
1924
1925
1926
1927
1928
1929
1930
1931
1932
1933
1934
1935
1936
1937
1938
1939
1940
1941
1942
1943
1944
1945
1946
1947
1948
1949
1950
1951
1952
1953
1954
1955
1956
1957
1958
1959
1960
1961
1962
1963
1964
1965
1966
1967
1968
1969
1970
1971
1972
1973
1974
1975
1976
1977
1978
1979
1980
1981
1982
1983
1984
1985
1986
1987
1988
1989
1990
1991
1992
1993
1994
1995
1996
1997
1998
1999
2000
2001
2002
2003
2004
2005
2006
2007
2008
2009
2010
2011
2012
2013
2014
2015
2016
2017
2018
2019
2020
2021
2022
2023
2024
2025
2026
2027
2028
2029
2030
2031
2032
2033
2034
2035
2036
2037
2038
2039
2040
2041
2042
2043
2044
2045
2046
2047
2048
2049
2050
2051
2052
2053
2054
2055
2056
2057
2058
2059
2060
2061
2062
2063
2064
2065
2066
2067
2068
2069
2070
2071
2072
2073
2074
2075
2076
2077
2078
2079
2080
2081
2082
2083
2084
2085
2086
2087
2088
2089
2090
2091
2092
2093
2094
2095
2096
2097
2098
2099
2100
2101
2102
2103
2104
2105
2106
2107
2108
2109
2110
2111
2112
2113
2114
2115
2116
2117
2118
2119
2120
2121
2122
2123
2124
2125
2126
2127
2128
2129
2130
2131
2132
2133
2134
2135
2136
2137
2138
2139
2140
2141
2142
2143
2144
2145
2146
2147
2148
2149
2150
2151
2152
2153
2154
2155
2156
2157
2158
2159
2160
2161
2162
2163
2164
2165
2166
2167
2168
2169
2170
2171
2172
2173
2174
2175
2176
2177
2178
2179
2180
2181
2182
2183
2184
2185
2186
2187
2188
2189
2190
2191
2192
2193
2194
2195
2196
2197
2198
2199
2200
2201
2202
2203
2204
2205
2206
2207
2208
2209
2210
2211
2212
2213
2214
2215
2216
2217
2218
2219
2220
2221
2222
2223
2224
2225
2226
2227
2228
2229
2230
2231
2232
2233
2234
2235
2236
2237
2238
2239
2240
2241
2242
2243
2244
2245
2246
2247
2248
2249
2250
2251
2252
2253
2254
2255
2256
2257
2258
2259
2260
2261
2262
2263
2264
2265
2266
2267
2268
2269
2270
2271
2272
2273
2274
2275
2276
2277
2278
2279
2280
2281
2282
2283
2284
2285
2286
2287
2288
2289
2290
2291
2292
2293
2294
2295
2296
2297
2298
2299
2300
2301
2302
2303
2304
2305
2306
2307
2308
2309
2310
2311
2312
2313
2314
2315
2316
2317
2318
2319
2320
2321
2322
2323
2324
2325
2326
2327
2328
2329
2330
2331
2332
2333
2334
2335
2336
2337
2338
2339
2340
2341
2342
2343
2344
2345
2346
2347
2348
2349
2350
2351
2352
2353
2354
2355
2356
2357
2358
2359
2360
2361
2362
2363
2364
2365
2366
2367
2368
2369
2370
2371
2372
2373
2374
2375
2376
2377
2378
2379
2380
2381
2382
2383
2384
2385
2386
2387
2388
2389
2390
2391
2392
2393
2394
2395
2396
2397
2398
2399
2400
2401
2402
2403
2404
2405
2406
2407
2408
2409
2410
2411
2412
2413
2414
2415
2416
2417
2418
2419
2420
2421
2422
2423
2424
2425
2426
2427
2428
2429
2430
2431
2432
2433
2434
2435
2436
2437
2438
2439
2440
2441
2442
2443
2444
2445
2446
2447
2448
2449
2450
2451
2452
2453
2454
2455
2456
2457
2458
2459
2460
2461
2462
2463
2464
2465
2466
2467
2468
2469
2470
2471
2472
2473
2474
2475
2476
2477
2478
2479
2480
2481
2482
2483
2484
2485
2486
2487
2488
2489
2490
2491
2492
2493
2494
2495
2496
2497
2498
2499
2500
2501
2502
2503
2504
2505
2506
2507
2508
2509
2510
2511
2512
2513
2514
2515
2516
2517
2518
2519
2520
2521
2522
2523
2524
2525
2526
2527
2528
2529
2530
2531
2532
2533
2534
2535
2536
2537
2538
2539
2540
2541
2542
2543
2544
2545
2546
2547
2548
2549
2550
2551
2552
2553
2554
2555
2556
2557
2558
2559
2560
2561
2562
2563
2564
2565
2566
2567
2568
2569
2570
2571
2572
2573
2574
2575
2576
2577
2578
2579
2580
2581
2582
2583
2584
2585
2586
2587
2588
2589
2590
2591
2592
2593
2594
2595
2596
2597
2598
2599
2600
2601
2602
2603
2604
2605
2606
2607
2608
2609
2610
2611
2612
2613
2614
2615
2616
2617
2618
2619
2620
2621
2622
2623
2624
2625
2626
2627
2628
2629
2630
2631
2632
2633
2634
2635
2636
2637
2638
2639
2640
2641
2642
2643
2644
2645
2646
2647
2648
2649
2650
2651
2652
2653
2654
2655
2656
2657
2658
2659
2660
2661
2662
2663
2664
2665
2666
2667
2668
2669
2670
2671
2672
2673
2674
2675
2676
2677
2678
2679
2680
2681
2682
2683
2684
2685
2686
2687
2688
2689
2690
2691
2692
2693
2694
2695
2696
2697
2698
2699
2700
2701
2702
2703
2704
2705
2706

```

```

C-----DATA IY/Y/,IZ/N*/-----
4C CCNTINUE-----
   WRITE(6,10C)-----
   WRITE(6,10E)-----
C-----FMIN-----
5C WRITE(6,11C)-----
   CALL RCREAL(ANSR)-----
   FMIN = ANSR-----
   IF (FMIN.GT.C.0) GO TC 60-----
   WRITE(6,110)-----
   GO TO 5C-----
C-----FMAX-----
6C WRITE(6,120)-----
   CALL RCREAL(ANSR)-----
   FMAX = ANSR-----
   IF (FMAX.GT.C.0) GO TC 70-----
   WRITE(6,110)-----
   GO TO 60-----
C-----CORRECTIONS-----
7C CALL FRTCMS('CLRSCRN ')-----
   WRITE(6,10C)-----
   WRITE(6,10E)-----
   WRITE(6,150) FMIN-----
   WRITE(6,160) FMAX-----
   WRITE(6,19C)-----
   CALL RCHAR(ANS)-----
   IF ((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 1C-----
   GO TO 20-----
1C WRITE(5,50C)-----
   GO TO 30-----
20 CCNTINUE-----
   IF (IANS.EQ.IY) GO TC 40-----
   RETURN-----
C-----PLOTTING LIMITS FOR GRAPH'/'-----
100 FORMAT(/,5X,'PLOTTING LIMITS FOR GRAPH',/ )-----
110 FORMAT(10X,'FREQUENCY RANGE - RADIANS PER SECOND',/ )-----
1110 FORMAT(15X,'MINIMUM FREQUENCY = ',/ )-----
1120 FORMAT(15X,'MAXIMUM FREQUENCY = ',/ )-----
1130 FORMAT(15X,'MINIMUM FREQUENCY = ',15.3,/ )-----
1140 FORMAT(15X,'MAXIMUM FREQUENCY = ',15.3,/ )-----
1150 FORMAT(/,5X,'DO YOU DESIRE TO MAKE ANY CHANGES ?',/ ,10X,-----
   * TYPE "YES", OR "NO".,/ )-----
500 FORMAT(/,5X,'WARNING',/ )-----
   * 2X, ENTER "YES" OR "NO".,/ )-----
510 FORMAT(/,5X,'WARNING',/ )-----
   * 3X, FREQUENCY MUST BE GREATER THAN ZERO.,/ )-----
   END

```



```

C=====OPT21610
C=====OPT21620
C=====OPT21630
C=====OPT21640
C=====OPT21650
C=====OPT21660
C=====OPT21670
C=====OPT21680
C=====OPT21690
C=====OPT21700
C=====OPT21710
C=====OPT21720
C=====OPT21730
C=====OPT21740
C=====OPT21750
C=====OPT21760
C=====OPT21770
C=====OPT21780
C=====OPT21790
C=====OPT21800
C=====OPT21810
C=====OPT21820
C=====OPT21830
C=====OPT21840
C=====OPT21850
C=====OPT21860
C=====OPT21870
C=====OPT21880
C=====OPT21890
C=====OPT21900
C=====OPT21910
C=====OPT21920
C=====OPT21930
C=====OPT21940
C=====OPT21950
C=====OPT21960
C=====OPT21970
C=====OPT21980
C=====OPT21990
C=====OPT22000
C=====OPT22010
C=====OPT22020
C=====OPT22030
C=====OPT22040
C=====OPT22050
C=====OPT22060
C=====OPT22070
C=====OPT22080

SUBROUTINE RANGK(KMIN,KMAX)
SUBROUTINE RANGK INTERACTIVELY ALLOWS THE USER TO SELECT GAIN
LIMITS FOR USE WITH ROOT-LOCUS PLOTS
REAL*8 KMIN,KMAX
DATA IY,Y,IZ,N/
4C CCNTINUE
C WRITE(6,100)
C-----KMIN-----
5C WRITE(6,110)
CALL RCREAL(ANSR)
KMIN = ANSR
C-----KMAX-----
6C WRITE(6,120)
CALL RCREAL(ANSR)
KMAX = ANSR
C-----CORRECTICNS-----
7C CALL FRTCMS('CLRSCRN ')
WRITE(6,100) KMIN
WRITE(6,150) KMAX
WRITE(6,160) KMAX
WRITE(6,170) KMAX
CALL RCHAR(ANSR)
IF((IANS.NE.IY).AND.(IANS.NE.IZ)) GO TO 10
GO TO 20
1C WRITE(6,500)
GO TO 30
2C CCNTINUE
IF(IANS.EQ.IY) GO TO 40
RETURN
100 FORMAT(/,5X,'GAIN RANGE FOR ROOT-LOCUS PLCT',/)
110 FORMAT(15X,'MINIMUM GAIN = ',/)
120 FORMAT(15X,'MAXIMUM GAIN = ',/)
130 FORMAT(15X,'MINIMUM GAIN = ',E15.3,/)
140 FORMAT(15X,'MAXIMUM GAIN = ',E15.3,/)
150 FORMAT(/,5X,'DO YOU DESIRE TO MAKE ANY CHANGES ?',/,10X,
*TYPE "YES" OR "NO",/)
500 FORMAT(/,5X,'*****WARNING *****',/,5X,'IMPROPER DATA ENTRY ',/,
*3X,'ENTER "YES" OR "NO".',/)
END
SUBROUTINE GHEAD(NL)
SUBROUTINE GHEAD INTERACTIVELY ALLOWS THE USER TO INPUT THREE

```



```

C-----STOP-----OPT233050
5C  FORMAT(IX,'WARNING: NULL STRINGS ARE NOT ALLOWED, ENTER',OPT233060
   *IX,'CHARACTER VALUES.')

```

```

4C      CCNTINUE
5C      STOP
5C      FORMAT (1X,64HWARNING: NULL STRINGS ARE NOT ALLOWED, ENTER A NUMERICAL VALUE.)
6C      FORMAT (///,2X,42HPROGRAM KILLED - TWO NULL STRINGS ENTERED ,/)
C      END
C      =====
C      SUBROUTINE RDINT -- INTERACTIVELY READS AN INTEGER REPLY
C      INTCA FORTRAN PROGRAM. IF THE USER INADVERTENTLY ENTERS A NULL
C      STRING THE S/R ISSUES A WARNING AND ALLOWS A RECOVERY.
C      =====
C      SUBROUTINE RDINT (IANS)
C      INTEGER COUNT,IANS
C      =====
1C      COUNT=0
C      CCNTINUE
C      COUNT=COUNT+1
C      IF (COUNT.LT.3) GO TC 20
C      WRITE (6,6C)
C      GO TO 40
C      CCNTINUE
2C      READ (5,*,END=30,ERR=30) IANS
C      RETURN
3C      REWIND 5
C      WRITE (6,5C)
C      GO TO 10
4C      CCNTINUE
C      STOP
C      =====
5C      FORMAT (1X,64HWARNING: NULL STRINGS ARE NOT ALLOWED, ENTER A NUMERICAL VALUE.)
6C      FORMAT (///,2X,42HPROGRAM KILLED - TWO NULL STRINGS ENTERED ,/)
C      END
C      =====
C      SUBROUTINE RDCPAR -- INTERACTIVELY READS A CHARACTER STRING REPLY
C      (YES, OR NO) INTO A FORTRAN PROGRAM. IF THE USER INADVERTENTLY
C      ENTERS A NULL STRING THE S/R ISSUES A WARNING AND ALLOWS A RECOVERY.
C      =====
C      SUBROUTINE RDCPAR (IANS)
C      INTEGER COUNT,IANS
C      =====
1C      COUNT=0
C      CCNTINUE
C      COUNT=COUNT+1
C      IF (COUNT.LT.3) GO TC 20

```

```

2C      WRITE (6,6C)
        GO TO 40
        CCNTINUE
3C      READ (5,70,END=30,ERR=30) IANS
        RETURN 5
        WRITE (6,5C)
        GC TO 10
4C      CCNTINUE
        STOP
C-----
5C      FORMAT (1X,60HWARNING: NULL STRINGS ARE NOT ALLOWED, ENTER "YES"
        1CR "NO")
6C      FORMAT (//,2X,42HPROGRAM KILLED - TWO NULL STRINGS ENTERED ,/)
7C      FORMAT (A1)
        END
C=====
C      SUBROUTINE MINMAX(N,AA,MIN,MAX)
C      SUBROUTINE MINMAX FINDS THE MINIMUM AND MAXIMUM VALUES FOR A ONE
C      DIMENSIONAL ARRAY
C=====
C      REAL*4 MIN,MAX,AA
C      INTEGER N
C      DIMENSION AA(N)
C-----
        MAX = AA(1)
        MIN = AA(1)
        DO 10 I = 1,N
            IF (AA(I) .GT. MAX) GC TO 5
            IF (AA(I) .LT. MIN) GC TO 6
        GO TO 10
        MAX = AA(1)
        MIN = AA(1)
        CCNTINUE
        RETURN
        END
C=====
C      SUBROUTINE MAKPOL(N,R,C)
C      SUBROUTINE MAKPOL COMPUTES THE COMPLEX COEFFICIENTS OF AN N-TH
C      DEGREE POLYNOMIAL GIVEN N COMPLEX ROOTS OF THE POLYNOMIAL
C=====
C      COMPLEX*16 R(N),C(N)
C      IF (N .LE. 0) RETURN
C      DO 10 I=1,N

```



```

15 WRITE(6,510)
25 GC TO 30
CCNT INUE
PTS = IANS
C-----
C-----
100 FORMAT(/,5X,'HOW MANY POINTS DO YOU WANT TO TABULATE?',/,
*10X,'(50 IS THE MAXIMUM)',/)
110 FORMAT(/,5X,'ENTER NUMBER OF POINTS',/)
510 FORMAT(/,5X,'***** ERROR ***** MUST ENTER BETWEEN 1 AND 50
*0 POINTS',/)
C-----
END
C=====
C=====
SUBROUTINE FSCALE(PAGEX)
SUBROUTINE PSCALE AUTOMATICALLY SCALES DISSPLA FLCTS
C=====
REAL*4 PAGEX,TS,TH,IH1,I1,I2,I3,I4,I5,I6,I7,I8,I9,I10
COMMON /SCALE/ TS,TH,IH1,I1,I2,I3,I4,I5,I6,I7,I8,I9,I10
C-----
TS = PAGEX/11.0
TH = 0.14*TS
IH1 = 0.10*TS
I1 = 0.60*TS
I2 = 1.60*TS
I3 = 1.20
I4 = 0.30*TS
I5 = 2.10*TS
I6 = 0.9*TS
I7 = 2.00*TS
I8 = 0.20*TS
I9 = 2.0*TS
I10 = 3.0*TS
IF(PAGEX.LT.6.0) T3 =1.0
RETURN
C-----
END

```

APPENDIX D
OPGRAPH LISTING

This portion of the thesis contains a sample of tabular
output sent to a disk (OPGRAPH LISTING)

BCCE PLOT COMPENSATOR TRANSFER FUNCTION

INPUT NUMBER = 1
 OUTPUT NUMBER = 1
 DENOMINATOR ORDER = 2
 NUMERATOR ORDER = 1
 TRANSFER FUNCTION (DC) GAIN = -0.1135D+06

FREQUENCY (RAD/SEC)	MAGNITUDE (DECIBELS)	PHASE (DEGREES)	REAL PART	IMAGINARY PART
0.1000D+02	0.4815D+02	-0.1482D+03	-0.2171D+03	-0.1346D+03
0.1778D+02	0.5106D+02	-0.1401D+03	-0.2740D+03	-0.2292D+03
0.3162D+02	0.5504D+02	-0.1423D+03	-0.4466D+03	-0.3456D+03
0.5623D+02	0.5891D+02	-0.1629D+03	-0.8431D+03	-0.2598D+03
1.0000D+02	0.5956D+02	-0.2025D+03	-0.8786D+03	-0.3637D+03

LIST OF REFERENCES

1. Hall, W. E., Computational Methods for the Synthesis of Rotary-Wing VTOL Aircraft Control Systems, Ph.D. Dissertation, Stanford Univ., Aug. 1977.
2. Walker, R. A., User's Manual for OPTSYS 4 at SCIP, Stanford Univ., Aero/Astro Dept., Dec. 1979.
3. Liu, G., User's Manual for OPTSYS 5 at CIT, Stanford Univ., Aero/Astro Dept., Aug. 1982.
4. Hoden, J. G., Interactive Implementation of the Optimal Systems Control Design Program (OPTSYSX) on the IBM/3033, MS Thesis, Naval Postgraduate School, Monterey CA.
5. Diel, H. A., Development of Graphical Time Response using the OPTSYSX Program, MS Thesis, Naval Postgraduate School, Monterey CA.
6. Bryson, A. E. and Ho, Y. C., Applied Optimal Control, Hemisphere Pub. Co., 1969, (2nd Printing, 1975).
7. Research and Educational Association, Problem Solver in Automatic Control Systems/Robotics, 1982.
8. Kwakernaak, H. and Sivan, R., Linear Optimal Control Systems, Wiley-Interscience, 1972.

BIBLIOGRAPHY

D'Azzo, J.J. and Houpis, C.H., Linear Control System Analysis and Design: Conventional and Modern, McGraw-Hill, 1981.

DiStefano III, J.J., Stubberud, A.R., and Williams, I.J., Feedback and Control Systems, Schaum's Outline Series, McGraw-Hill, 1967.

Lipschutz, S. and Poe, A., Programming with FORTRAN, Schaum's Outline Series, McGraw-Hill, 1978.

Melsa, J.L. and Jones, S.K., Computer Programs for Computational Assistance in the Study of Linear Control Theory, McGraw-Hill, 1973.

INITIAL DISTRIBUTION LIST

	No.	Copies
1. Defense Technical Information Center Cameron Station Alexandria Va 22314		2
2. Chairman, Code 67 Department of Aeronautics Naval Postgraduate School Monterey, Ca 93943		1
3. Library, Code 0142 Naval Postgraduate School Monterey Ca 93943		2
4. Professor D.J. Collins Code 67Co Department of Aeronautics Naval Postgraduate School Monterey, Ca 93943		5
5. CLR V.C. Gordon 315 Alameda Blvd. Coronado, Ca 92118		1
6. Professor A.E. Bryson Department of Aeronautics and Astronautics Stanford University Stanford, Ca 94305		1
7. LT M.H. Laptas 39 Valley Heights Holyoke, Ma 01040		5

END

FILMED

5-85

DTIC